




neat 2384246 Board Collaboration System User Manual

[Home](#) » [neat](#) » neat 2384246 Board Collaboration System User Manual 

neat.


2384246 Board Collaboration System
User Manual



Contents

- 1 2384246 Board Collaboration System
- 2 Neat Board – Collaboration System
- 3 Simple Setup
- 4 Size and Weight
- 5 Setup and Connectivity
- 6 Documents / Resources
 - 6.1 References

2384246 Board Collaboration System



Neat Board – Collaboration System

Neat Board transforms the meeting space experience by fitting powerful technology and all the capabilities of Zoom in an elegant all-in-one design.







Neat Board includes Screen, Camera, Speakers, Microphones and environmental sensors all in one compact design.

It's perfect for bringing superior-quality audio, video and collaboration tools to your huddle, focus and meeting spaces.

Neat Board works standalone but can also be accompanied by optional Neat Pad Controllers and Scheduling Displays.

Simple Setup

Neat Board is easy to set up, having just one cable and a choice of either a floor stand, with optional wheels, wall mount or table mount



Everything you need

Neat Board comes with everything you need to get started, including cables and the chosen mounting option.


MOUNTING OPTIONS:

Neat Board Floor Stand (optional)

Can be used with or without wheels

2x M6 screw, 3 in (75mm) 1x 5mm hex wrench

12x M4 screw, 0.3 in (8mm) 1x 3mm hex wrench 4x Wheels



IN THE BOX:

Neat Board: All-in-one collaboration system


Ethernet cable: 16.4ft (5m)

Power cord: 9.9ft (3m)

Neat Board Table Stand (Included)

2x M6 screw, 2.4 in (60mm)

1x 5mm hex wrench

**Marker holder**

2x Marker


1x 2,5mm hex wrench

Neat Board Wall mount (optional)

VESA compatible

2x M6 screw, 0.8 in (20mm)

1x 5mm hex wrench




Screws for mounting to the wall are not included.

Mounting on a wall should only be performed by qualified personnel in line with applicable facility and state regulations. The wall and the mounting equipment must safely withstand the load of the product.


Size and Weight

Neat Board with Floor Stand


Weight: 124.6 pounds (56,5 kg)



Neat Board with Table Stand
Weight: 102.6 pounds (46,5 kg)



Neat Board with Wall Mount
Weight: 111.6 pounds (50,6 kg)




Setup and Connectivity

Setup


Use the provided cables to set up the system.
Connect the cables according to the illustration.

Cables marked blue  are included

Cables marked in green  are optional and not required for basic use of the system.

Requirements for a complete setup

Internet connection
Zoom Room License



Environmental Requirements


Ambient operating temperature: 32° to 95° F (0° – 35° C)


Storage temperature: 5° – 149° F (-15° – 65° C)

Relative humidity: 20% to 80%

Additional Product Information

<https://neat.no/board>



 The 16.4 ft Ethernet Cable provided is not to be used for in-wall installation. In-wall cable routing should only be performed by qualified personnel using appropriate equipment.

neat.

Neat Board – User Manual rev06

www.neat.no



[neat 2384246 Board Collaboration System](#) [pdf] User Manual
2384246 Board Collaboration System, 2384246, Board Collaboration System, Collaboration System

References

- [neat Neat - Meeting Spaces the Neat way](#)
- [neat Board](#)

[Manuals+](#)