



neat Board 50 Multi-Touch 4K Screen Drive Dynamic Collaboration User Guide

[Home](#) » [neat](#) » neat Board 50 Multi-Touch 4K Screen Drive Dynamic Collaboration User Guide 

neat.

User guide for Zoom
Neat Board, Board 50 and
Board Pro



Updated October 2024

Contents

- 1 How to start a scheduled meeting
- 2 In meeting controls
- 3 Share content via cable
- 4 Whiteboarding
- 5 Documents / Resources
 - 5.1 References


How to start a scheduled meeting

1. Your scheduled meeting will automatically appear on the home screen – tap Start to start your meeting.



Joining from Board with a meeting ID

1. Select Join.
2. Enter your Zoom meeting ID (found in the meeting invite).
3. Press Join on the screen.
4. If the meeting has a meeting passcode, a pop-up window will appear. Enter the meeting passcode and press OK.




Direct Guest Join (DGJ) allows Zoom Rooms to join Google Meet, Microsoft Teams, and Webex meetings without the need for additional infrastructure or licensing.

Utilize the DGJ application buttons on the home screen or the icons from the “Join” screen by entering the aligned meeting ID.

DGJ application buttons on the home screen must be enabled within the Zoom admin settings.

In meeting controls



Camera controls


Camera control options can be used to help remote participants to have a better view of in meeting participants

1. Select Camera Mode menu
2. Toggle through the menu to select preferred camera option



One-click direct share


1. Open your Zoom desktop app1.
2. Click on the Home button on the top left.
3. Press the Share Screen button & you will directly share with your desktop on your in room screen.



Sharing with a key

Sharing outside of a Zoom meeting:

1. Press Share Content and a pop-up with the sharing key will appear.
2. Tap Share Screen on personal device Zoom app, a Share Screen pop-up will appear.
3. Enter the sharing key & press Share.



Sharing with a key

Sharing within a Zoom meeting:

1. Press Share Content and a pop-up with the sharing key will appear.
2. Tap Share Screen on personal device Zoom app, a share screen pop-up will appear.
3. Enter the sharing key & press Share.



Share content via cable


1. Plug in the cable to your devices and screen sharing will begin.

Neat Board 50 and Neat Board Pro – USBC cable Neat Board – HDMI cable

If you tap Stop Sharing and leave the HDMI cable connected, you can start sharing again by tapping the Share button.




Whiteboarding



neat.

All Neat Boards – user guide for Zoom

Documents / Resources

 <p>Neat Board, Board 50 and Board Pro User guide for Zoom</p>	<p>neat Board 50 Multi-Touch 4K Screen Drive Dynamic Collaboration [pdf] User Guide Board 50, Board 50 Multi-Touch 4K Screen Drive Dynamic Collaboration, Multi-Touch 4K Screen Drive Dynamic Collaboration, 4K Screen Drive Dynamic Collaboration, Drive Dynamic Collaboration, Dynamic Collaboration, Collaboration</p>
---	---

References

- [User Manual](#)

[Manuals](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.