



## nedis Bluetooth Speaker with a unique and fun design User Guide

[Home](#) » [nedis](#) » nedis Bluetooth Speaker with a unique and fun design User Guide 


nedis Bluetooth Speaker with a unique and fun design

nedis

# Bluetooth® Speaker

with a unique and fun design

SPBT4100BG | SPBT4100BK  
SPBT4100GY | SPBT4100RD



[ned.is/spbt4100bg](https://ned.is/spbt4100bg)



[ned.is/spbt4100bk](https://ned.is/spbt4100bk)



[ned.is/spbt4100gy](https://ned.is/spbt4100gy)



[ned.is/spbt4100rd](http://ned.is/spbt4100rd)

## Bluetooth® Speaker

SPBT4100BG | SPBT4100BK  
SPBT4100GY | SPBT4100RD



For more information see the extended manual online:

[ned.is/spbt4100bg](http://ned.is/spbt4100bg) | [ned.is/spbt4100bk](http://ned.is/spbt4100bk)  
[ned.is/spbt4100gy](http://ned.is/spbt4100gy) | [ned.is/spbt4100rd](http://ned.is/spbt4100rd)

### Intended use

The Nedis SPBT4100BG | SPBT4100BK | SPBT4100GY | SPBT4100RD is a Bluetooth speaker that plays audio from your media device. The product is exclusively intended for playing music from a Bluetooth device and for answering and making hands-free phone calls. This product is not a toy, it is intended as a speaker. The product is not intended for professional use. Any modification of the product may have consequences for safety, warranty, and proper functioning.

#### Contents

- [1 Specifications](#)
- [2 Safety instructions](#)
- [WARNING](#)
- [3 Declaration of Conformity](#)
- [4 Documents / Resources](#)
  - [4.1 References](#)
- [5 Related Posts](#)

## Specifications

<b>Product</b>	Bluetooth® Speaker
<b>Article number</b>	SPBT4100BG   SPBT4100BK   SPBT4100GY   SPBT4100RD
<b>Power input</b>	5 VDC ; 0.5 A
<b>Bluetooth® version</b>	5.0
<b>Bluetooth® frequency range</b>	2402 - 2480 MHz
<b>Bluetooth® signal range</b>	Up to 10 m
<b>Frequency response</b>	100 Hz - 20 KHz
<b>Max. radio transmit power</b>	4.92 dBm
<b>Max. antenna gain</b>	-0.58 dBi
<b>Peak power</b>	9 W
<b>Power (RMS)</b>	3 W
<b>Impedance</b>	4 Ω
<b>Sensitivity</b>	81 dB
<b>Driver size</b>	40 mm
<b>Battery type</b>	Lithium-ion (602040)
<b>Charging time</b>	Up to 1.5 hours
<b>Battery capacity</b>	400 mAh
<b>Play time</b>	Up to 3 hours
<b>Built-in microphone</b>	Yes

### Main parts (image A)

1. Power button
2. Microphone
3. Micro USB cable
4. Micro USB port
5. Status indicator LED

### Safety instructions



#### WARNING

- Ensure you have fully read and understood the instructions in this document before you install or use the product. Keep this document for future reference.
- Only use the product as described in this document.
- Do not use the product if a part is damaged or defective. Replace a damaged or defective product immediately.
- This product can be used by children aged from 6 years and above and persons with reduced physical,

sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning the use of the product in a safe way and understand the hazards involved. Children shall not play with the product. Cleaning and user maintenance shall not be done by children without supervision.

- Not to be used by very young children (0-3 years).
- Usage by children should be supervised at all times.
- Do not drop the product and avoid bumping.
- This product may only be serviced by a qualified technician for maintenance to reduce the risk of electric shock.
- Disconnect the product from the power source and other equipment if problems occur.
- Do not expose the product to water or moisture.
- Do not use the product where splashing of water might occur e.g. bathrooms, swimming pools, or close to washbowls.
- This product is equipped with a non-removable internal battery. Do not attempt to replace the battery yourself.
- Provide enough ventilation during charging.
- Do not expose the product to direct sunlight, naked flames, or heat.
- Do not open the product.
- Do not use the product at locations where the use of wireless devices is prohibited due to potential interference with other electronic devices, which may cause safety hazards.
- Listening at a high volume for a long time will damage your hearing.

## Charging the product

1. Plug the micro USB cable **A(3)** into the micro USB port **A4**.
2. Plug the other end of **A(3)** into a USB adapter.
3. The status indicator LED **A(5)** lights up red.



**A(5)** turns off when the product is fully charged.

## Pair with Bluetooth

1. Press and hold the power button **A(1)** for 2 seconds to switch on the product.
2. **A(5)** blinks and the product emits a tone to indicate pairing mode is active.
3. Enable Bluetooth on the device you want to pair the speakers with.
4. Select "SPBT4100" from the list of available Bluetooth devices on your device.

## True Wireless Stereo (TWS)



TWS only works with two speakers of the same type.

1. Disable Bluetooth on the device you want to pair the speakers with.
2. Switch on both speakers.
3. Double press **A(1)** on one of the speakers.
4. After a few seconds, **A(5)** blinks and the product emits a tone to indicate pairing mode is active.
5. **A5** of the other speaker lights up.
6. Enable Bluetooth on the device you want to pair the speakers with.

7. Select “SPBT4100” from the list of available Bluetooth devices on your device.
8. Double press **A(1)** of one of the speakers, to switch off the TWS function.

## Controlling the music

- Press **A(1)** to play or pause the music.

## Making phone calls

- To answer an incoming call, press A1.
- To end a call, press A1.

## Declaration of Conformity

We, Nedis B.V. declare as a manufacturer that the product SPBT4100BG | SPBT4100BK | SPBT4100GY | SPBT4100RD from our brand Nedis®, produced in China, has been tested according to all relevant CE standards and regulations and that all tests have been passed successfully. This includes, but is not limited to the RED 2014/53/EU regulation.

The complete Declaration of Conformity (and the safety datasheet if applicable) can be found and downloaded via:

[webshop.nedis.com/spbt4100bg#support](http://webshop.nedis.com/spbt4100bg#support)

[webshop.nedis.com/spbt4100bk#support](http://webshop.nedis.com/spbt4100bk#support)

[webshop.nedis.com/spbt4100gy#support](http://webshop.nedis.com/spbt4100gy#support)

[webshop.nedis.com/spbt4100rd#support](http://webshop.nedis.com/spbt4100rd#support)

For additional information regarding the compliance, contact the customer service:

Web: [www.nedis.com](http://www.nedis.com)


E-mail: [service@nedis.com](mailto:service@nedis.com)

Phone: +31 (0)73-5991055 (during office hours)

Nedis B.V., de Tweeling 28

5215 MC 's-Hertogenbosch, the Netherlands

## Documents / Resources



 <p>nedis Bluetooth® Speaker with a unique and fun design SPBT4100BG   SPBT4100BK SPBT4100GY   SPBT4100RD</p>	<p><a href="#">nedis Bluetooth Speaker with a unique and fun design</a> [pdf] User Guide Bluetooth Speaker with a unique and fun design, SPBT4100BG, SPBT4100BK, SPBT4100GY, SPBT4100RD</p>
--	---

## References

- [Bluetooth® Speaker | Battery play time: up to 3 Hours | Handheld Design | 9 W | Mono | Built-in microphone | Linkable | Animaticks Olly Owl | Beige | Nedis](#)
- [Bluetooth® Speaker | Battery play time: up to 3 Hours | Handheld Design | 9 W | Mono | Built-in microphone | Linkable | Animaticks Pippy Penguin | Black | Nedis](#)

-  [Bluetooth® Speaker | Battery play time: up to 3 Hours | Handheld Design | 9 W | Mono | Built-in microphone | Linkable | Animaticks Melody Mouse | Grey | Nedis](#)
-  [Bluetooth® Speaker | Battery play time: up to 3 Hours | Handheld Design | 9 W | Mono | Built-in microphone | Linkable | Animaticks Perry Parrot | Red | Nedis](#)
-  [Bluetooth® Speaker | Battery play time: up to 3 Hours | Handheld Design | 9 W | Mono | Built-in microphone | Linkable | Animaticks Olly Owl | Beige | Nedis](#)
-  [Bluetooth® Speaker | Battery play time: up to 3 Hours | Handheld Design | 9 W | Mono | Built-in microphone | Linkable | Animaticks Pippy Penguin | Black | Nedis](#)
-  [Bluetooth® Speaker | Battery play time: up to 3 Hours | Handheld Design | 9 W | Mono | Built-in microphone | Linkable | Animaticks Melody Mouse | Grey | Nedis](#)
-  [Bluetooth® Speaker | Battery play time: up to 3 Hours | Handheld Design | 9 W | Mono | Built-in microphone | Linkable | Animaticks Perry Parrot | Red | Nedis](#)
-  [Bluetooth®-Lautsprecher | Batteriespielzeit: bis zu 3 Stunden | Handgerät | 9 W | Mono | Eingebautes Mikro | Verknüpfbar | Animaticks Pippy Penguin | Schwarz | Nedis](#)
-  [Bluetooth®-Lautsprecher | Batteriespielzeit: bis zu 3 Stunden | Handgerät | 9 W | Mono | Eingebautes Mikro | Verknüpfbar | Animaticks Melody Mouse | Grau | Nedis](#)
-  [Altavoz Bluetooth® | Tiempo de reproducción de la batería: Hasta 3 horas | Diseño portátil | 9 W | Mono | Micrófono incorporado | Enlazable | Animaticks Pippy Penguin | Negro | Nedis](#)
-  [Altavoz Bluetooth® | Tiempo de reproducción de la batería: Hasta 3 horas | Diseño portátil | 9 W | Mono | Micrófono incorporado | Enlazable | Animaticks Melody Mouse | Gris | Nedis](#)
-  [Bluetooth® Kaiutin | Akun toisto aika: Jopa 3 tuntia | Kannettava muotoilu | 9 W | Mono | Sisäänrakennettu mikrofoni | Linkitettävä | Animaticks Pippy Penguin | Musta | Nedis](#)
-  [Bluetooth® Kaiutin | Akun toisto aika: Jopa 3 tuntia | Kannettava muotoilu | 9 W | Mono | Sisäänrakennettu mikrofoni | Linkitettävä | Animaticks Melody Mouse | Harmaa | Nedis](#)
-  [Haut -parleur Bluetooth | Temps de lecture de la batterie: Up to 3 Hours | Conception portable | 9 W | Mono | Microphone intégré | Liable | Animaticks Pippy Penguin | Noir | Nedis](#)
-  [Haut -parleur Bluetooth | Temps de lecture de la batterie: Up to 3 Hours | Conception portable | 9 W | Mono | Microphone intégré | Liable | Animaticks Melody Mouse | Gris | Nedis](#)
-  [SPBT4100BK Manuals / Datasheets / Instructions - Manuals+](#)
-  [SPBT4100GY Manuals / Datasheets / Instructions - Manuals+](#)
-  [Altoparlante Bluetooth® | Tempo di riproduzione della batteria: Fino a 3 ore | Design portatile | 9 W | Mono | Microfono incorporato | collegabile | Animaticks Pippy Penguin | Nero | Nedis](#)
-  [Altoparlante Bluetooth® | Tempo di riproduzione della batteria: Fino a 3 ore | Design portatile | 9 W | Mono | Microfono incorporato | collegabile | Animaticks Melody Mouse | Grigio | Nedis](#)
-  [Bluetooth®-Speaker | Batterij speelduur: Tot 3 Uur | Handheld Ontwerp | 9 W | Mono | Ingebouwde microfoon | Koppelbaar | Animaticks Pippy Penguin | Zwart | Nedis](#)
-  [Bluetooth®-Speaker | Batterij speelduur: Tot 3 Uur | Handheld Ontwerp | 9 W | Mono | Ingebouwde microfoon | Koppelbaar | Animaticks Melody Mouse | Grijs | Nedis](#)
-  [Nedis | Su mayorista de confianza en electronica de consumo | Nedis](#)
-  [Nedis | Su mayorista de confianza en electronica de consumo | Nedis](#)
-  [Bluetooth® Reprodukter | Doba přehrávání na baterie: Až 3 hodiny | Do ruky | 9 W | Mono | Vestavěný mikrofón | Propojitelný | Animaticks Pippy Penguin | Černá | Nedis](#)
-  [Bluetooth® Reprodukter | Doba přehrávání na baterie: Až 3 hodiny | Do ruky | 9 W | Mono | Vestavěný](#)

[mikrofon](#) | [Propojiteľný](#) | [Animaticks Melody Mouse](#) | [Sedá](#) | [Nedis](#)

-  [Nedis | Your wholesaler of consumer electronics](#)
-  [Nedis | Your wholesaler of consumer electronics](#)

[Manuals+](#).