

nedis EXSOC415UFWT Extension Socket User Guide


[Home](#) » [nedis](#) » nedis EXSOC415UFWT Extension Socket User Guide 

Contents

- [1 nedis EXSOC415UFWT Extension Socket](#)
- [2 Extension Socket](#)
- [3 Specifications](#)
- [4 Main parts \(image A\)](#)
- [5 Safety instructions](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)
- [7 Related Posts](#)

nedis

nedis EXSOC415UFWT Extension Socket



Extension Socket

Intended use

This product is intended to extend and multiply a single power outlet into four power sockets and two USB ports. The product is intended for indoor use only. Any modification of the product may have consequences for safety, warranty and proper functioning.

Specifications

Product	Extension Socket
Article number	EXSOC415UFWT
Cable length	1.5 m

Specifications (Power sockets)

Input power	250 V / 16 A
Electrical class	I
Nominal power	Max. 3680 W
IP rating	IP20

Specifications (USB ports)


Input power	230 V ~ 50 Hz
Output voltage	5 A
Output current	2.1 V

Output power	10.5 W
Average operation efficiency	79.19 %
Efficiency at low load (10 %)	73.76 %
No-load power consumption	0.08 W

Main parts (image A)

1. Power socket
2. USB ports
3. Box
4. Power plug
5. Mounting bracket
6. Mounting plate
7. Screw

A



Safety instructions

WARNING

- Ensure you have fully read and understood the instructions in this document before you install or use the product. Keep the packaging and this document for future reference.
- Only use the product as described in this document.
- Do not use the product if a part is damaged or defective. Replace a damaged or defective product immediately.
- Do not cover the product.
- Do not drop the product and avoid bumping.
- Do not expose the product to water or moisture.
- Always check that the voltage of the product corresponds to the mains voltage.
- Disconnect the product from the power source and other equipment if problems occur.
- Do not plug or unplug the power cable with wet hands.
- Do not unplug the product by pulling on the cable. Always grasp the plug and pull.
- Unplug the product from the power source and other equipment if problems occur.
- This product may only be serviced by a qualified technician for maintenance to reduce the risk of electric shock.

Installing the product (image B)


It is optional to fasten the product to a table.

- Fasten the product in a range of 1.5 meter from the power outlet.
 1. Place the mounting bracket A5 and mounting plates A6 on the table.
 2. Fasten A5 on the table with A6 and the screws A7.
 3. Slide the box A3 inside A5.
- The product can be fastened in multiple ways.
- To slide A3 out of A5, pull the legs of A5 slightly outwards.

Using the product

- Only plug the cable into a wall outlet. Do not use extension cords.
 1. Plug the product into a power outlet.
 2. Plug the desired cables into the power sockets and/or USB ports of the box.

B



For more information see the extended manual online: ned.is/exsoc415ufwt

Documents / Resources

	nedis EXSOC415UFWT Extension Socket [pdf] User Guide EXSOC415UFWT, Extension Socket
---	--

References

- [Smart solutions for your daily needs | Nedis](#)