


nedis ZBPB10BK Zigbee SOS Panic Button Instruction Manual

[Home](#) » [nedis](#) » nedis ZBPB10BK Zigbee SOS Panic Button Instruction Manual 

Contents

- [1 nedis ZBPB10BK Zigbee SOS Panic Button Instruction Manual](#)
- [2 Safety instructions](#)
- [3 About this document](#)
 - [3.1 Symbols used](#)
- [4 Safety instructions](#)
 - [4.1 1 CAUTION!](#)
 - [4.2 NOTICE](#)
- [5 Declaration of Conformity](#)
 - [5.1 Read More About This Manual & Download PDF:](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)

nedis ZBPB10BK Zigbee SOS Panic Button Instruction Manual



Safety instructions

Zigbee SOS / Panic Button



For more information see the extended manual online: ned.is/zbpb10bk

About this document

This document is the user manual and contains all the information for correct, efficient and safe use of the product. Ensure you have fully read and understood the instructions in this document before you install or use the product. Keep the packaging and this document for future reference. Only use the product as described in this document.

Symbols used

6 WARNING!
Signal word used to indicate a potentially hazardous situation which, if not avoided, could result in death or serious injury.
1 CAUTION!
Signal word used to indicate a potentially hazardous situation which, if not avoided, could result in minor or moderate injury.
NOTICE
Signal word used to address practices not related to physical injury.

Intended use

This product is intended as a panic button that the user can carry with them to alert a person connected to this product via the Nedis Smartlife App in case of an emergency.

Please note that the product must be within the range of your designated Zigbee network, and the person you intend to alert must have correctly installed the Nedis app on their mobile device with the appropriate settings configured.

This product requires the Nedis Zigbee Gateway WIFIZB10WT to use the product wirelessly.

This product is intended to be used with the Nedis SmartLife app.

This product is intended for indoor use only.

Only use the product as described in this user manual.

Safety instructions

6 WARNING!

Choking hazard:

- Do not let children play with the packaging material. Always keep the packaging material out of the reach of

Chemical burn hazard:

- Battery usage by children should be
- Always keep button cell batteries, both full and empty, out of reach of children to avoid the chance of Dispose of used batteries immediately and safely. Keep in mind that the first symptoms may look like child diseases like coughing or drooling. Seek immediate medical attention when you suspect that batteries have been swallowed.
- Seek medical advice immediately if a cell or battery has been swallowed.

1 CAUTION!

Chemical hazard:

- Do not subject cells or batteries to mechanical Environmental hazard:
- Properly dispose empty cells or batteries

NOTICE

Risk of damaging the product:

- Do not immerse the product in water or other
- Do not expose the product to water, rain, moisture, or high
- Do not use aggressive chemical cleaning agents when

cleaning the product.

- Do not use any cell or battery that is not designed for use with the product. Use only the cell or battery in the product for which it was

Risk of improper functionality of the product:

- Ensure that your Zigbee network provides enough coverage throughout your home, paying special attention to areas where the signal might weaken or drop entirely. Verify that the Nedis SmartLife app is correctly installed on the mobile device of the person you intend to alert in case of an emergency. Insufficient Zigbee network coverage or incorrect installation of the Nedis SmartLife app may result in improper functioning of the
- Do not drop the product and avoid
- Do not use the product if a part is damaged or Replace a damaged or defective product immediately.
- Wipe the cell or battery terminals with a clean dry cloth if they become dirty.
- Observe the plus (+) and minus (–) marks on the cell or battery and product and ensure correct

Disposal

The product is designated for separate collection at an appropriate collection point. Do not dispose of the product with household waste.

For more information, contact the retailer or the local authority responsible for the waste management.


Declaration of Conformity

We, Nedis B.V. declare as manufacturer that the product ZBPB10BK from our brand Nedis®, produced in China,

has been tested according to all relevant CE standards and regulations and that all tests have been passed successfully. This includes, but is not limited to the RED 2014/53/EU regulation.
The complete Declaration of Conformity (and the safety datasheet if applicable) can be found and downloaded via: nedis.com/ZBPB10BK#support

Read More About This Manual & Download PDF:

Documents / Resources

	nedis ZBPB10BK Zigbee SOS Panic Button [pdf] Instruction Manual ZBPB10BK Zigbee SOS Panic Button, Zigbee SOS Panic Button, SOS Panic Button, Panic Butt on, Button
---	--

References

-  [Nedis | Your wholesaler of consumer electronics](#)
-  [Offer to sell domain: \[nedis.pl\]\(https://nedis.pl\)](#)
- [User Manual](#)

Manuals+. Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.