

Neomounts DS15-545BL1 Table Stand Instruction Manual

Home » Neomounts » Neomounts DS15-545BL1 Table Stand Instruction Manual


Contents

- 1 Neomounts DS15-545BL1 Table Stand Instruction Manual
- 2 Documents / Resources
 - 2.1 References
- **3 Related Posts**

Neomounts DS15-545BL1 Table Stand Instruction Manual

INSTRUCTION MANUAL






Measuring unit: mm


DS15-545BL1


Tablet stand


www.neomounts.com


DS15-545BL1













- 1. To ensure safety, please read this manual carefully before installation and follow the instructions. Store this manual in a secure place for future reference.
- 2. The manufacturer shall not be legally responsible tor any equipment damage or personal injury caused by incorrect installation or operation other than that covered in this manual.
- 3. The mount is designed for easy installation and removal. I he manufacturer shall not be liable for damage to eauipment or personal injuries arising out of human factors or acts of nature. such as earthquake or typhoon.
- 4. It is recommended that the mount be installed by qualified personnel only.
- 5. At least two persons are needed to Install or remove the product to avoid hazard or falling objects.
- 6. Please carefully inspect the area where the mount is to be installed:
 - Avoid places that are subject to high temperatures, humidity or contact with water.
 - Do not install the product near air conditioning vents or areas with excess dust and fumes.
 - Only install on vertical walls and avoid slanted surfaces.
 - Do not install in places subject to any shock or vibration.
 - Do not install In places subject to direct exposure to bright light, as it may cause eye fatigue when viewing the display panel.
- 7. Maintain sufficient space around the display to ensure adequate ventilation.
- 8. To ensure safe installation, first check the structure of the wall, ceiling or floor and select a secure mounting location.
- 9. The wall, ceiling or floor should be strong enough to sustain a weight of at least four times of the display and mount combined. The mounting location must be able to withstand earthquake or other strong shock.
- 10. Do not modify any accessories or use broken parts. Contact your dealer with any questions.
- 11. Tighten all screws (do not exert excessive force to avoid breaking the screw or damaging its thread).
- 12. Drill holes and bolts will be left in the wall. ceiling or floor once the display and bracket are removed. Stains may occur after extended use.
- 13. Since the manufacturer has no way to control the wall. ceiling or floor tune and installation of the mount. the warranty of the product shall only cover the body of the mount. The warranty period of the product is 5 years.
- 14. Please consult the English language manual for any dispute on conditions.

Documents / Resources



Neomounts DS15-545BL1 Table Stand [pdf] Instruction Manual DS15-545BL1 Table Stand, DS15-545BL1, Table Stand, Stand

References

- N Neomounts
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.