



NESTERA WiFi Bird Box Camera Instruction Manual

[Home](#) » [NESTERA](#) » NESTERA WiFi Bird Box Camera Instruction Manual 

Contents

- [1 NESTERA WiFi Bird Box Camera](#)
- [2 Whats in The Box?](#)
- [3 Specifications](#)
- [4 Connecting the Wifi Camera to the Nestera App](#)
- [5 Troubleshooting](#)
- [6 Mounting the Bird Box](#)
- [7 Using the Nestera App](#)
- [8 Frequently Asked Questions](#)
- [9 Troubleshooting](#)
- [10 Support](#)
- [11 About the Wifi Bird Box Camera](#)
- [12 Documents / Resources](#)



NESTERA WiFi Bird Box Camera



Whats in The Box?

- 1 x Camero-ready Bird Box
- 1 x WiFi Bird Box Camero
- 1 X Multi adopter 12V 1 Amp power supply unit
- 1 x 1 Om (30ft) power coble
- 1 x Hole protector set (32mm & 28mm) with mounting screws
- 1 x Bird Box mounting screw
- 1 x Coble clip

Specifications

Wifi Camera



*These LEDs are infrared and do not emit white light or disturb the birds.

Bird Box



Optional 28mm and 32mm entrance protection plates are included, making this an ideal Bird Box for a wide range of garden birds:



*This Bird Box features a removable front panel for larger birds, such as robins.

Connecting the Wifi Camera to the Nestera App



Nestera Bird Cam
for iOS



Nestera Bird Cam
for Android

Please download the Nestera Bird Cam App available on Apple App Store and Google Play Store by scanning the QR Code above

Smartphone/tablet

1. Search and download the 'Nestera Bird Com' App on App Store or Google Play Store or scan the QR Code above
2. Register/Log in to the App.
3. On the homepage, top 'Add Device' and seled 'Bird Box Camera (WiFi/IP)'.



Log In / Sign Up





Add Device



Select Camera Type


Bird Box Camera

4. Attach aerial to the back of WiFi Camera and remove the protective lens cap.
5. Attach IOM power cable and power supply unit to the WiFi Camera.
6. Slide the camera tray out of the Bird Box (1) and mount the WiFi Camera onto bracket (2).
7. Partially slide the camera tray back into the Bird Box so the WiFi Camera is looking down the front of the Bird Box (3) .




Smartphone/tablet & WiFi Camera

8. Select your WiFi Network and enter Wifi Password into the Nestera App and tap 'Next' to display a QR Code.
9. Connect the WiFi Camera to a mains power supply to turn it on.




10. Place your smartphone/tablet flat on its back with the top of your device against the front of the Bird Box so the QR Code can be read by the camera.
11. The WiFi Camera will scan the QR Code displayed on your smartphone/tablet. This can take up to 20 seconds. Do not move your smartphone/tablet during this process.
12. When you hear an audible 'click' from the WiFi Camera, tap 'I Heard o Prompt'.
13. The Nestera App will finalise the pairing process which can take up to 2 minutes. Tap 'Done' once complete.



Troubleshooting

If the Wifi Camero does not connect to the Nesterio App, hold the reset button on the WiFi Camero coble for o slow count of 6 ond return to Step 10.



Mounting the Bird Box

Slide Camera Tray Back into the Bird Box

Once your Wifi Camero is connected to the Nesterio App, tighten the screws on the side of the Wifi Camera and slide the camera troy fully back into the Bird Box, making sure the coble connections stay inside the Bird Box. The power cable should exit through the front right hand side of the Bird Box (as you look at it).

Adjust Lens Position

Remove the Bird Box's centre panel, and while looking at the live feed from the Wifi Camero in the Nesterio App on your smartphone/tablet, use your forefinger and thumb to adjust the position of the camera lens under the camera troy. The ideal camera position is tilted slightly towards the bock wall. Birds usually build their nest towards the rear of the Bird Box• and once birds ore nesting inside, you cannot adjust the camera's position.

Run the power coble under the eaves of the roof towards the bock of the Bird Box and secure it in place with the coble clip provided. When you ore happy with the position of the Wifi Camero, disconnect it from the mains power supply and toke the Bird Box outside.

Mounting the Bird Box

Using the fixing screw supplied, securely mount the Bird Box in your chosen location and reattach the centre panel. If required, attach one of the two metal hole protectors to the Bird Box entrance. Run the length of the

cable to your mains power supply, plug it back in and switch it on.

Using the Nestera App

Camera control screen



HD/SD Mode



Activate/ deactivate microphone



Full screen landscape mode @ Take a picture



Hold to speak



Record video



More options

Sharing Access to Your Wifi Bird Box Camera with Family & Friends

From the Live View, tap the three dots of the top right of the screen. Scroll down to 'Share Device' and tap 'Add Sharing' and select who to share with using the various methods shown.

Please note: anyone you share access with will need to download the Nestera Bird Cam App and log in.

Saving Your Photos & Videos

Cloud storage options are available within the Nestera App, but we recommend inserting a MicroSD Card (max. 128GB) into the WiFi Camera to save your footage locally. This can then be easily transferred to your smartphone/tablet, computer or storage device.

Frequently Asked Questions

Where should I place my Bird Box?

Different Bird Boxes will attract different species of birds depending on the size of the entrance hole and where the box is located. Check which birds will be suited to your Bird Box and position it accordingly.

Place the Bird Box in a quiet location in the garden; amongst other plants or trees, ensuring that any nesting birds have a clear flight path to and from the Bird Box. Make sure enough natural light is allowed through to the translucent window panels so you capture colour images.

We recommend the Bird Box faces between North and East to avoid direct sunlight and strong winds. If possible,

tilt the Bird Box slightly forward to protect the entrance hole from driving rain.

When is the best time of year to hang my Bird Box?

Garden birds start breeding around mid-February, so you should aim to have your Bird Box in place by the end of February, or the beginning of March. However, we have known Bird Boxes put up as late as April to have success.

How do I clean my Bird Box?

Most nests are known to harbour fleas and various other parasites, which can go on to infest newly-hatched or young birds the following year. Old, disused nests should be removed from Bird Boxes from August onwards (or only once you are 100% certain the birds have stopped using the nest).

Remove your WiFi Camera from the Bird Box before removing any nesting materials, then clean the Bird Box out with boiling water to kill any remaining parasites. Ensure the Bird Box is thoroughly dry before reinstalling the WiFi Camera or replacing the front panel. Never use insecticides or flea powders in a Bird Box.

What is the range of WiFi signal for my WiFi Bird Box Camera?

The range is approximately 15-20m depending on the surrounding environment and performance of your router. Large obstructions, such as garages and sheds can impact the range of your signal, so aim to place the Bird Box within line of sight of your router. If your smartphone/tablet has at least two bars of WiFi signal where you place your WiFi Bird Box Camera, this should be sufficient.

The WiFi Bird Box Camera scans the QR Code but will not connect

First, check that your router is broadcasting at 2.4GHz. Most domestic routers can broadcast at 2.4GHz and 5GHz frequencies, but the WiFi Bird Box Camera will only function at 2.4GHz. If you are unsure what frequency your router broadcasts, you may need to ask your broadband provider.

If you know your router is broadcasting at 2.4GHz, follow the Camera reset instructions under 'Troubleshooting' above.

I am scanning the QR Code but there is no audible 'click'

Tap the 'I heard a prompt' button and you will see a two-minute timer while it scans. If it times out without connecting, power off the WiFi Camera for 10 seconds at the mains and follow the Camera reset instructions under 'Troubleshooting' above.

Troubleshooting

Please refer to the FAQs and watch our Installation Guide video – see page 5 for QR Code.

Support

If you are still experiencing technical issues, use the Live Chat on our website where one of our friendly and knowledgeable technical specialists will be happy to help.

Business hours: 8am-4pm, Monday-Friday (except public holidays)

Share Your Favourite Moments

We love to be part of the action and to see how your feathery friends are getting on in your new Nester Bird Box! Share your favourite photos and videos with us by tagging us on social media or using #nester so we can share them on our own channels.

- nestera.uk
- nestera.us
- nestera.fr
- nestera.deutschland
- nestera.benelux
- nestera.uk
- nestera.us
- nestera.fr
- nestera.deutschland
- nestera.benelux

About the Wifi Bird Box Camera

Congratulations! You are now a step closer to nature with Nester's WiFi Bird Box Camera.

Our WiFi Bird Box Camera System allows 24/7 access to unseen, close-up HD video and audio of nesting birds in your garden on a smartphone or tablet. But the fun doesn't end there ...

With our secure, easy-to-use Nester app, you can record and share recorded or live footage of your nesting birds with friends and family, wherever they are in the world.


Our two decades of manufacturing experience has helped us create the perfect Bird Box Camera Systems for you to enjoy the wonders of nature up close. Made from responsibly sourced high-grade Western Red Cedar, our Bird Box designs adhere to guidelines suggested by the RSPB and BTO.

The 4.0 Megapixel WiFi Camera includes a 10m power cable and connects to the Nester app to provide stunning HD videos of your nesting birds.

The camera can also be used out of WiFi range with a CAT 5e Ethernet cable (up to 100m) that connects to a router. With our Power over Ethernet (PoE) adapter, this cable can also power the camera to offer a robust solution that does not rely on WiFi or power sockets near the Bird Box.

The PoE adapter and CAT5e Ethernet cable are optional extras.

Documents / Resources

	<p>NESTERA WiFi Bird Box Camera [pdf] Instruction Manual</p> <p>WiFi Bird Box Camera, Bird Box Camera, Box Camera, Camera</p>
---	---