

NETGEAR M5 Nighthawk 5G Mobile Router User Guide

Home » NETGEAR » NETGEAR M5 Nighthawk 5G Mobile Router User Guide 🖔



NETGEAR M5 Nighthawk 5G Mobile Router




Contents

- 1 What's in the box
- 2 Get to know your Mobile Router
- 3 Install the battery
- 4 Set up Your Mobile Router
- 5 Home screen
- 6 Connect to the Internet
- 7 LCD Settings
- 8 LCD WiFi Manager
 - 8.1 WiFi Manager
- 9 Download the NETGEAR Mobile
- 10 Support
- 11 Documents / Resources
 - 11.1 References
- **12 Related Posts**

What's in the box


- Nighhawk M5 5G Mobile Router
- · Battery cover
- Battery
- USB Type-C cable
- AC power adapter
- Quick start guide

Get to know your Mobile Router



Install the battery

1. Insert the battery.



2. Install the back cover.

The battery is partially charged. To fully charge it, connect the USB cable to the mobile router and then plug it into either:


- A wall socket, using the wall charger (faster charge option)
- · The USB port on your laptop

Note: The SIM card must be activated with a data plan with your operator.

Set up Your Mobile Router

1. Press and hold the Power button for two seconds.

To better safeguard your network, the first time you turn on your mobile router, you are asked to set up your login credentials.



2. Follow the onscreen instructions to customize your mobile router settings.

Customize your WiFi


We recommend you change the default credentials to your own custom credentials.

Don't customize

Customize

Home screen

The Home screen displays the mobile router's WiFi network name and password. The network indicator lets you know which wireless network you are connected to.



Note: The appearance of your home screen depends on the model.

Connect to the Internet

Note: The mobile router's Home screen displays the WiFi network name and password. The screen goes dark to save power. Press and release the Power button to wake the screen.

On your laptop or other WiFi device

- 1. Open your WiFi network connection manager.
- 2. Find your mobile router's WiFi network name (NTGR-XXXX) and connect.
- 3. Enter your mobile router's WiFi password.
- 4. Launch your Internet browser


Change the WiFi band

- 1. On the home screen, tap the WiFi icon.
- 2. Tap Band.
- 3. Select the 2.4 GHz, 5 GHz, or dual WiFi band.

LCD Settings

View or change the settings

On the home screen, tap the Settings icon.




LCD WiFi Manager


You can manage the WiFi network and change the WiFi settings from the LCD screen.

Change the WiFi network name and password

1. On the home screen, tap the **WiFi** icon.



2. Tap WiFi and then select from the available WiFi networks.




- 3. Tap WiFi Name and enter your changes.
- 4. Tap WiFi Password and enter your changes.

You can use a browser to view and change the mobile router settings.

Log In

- 1. On your mobile router, go to the LCD Settings screen, tap the **More** icon. Then tap **Device Information** and look for the WiFi Manager URL.
- 2. On the WiFi device that is connected to your mobile router, type the WiFi Manager URL in the browser bar.
- 3. Log in as administrator. The default login is printed on the product label.



Download the NETGEAR Mobile app

Use the NETGEAR Mobile app to change your WiFi network name and password. You can also use it to play and share media, and enable the travel router feature.

- 1. Connect your mobile device to the Internet.
- 2. Download the NETGEAR Mobile app from netgear.com/mobileapps.

Support

For additional information, visit netgear.com/support.

Compliance

For regulatory compliance information including the EU Declaration of Conformity, visit https://www.netgear.com/about/regulatory/ to access the full user manual and to download firmware updates.

See the regulatory compliance document before connecting the power supply.



Floor 1, Building 3, University Technology Centre Curraheen Road, Cork, T12EF21, Ireland

NETGEAR, Inc.

350 East Plumeria Drive San Jose, CA 95134, USA

© NETGEAR, Inc., NETGEAR and the NETGEAR Logo are trademarks of NETGEAR, Inc. Any non-NETGEAR trademarks are used for reference purposes only.

NETGEAR®

Documents / Resources



NETGEAR M5 Nighthawk 5G Mobile Router [pdf] User Guide

M5 Nighthawk 5G Mobile Router, M5, Nighthawk 5G Mobile Router, Mobile Router, Router

References

- N Regulatory | NETGEAR
- N NETGEAR Nighthawk App | NETGEAR
- N NETGEAR Support | NETGEAR
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.