



NETKRAFT 5163+4W282 Wireless Keyboard and Mouse Combo User Manual

[Home](#) » [NETKRAFT](#) » NETKRAFT 5163+4W282 Wireless Keyboard and Mouse Combo User Manual 

Contents

- [1 NETKRAFT 5163+4W282 Wireless Keyboard and Mouse Combo](#)
- [2 BATTERY INSTALLATION](#)
- [3 CONNECTING RECEIVER](#)
- [4 PROBLEM-SOLVING](#)
- [5 FCC Compliance Notice](#)
- [6 Documents / Resources](#)
- [7 Related Posts](#)

NETKRAFT INC

NETKRAFT 5163+4W282 Wireless Keyboard and Mouse Combo



BATTERY INSTALLATION


The mouse requires two AAA batteries. The keyboard requires an AA battery

Installing the batteries on the mouse

Step 1: Open the battery compartment located below the mouse

Step 2: Insert the batteries

Step 3: Close the compartment




Installing the battery on the keyboard

Step 1: Open the battery compartment located below the keyboard

Step 2: Insert the battery

Step 3: Close the compartment




CONNECTING RECEIVER

The receiver must be plugged into a direct USB port or a USB extender.



USB Port



Connect the USB receiver to your computer's USB port.

MULTIMEDIA FUNCTION



Play and Pause



Stop



Previous



Next



Volume-



Volume+



Mute



Home Page

WIRELESS RECEIVER

1. The receiver is in a compartment located at the back of the keyboard
2. The compartment is used to store the receiver during transport.

PROBLEM-SOLVING

When your mouse has problems, check

1. If the batteries have been in use for a long time, replace them with new batteries.
2. If the mouse LED is on but still un running, follow the steps below. Step1.Disconnect and connect the receiver to the USB port available from the computer.
3. Step 2. Place the mouse near the receiver (about 10 cm), remove the batteries and reinstall the batteries of the mouse.
4. If the mouse turns on, the mouse is ready for use.

ENERGY SAVING

To save battery power, our product has an energy-saving system, avoiding unnecessary mouse and keyboard expenses when both are not in use.

Stand-by mode: If the devices are not used for 45 seconds, they will go into Stand-by mode.

Suspension mode: If the devices are not used for 15 minutes, they will go into Suspension mode, and you need to press any button to wake them up.

FCC Compliance Notice

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.


This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Documents / Resources

	<p>NETKRAFT 5163+4W282 Wireless Keyboard and Mouse Combo [pdf] User Manual 4W282, 2A8ZH4W282, 5163 4W282 Wireless Keyboard and Mouse Combo, 5163 4W282, 5163 4W282 Wireless Combo, Wireless Keyboard and Mouse Combo, Wireless Keyboard, Keyboard and Mouse, Wireless Mouse, Keyboard, Keyboard and Mouse Combo, Keyboard and Mouse</p>
---	---