

[Skip to content](#)

Manuals+

User Manuals Simplified.



NetVIP WiFi Repeater Extender 519 User Manual

[Home](#) » [NetVIP](#) » NetVIP WiFi Repeater Extender 519
User Manual

NetVIP WiFi Repeater Extender 519 User Manual



Contents [hide](#)

[1 24h Tech Support:](#)

[2 2 Working Modes;](#)

[3 How to set Repeater Mode](#)

[4 Reference Video](#)

[5 FQ](#)

[6 Documents / Resources](#)

[6.1 References](#)

[7 Related Posts](#)

24h Tech Support:

awanka@163.com

2 Working Modes;

(Select based on your needs)

1. Repeater Mode

Plug NETVIP WiFi Booster into your power socket, easily expand your existing WiFi coverage to signal dead zones

2. Access Point Mode

Connect your router signal with Ethernet Cable, cover a wired network to a wireless access point.

How to set Repeater Mode

- **Step 1** Plug the item into power socket directly. Turn off your cell data, connect the repeater signal.




- **Step 2;** Open your browser and go to the web; 192.168.10.1




- **Step 3** User name and password are both admin



Step 3; Choose Repeater Mode.




- **Step 4;** Select your current Wifi



- **Step 5;** finish the setting



- **Step 6;** Done, close your browser directly



Reference Video

<https://youtu.be/3uoGpCGITWk>

<https://youtu.be/bGedIZMJSKE>

FQ

Why unable to open the IP address 192.168.188.1?

1. Before go to the web site, please connect the Repeater signal FIRST. (NOT your home wifi, a new signal in your WLAN list)
2. Please do not use the network cable before completing the setting.

Documents / Resources

NetVIP 519 WiFi Extender User Manual



[NetVIP WiFi Repeater Extender 519 \[pdf\] User Manual](#)

WiFi, Repeater, Extender, 519, awanka

References

- [Repeater Mode Setting - YouTube](#)
- [Repeater Mode Setup of WiFi Repeater - YouTube](#)

[Manuals+](#),

- [home](#)

- [privacy](#)