netvox DSC716L Illuminance Meter





netvox DSC716L Illuminance Meter User Manual

Home » netvox » netvox DSC716L Illuminance Meter User Manual



Contents

- 1 netvox DSC716L Illuminance
- Meter
- 2 Introduction
- **3 Features**
- 4 Set up Instructions
- **5 Important Maintenance Instruction**
- 6 Documents / Resources
 - **6.1 References**
- **7 Related Posts**



netvox DSC716L Illuminance Meter




Copyright@Netvox Technology Co., Ltd

This document contains proprietary technical information which is the property of NETVOX Technology. It shall be maintained in strict confidence and shall not be disclosed to other parties, in whole or in part, without written permission of NETVOX Technology. The specifications are subject to change without prior notice

Introduction

DSC716L detects the illuminance and displays the data on LCD. You can easily know the illuminance and find your device a good installation spot by one short press.

Appearance



Features


- · Simple operation
- · Light and easy to carry
- Low power consumption

Set up Instructions

Power On



LCD Interface




Important Maintenance Instruction

- Kindly pay attention to the following in order to achieve the best maintenance of the product:
- Do not put the device near or submerge in water. Minerals in rain, moisture, and other liquids could cause corrosion of electronic components. Please dry the device, if it gets wet.

- Do not use or store the device in dusty or dirty environments to prevent damage to parts and electronic components.
- Do not store the device in high temperatures. This may shorten the lifespan of electronic components, damage batteries, and deform plastic parts.
- Do not store the device in cold temperatures. Moisture may damage circuit boards as the temperatures rise.
- Do not throw or cause other unnecessary shocks to the device. This may damage internal circuits and delicate components.
- Do not clean the device with strong chemicals, detergents, or strong detergents.
- Do not apply the device with paint. This may block detachable parts and cause malfunction.
- Do not dispose of batteries in fire to prevent explosion.
- The instructions are applied to your device, battery, and accessories. If any device is not working properly, please bring it to the nearest authorized service provider for repair.

Documents / Resources



References

User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.