



nevir NEV005 Remote Control Instructions

[Home](#) » [nevir](#) » nevir NEV005 Remote Control Instructions 

Contents

- [1 nevir NEV005 Remote Control](#)
- [2 Remote Control Function](#)
- [3 Documents / Resources](#)
 - [3.1 References](#)
- [4 Related Posts](#)

nevir[®]

nevir NEV005 Remote Control



Remote Control Function



Originale	Sostituto
	Power
	Standby
	OPEN/CLOSE
	Eject
	Subt
	Audio
	Dual
	Angle
	Guide
	PS/IS
	Green
	1
	2
	3
	4
	5
	6
	7
	8
	9
	0
	GOTO
	Shift + Guide

Originale	Sostituto
	Mute
	Mute
	SETUP
	Options
	SOURCE
	AV
	TITLE
	Red
	MENU
	Menu
	Up
	Up
	Down
	Down
	Right
	Right
	Left
	Left
	ENTER
	Ok
	Ch +
	Ch +
	Ch -
	Ch -
	Vol +
	Vol +
	Vol -
	Vol -
	Rec
	Rec
	DISC OP
	List
	TIMER
	Shift + AV





Originale	Sostituto	Originale	Sostituto
	PLAY		Play
	PAUSE/STEP		Pause
	STOP		Stop
	I<</PREV		I<<
	>>/NEXT		>>I
	RETURN		Back
	<</FB		<<
	DVD		Smart
	>>/FF		>>
	ERASE		Yellow
	TIMESHIFT		3D
	ADD/CLEAR		Exit
	RANDOM		Blue
	ZOOM		Shift + Eject
	HDD/DUB		Media
	EDIT		Shift + Exit
	DV/USB		D. Menu
			FINALIZE
			QUALITY
			DISPLAY
			A-B
			REPEAT
			PROGRAM
			SORT/SLOW
			Pre Ch
			Shift + Back
			Info
			TV/R
			Text
			Sleep
			Format



<https://tutti-i-telecomandi.it/it/Nevir/1056277-60771-telecomando-di-sostituzione-per-Nevir-NEV005.html>.

Documents / Resources

	nevir NEV005 Remote Control [pdf] Instructions NEV005 Remote Control, NEV005, Remote Control, Control
--	--

References

- [User Manual](#)