

newline Q Pro Series High-Performance Interactive Display



newline Q Pro Series High Performance Interactive Display User Guide

[Home](#) » [newline](#) » newline Q Pro Series High Performance Interactive Display User Guide 

Contents

- 1 [newline Q Pro Series High-Performance Interactive Display](#)
- 2 [Product Usage Instructions](#)
- 3 [Q Pro Series Panel Front Buttons](#)
- 4 [The Front Ports](#)
- 5 [The Side Ports](#)
- 6 [The Home Screen](#)
- 7 [Moving Apps to Customize Home Screen](#)
- 8 [Switching Sources](#)
- 9 [Accessing the Built-In OPS Computer](#)
- 10 [Switching Sources](#)
- 11 [Installing the Wi-Fi Module](#)
- 12 [Changing the Settings](#)
- 13 [Launching Updates](#)
- 14 [Whiteboard Tools](#)
- 15 [Accessing the Google Play Store](#)
- 16 [Using Newline Cast](#)
- 17 [Using Newline Broadcast](#)
- 18 [FAQ](#)
- 19 [Documents / Resources](#)
 - 19.1 [References](#)

newline

newline Q Pro Series High-Performance Interactive Display



Specifications

- USB Touch port x 1
- HDMI port x 1
- USB 3.0 ports x 2
- USB Type-C with 65 watts power delivery port x 1
- Mic-in port x 1
- HDMI IN 2.0 x 2
- DisplayPort 1.2 x 1
- USB Type-B (Touch) x 3
- USB Type-C (no PD) x 1
- USB 3.0 Type-A x 2
- USB 3.0 Type-A to Android x 1
- HDMI OUT 2.0 x 1
- RS232 x 1
- RJ45 (Gigabit) IN x 1 & OUT x 1
- SPDIF x 1
- SDM/VGA x 1
- Audio Line out x 1
- Wi-Fi module slot OPS Slot

Product Usage Instructions

Turning On and Off the Display

1. Press the Power button located on the bottom right side of the display to turn it on.
2. The button will change color from red to white once the display is powered on.

Accessing Home Screen and Settings

To access the Home Screen, press the Home Button. Press the Settings Button to bring up the settings menu.

Moving Apps and Customizing Home Screen

1. Long press on any app on the home screen to move its location.
2. To create a folder of multiple apps, move one app on top of another app.
3. To remove an app from the home screen or uninstall it completely, long press on the app.


Using Quick Access Toolbar

To access the Quick Access Toolbar, tap the white circle on either side of the screen. Tap again to minimize it.

Google Search and Android Toolbar

Utilize the Google Search Bar on the Home Screen to search the web and panel contents directly. The Android Toolbar provides quick access tools like Back, Home, and Task Switcher.

Q Pro Series Panel Front Buttons



Turning On the Display

1. Press the Power button on the bottom right side of the display.
2. The button will change color from red to white once the display is powered on.



The Front Ports

There are six ports located on the bottom left-hand side of the front of the panel: one USB Touch port, one HDMI port, two USB 3.0 ports, a USB Type-C with 65 watts power delivery port, and a mic-in port.



The Side Ports



The following ports are located on the left side of the panel


- HDMI IN 2.0 x 2
- DisplayPort 1.2 x 1
- USB Type-B (Touch) x 3
- USB Type-C (no PD) x 1
- USB 3.0 Type-A x 2
- USB 3.0 Type-A to Android x 1,

- HDMI OUT 2.0 x 1
- RS232 x 1
- RJ45 (Gigabit) IN x 1 & OUT x 1
- SPDIF x 1
- SDM/VGA x 1
- Audio Line out x 1
- Wi-Fi module slot
- OPS Slot

The Home Screen

Google Search Bar

Search the web and the contents of your panel directly from the home screen!




Quick Access Toolbar

The Quick Access Toolbar can be accessed by tapping the white circle on either the left or right side of the screen. To minimize the Quick Access Toolbar, tap the white circle again.




Android Toolbar

One the bottom on the panel screen is the Android toolbar. Use this toolbar for the following quick access tools




Moving Apps to Customize Home Screen

On the home screen, long press on any app to move its location. The panel will show you where you can place an app by creating a white rectangle in your desired location.




Bonus Tip: To create a folder of multiple apps, simply move one app on top of another app. A folder will be created automatically. Long press on the folder to rename the folder.



Bonus Tip: By long pressing, you also have the option to remove the app from the home screen or uninstall the app completely.


Switching Sources

1. Tap the Source icon on the home screen.
2. Any device currently connected to the display will light up in white in the Source window on the home screen.
3. Tap the icon of the source you want to switch to.
4. Plugging your device into the front ports will automatically bring up the device on screen.



Accessing the Built-In OPS Computer

1. Tap the Source icon on the home screen.
2. In the Source window that pops up, tap on the “OPS” button.
3. You will now be viewing and using the built-in OPS Computer.



Bonus Tip: You can also quickly navigate to the OPS using this icon on the floating menu on both sides of the display

Switching Sources


Connecting a Computer with USB-C

1. You will need a USB Type-C cable to connect a computer.
2. Plug in one end of the USB-C cable into the front or side USB-C port.
3. Take the other end of the USB-C port and plug it into the USB-C port on your computer.
4. Once both cables have been plugged into the display and the computer, the matching port should turn white on the Source window.



Connecting a Computer with USB & HDMI

1. You will need an HDMI cable and a USB A to B cable to connect a computer.
2. On the front or side ports of the Q Series, plug in one end of the HDMI cable into one of the HDMI ports.
3. Take the other end of the HDMI port and plug it into the HDMI port on your computer.
4. Plug in the USB-B end of the USB cable into one of the front or side ports labeled “USB Touch.”
5. Take the USB-A end of the USB cable and plug it into the USB port on your computer.
6. Once both cables have been plugged into the display and the computer, the matching port should turn white on the Source window.



Installing the Wi-Fi Module

1. Unscrew the 2 screws on the Wi-Fi Module port on the rear of the panel and remove the shielding cover.



Caution



The Wi-Fi Module does not support hot plugging. Therefore, you must insert or remove the Wi-Fi Module when the display is powered off. Otherwise, the displays or Wi-Fi Module may be damaged.

2. Insert the Wi-Fi Module into the port until firmly seated, then use the 2 screws to secure it.



Changing the Settings


1. From the home screen, select the Settings menu item.
2. From the Settings menu, you can adjust things like the Power settings, Internet Network settings, Date & Time, Wallpapers, and more.



Launching Updates


Updates to Firmware and Apps launch automatically “over the air.” A pop-up item will appear on the screen when the update is ready to be downloaded.

Whiteboard Tools




Accessing the Google Play Store

1. On the Home Screen, tap on the “Google Play Store” button.




2. In the Google Play Store, search and select the App you want to download.



3. On the App details screen, tap Install.




4. Once installed, new apps will appear on the second of the home screen. Swipe left to access this page. If you want to move the location of your downloaded apps, see page 5.




Using Newline Cast

Connecting to Newline Cast Using the DisplayNote Windows App

1. Open the Newline Cast app on your display.



2. Download the DisplayNote Windows App from displaynote.com/join on your computer.
3. Open the DisplayNote app on your laptop.
4. Type in the Session ID you see on the display and your name.
5. Select "Join" once both Session ID and Name are filled in.




Connecting to Newline Cast from a Web Browser

1. Open the Newline Cast app on your display.
2. Visit www.displaynote.com/join on your laptop and select “Connect via web.”
3. Type in the Session ID you see on the display and your name.
4. Select “Join” once both Session ID and Name are filled in.
5. When asked, select whether you want to share your entire screen, or just a specific application window.
6. Click “Share.”

Using Newline Broadcast

Share your Panel Screen to Student Devices

1. Turn on the display.
2. Begin a session by opening the Broadcast application and pressing the “Start broadcast” button.
3. Share the public share link with your viewers.
4. Begin your presentation.
5. To end the Broadcast, press the Stop Broadcast button.



Viewing a Broadcast

1. Click the link sent by the broadcast host, or go to broadcast.online, enter the 6-digit Broadcast ID and press Connect.
2. Users can interact with the “Enlarge” option to enlarge the broadcast information. This is designed to help users view the broadcast information from afar.
3. To leave a broadcast, press the Stop button at any time.

1-888-233-0868 info@newline-interactive.com
To learn more, visit: www.newline-interactive.com

FAQ

Q: How do I adjust the sound volume?

A: Use the Volume Button to adjust the sound volume higher or lower.

Q: How can I quickly switch between available sources?

A: Tap and hold the OPS/Sources Shortcut icon to pull up additional icons that can take you to the Sources menu for easy source switching.


Q: How do I access whiteboarding options?

A: Tap the Whiteboard Shortcut to access whiteboarding options on top of the current screen. Tap again to save a screenshot.





Q: Can I customize the Quick Access Menu?

A: Yes, tap the Quick Access Menu Button to open the menu and customize it according to your preferences.

Documents / Resources

	newline Q Pro Series High Performance Interactive Display [pdf] User Guide Q Pro Series High Performance Interactive Display, Q Pro Series, High Performance Interactive Display, Performance Interactive Display, Interactive Display, Display
--	--

References

-  [DisplayNote](#)
-  [Interactive - The Power of Communication - Interactive - The Power of Communication](#)
-  [DisplayNote](#)
-  [Newline - Global Leader in Interactive Displays](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.