



**FireNEX-UDC
Active USB-C to
USB C Adapter**



Newnex FireNEX-UDC Active USB-C to USB C Adapter User Guide

[Home](#) » [Newnex](#) » Newnex FireNEX-UDC Active USB-C to USB C Adapter User Guide 

Contents

- [1 Newnex FireNEX-UDC Active USB-C to USB C Adapter](#)
- [2 CONNECTION](#)
- [3 Specifications](#)
- [4 FAQ](#)
- [5 Documents / Resources](#)
 - [5.1 References](#)
- [6 Related Posts](#)



Newnex FireNEX-UDC Active USB-C to USB C Adapter



CONNECTION

1. Connect the Newnex special USB-C cable to device side of FireNEX-UDC.
 - If not using Newnex special USB-C cable, the USB-C connection will not support flip plug-in.



2. Connect a standard USB-C cable to the host side of FireNEX-UDC.



3. Connect the rest of USB connectors of the cables to host PC and USB devices.
4. Mount the bracket to the panel you intend to mount the FireNEX-UDC, the bracket is at Host side by default.
You may switch it to the device side with a hex screwdriver.



5. You can also remove the bracket if you don't need any mounting, keep the bracket stored in case you need it in the future.



FireNEX-UDC User Guide Rev 1.1

Specifications


- **Product Name:** FireNEX-UDC
- **Connector Type:** USB-C
- **Compatibility:** Host PC and USB devices
- **Bracket:** Mountable, reversible
- **Version:** Rev 1.1

FAQ

Q: Can I use any USB-C cable with FireNEX-UDC?

A: It is recommended to use the Newnex special USB-C cable for full compatibility and support for flip plug-in.

Documents / Resources

	<p>Newnex FireNEX-UDC Active USB-C to USB C Adapter [pdf] User Guide</p> <p>FireNEX-UDC Active USB-C to USB C Adapter, FireNEX-UDC, Active USB-C to USB C Adapter, USB-C to USB C Adapter, USB C Adapter, Adapter</p>
-----------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.