



Home » NEWYES » NEWYES AB0606 Notepad Calculator User Manual 📆

Contents [hide]

- 1 NEWYES AB0606 Notepad Calculator
- 2 Safety Precautions
- 3 Operation Precautions
- 4 Product parameters
- 5 Product Structure Diagram
- 6 Product Usage
- 7 Instructions for use
- 8 Instructions for Handwriting Board
- 9 Product Exception Handling
- 10 Documents / Resources
 - 10.1 References



NEWYES AB0606 Notepad Calculator



Safety Precautions

Battery

- This product is not a children's toy, and it is recommended to be used by people above 6 years old.
- It is strictly forbiddened to heat the whole product or battery, or place them in water or fire.

Operation Precautions


- When the screen of the calculator is dim, and the battery is obviously insufficient, you
 can unfold the product and place it flat under the sun or a fluorescent lamp. When the
 light source environment reaches 200LuXor above (household fluorescent lamps are
 generally 20-40 watts, and the light source environment can reach 200LuX or above),
 it can provide a normal power supply for the calculator.
- When the notepad can't be cleared, please check whether the anti-clearing lock key is in the locked state or not, if so, please turn it to the unlocked state. After the operation, if it still can't be cleared, please replace the button battery.
- This product is equipped with a button battery, when replaced the battery, it is strictly forbidden for children under 14 to do it to avoid accidental ingestion of the button battery.
- Do not use or store this product in areas with high temperature, high humidity, or excessive dust.

- Do not excessively impact, squeeze, or bend the calculator and handwriting board.
- Please use a soft and dry cloth to clean the exterior of the product, the LCD screen, and the notepad. Do not use hard objects other than the stylus pen to avoid scratching the LCD film, and do not use excessive force when writing.
- Whenever you discard this product or the lithium battery inside, pleasemake sure to comply with local laws and regulations.

Product parameters

Product name	Notepad Calculator		
Product size	15.3cm*9.0cm*1.6cm		
Product net weight	About 141g		
Working temperature	-10°C-40°C		
Battery type	Button battery		
Battery model	CR1220		
Battery life	More than 1 year		
Writing force	150-3009		
Calculator display digits	12 digits		
Calculator power supply	Solar panel and button battery		
Writing board life	More than 50,000 times		

Product Structure Diagram



Product Usage

- Simple arithmetic;
- Record the calculation process and results, you can record while calculating.
- It can be used in places such as home, school, shopping mall, and office.

Instructions for use

Button Introduction

- ON/AC: press this button to turn on the calculator or to clear all the values saved in the calculator:
- M+: save the currently displayed value in the memory and interrupts the input of digits;
- M-: subtract the currently displayed value from the memory content and interrupt the input of digits;
- MRC: press the button for the first time to recall the memory content and clear the memory content when pressing it for the second time;
- F: The backspace button clears the last digit of the number displayed on the LCD

screen;

- $\sqrt{\ }$: display the square root of a positive number input. (The square root);
- %: Percent;
- 0~9: number buttons, enter the numbers 0-9; . button: decimal point;
- +,-, x,÷,=: Operation button, addition, subtraction, multiplication, division, etc;

Calculation Example

Calculation Example	Operation	Screen Display	
100+50-30= (-10)×20÷0.5=	ON/AC 100 ± 50 □ 30 □ □ 10 × 20 ÷ 0.5 □	0 120 -400	
1234567890×66666=	1234567890×666666 目	82.3037029547	
√9×5=	9 √×5≡	15	
1500×10%= 1500+5%= 1500-5%= 20÷500%=	1500×10 % 1500 ± 5 % 1500 = 5 % 20 ÷ 500 %	150 1575 1425 4	
368+97+97= 839-47-47-47= 5 ⁻⁴ = 22.5 ³ =	368 ± 97 ≡ ≡ 839 □ 47 ≡ ≡ ≡ 5 ± ≡ ≡ ≡ 22.5 ⋉ ≡ ≡	562 698 0.0016 11390.625	
25×5 -) 84÷3 +) 68+17 182	25 ≥ 5 M+ 84 ÷ 3 M- 68 ± 17 M+ MRC	125 28 85 182	
123478+5	123456 ▶▶ 78 ⊕ 5 ≡	123456 1234 123478 123483	

Instructions for Handwriting Board

1. Before usage, please turn on the lock key first (at the top side), then the writing screen

^{*} The maximum number of digits entered on the screen is 12 digits. If the number exceeds 12 digits, an error mark ERROR will be displayed in the front

- can be cleared by clear key; if the lock key on the locked state, then when press the clear key can't clear the writing screen.
- 2. When writing on the lcd writing board, pls use the attched stylus pen to write, avoid using the sharp hard objects so as to avoid damaging the product
- 3. When not using the writing board, pls turn the lock key on the locked state to save battery power.

Product Exception Handling

Phenomena	Countermeasures
The calculator screen displ ay is dim	unfold the product and place it flat under the sun or whe re the light source environment reaches 200 LUX
The writing screen can't be cleared	please be sure that the lock key is turned to the unlocke d state
There are garbled codes du ring calculation	press ON/AC button
The stylus pen is missing	it can be replaced with other non-sharp hard objects

Button battery included not for kids under 6 vears old

WARNING

- INGESTION HAZARD: This product contains a button cell or coin battery.
- DEATH or serious injury can occur if ingested
- A swallowed button cell or coin battery can cause Internal Chemical. Burns in as little as 2 hours.
- KEEP new and used batteries OUT OF REACH of CHILDREN
- Seek immediate medical attention if a battery is suspected to be swallowed or inserted inside any part of the body.



Documents / Resources



NEWYES AB0606 Notepad Calculator [pdf] User Manual

AB0606, AB0606 Notepad Calculator, Notepad Calculator, Calculator

References

- User Manual
 - AB0606, AB0606 Notepad Calculator, Calculator, NEWYES, Notepad
- NEWYES Calculator

Email

Leave a comment

Your email address will not be published. Required fields are marked*

Comment *

Name

Website				
☐ Save my name, email,	and website in this browser fo	or the next time I com	ment.	
Post Comment				

Search:

e.g. whirlpool wrf535swhz

Search

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.