




NEXT audiocom A40 Stereo Amplifier with Bluetooth User Manual

[Home](#) » [NEXT audiocom](#) » NEXT audiocom A40 Stereo Amplifier with Bluetooth User Manual 

Contents

- [1 NEXT audiocom A40 Stereo Amplifier with Bluetooth](#)
- [2 INTRODUCTION](#)
- [3 PACKAGING CONTENTS](#)
- [4 WARRANTY POLICY](#)
- [5 SAFETY FIRST](#)
- [6 GETTING STARTED](#)
 - [6.1 WIRED CONNECTION](#)
 - [6.2 BLUETOOTH CONNECTION](#)
- [7 HANDS-ON](#)
 - [7.1 INSTALLATION](#)
- [8 TECHNICAL SPECIFICATIONS](#)
- [9 Documents / Resources](#)
- [10 Related Posts](#)



NEXT audiocom A40 Stereo Amplifier with Bluetooth



INTRODUCTION

Thank you for purchasing a NEXT Audiocom A40. This user manual will provide you with useful information about your equipment. Please devote some time reading it and keep it at hand for future reference. **ATTENTION!** Because of the continuous evolution of techniques and standards, NEXT Audiocom reserves the right to change the specifications of its products without warning. For the most updated version of this manual and general information about this and other products, please visit our website www.nextaudiocom.com.

PACKAGING CONTENTS

When unpacking your product, carefully examine it for any signs of possible transit damage and inform your dealer immediately if any such damage has occurred. It is suggested that you retain the original packaging so that the product can be repacked in the future when necessary.

- NEXT Audiocom A40
- 2-Pole Phoenix Type Connector (Power Input)
- 4-Pole Phoenix Type Connector (Speaker Output)

WARRANTY POLICY

NEXT Audiocom products are warranted, by NEXT Audiocom, against manufacturing defects in materials or craftsmanship over a period of 2 years counting from the date of original purchase for final customer. The original receipt of purchase is mandatory for warranty validation purposes, and the product must have been bought from a NEXT Audiocom authorized dealer.

SAFETY FIRST

Please take some time to review the following statements concerning safe use of your NEXT Audiocom A40.

- Read these instructions
- Keep these instructions
- Heed all warnings
- Follow all instructions
- Use the equipment only for its intended purpose as instructed in this manual
- Before installing, observe the applicable safety regulations for your country


- Always check if the equipment is installed securely and will not fall
- Never install close to ignition or heat sources such as radiators, ovens or any other apparatus that produce heat
- Do not use or install the equipment near water or exposed to rain
- If the equipment is not functioning properly or has been damaged in any way, switch it off immediately
- Do not open or try to service the equipment. It may only be repaired by authorized, qualified personnel

WARNINGS

Never remove the cover, because otherwise there may be a risk of electric shock. There are no user serviceable parts inside. Have repairs carried out only by qualified service personnel. The lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated #dangerous voltage “within the product’s enclosure that may be of sufficient magnitude to constitute a risk of electrical shock. The exclamation mark within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance instructions.


GETTING STARTED

1. Mains Power Input
2. Speaker Output
3. Bluetooth Status LED
4. Audio Signal Line-In (AUX) – 3.5mm Jack
5. Bluetooth Antenna



WIRED CONNECTION

Use the 3.5mm Stereo Jack to connect your audio player to the A40.



BLUETOOTH CONNECTION


Ensure the A40 is connected to the power socket and turned on. The Bluetooth LED Indicator starts flashing red. This indicates the A40 is ready to pair. Once successfully paired the LED turns solid red.

1. Turn on Bluetooth on your player and search for devices
2. Click “NEXT A40” to pair with your amplifier. Insert the PIN “2020” if requested.

HANDS-ON

INSTALLATION


1. Use the A40 to mark the spots for the holes that will hold it in place
2. Drill the holes. Use the correct drilling bit for the chosen anchors. Make sure you use the right anchors for the surface you are installing on. (not included)
3. Check that the A40 is installed securely and will not fall
4. Connect all the cables



TECHNICAL SPECIFICATIONS

- Product Type: Class D
- Amplifier Frequency Response: 20Hz-20kHz
- Amplifier Output: 2 x 30W@ BO
- Bluetooth Technology: 2.1 +EDR
- Bluetooth Range: 10m
- Input Sensitivity: 0dBV (0. 7V)
- Power Supply: AC 1 DDV-240V/50Hz-60Hz

Documents / Resources

	<p>NEXT audiocom A40 Stereo Amplifier with Bluetooth [pdf] User Manual A40 Stereo Amplifier with Bluetooth, A40, Stereo Amplifier with Bluetooth, Stereo Amplifier, Amplifier</p>
---	---