



# NEXXT NHB-C110 Smart Wi-Fi LED color Bulb User Guide

[Home](#) » [NEXXT](#) » NEXXT NHB-C110 Smart Wi-Fi LED color Bulb User Guide 

## Contents

- [1 NEXXT NHB-C110 Smart Wi-Fi LED color Bulb](#)
- [2 Product overview](#)
- [3 Package content](#)
- [4 Installing the Nexxt Home App](#)
- [5 Bulb installation](#)
- [6 Add device](#)
- [7 Functions](#)
- [8 Timer setup](#)
- [9 Schedule setup](#)
- [10 Power-on memory](#)
- [11 Settings](#)
- [12 WARRANTY](#)
- [13 Documents / Resources](#)
  - [13.1 References](#)
- [14 Related Posts](#)





### User guide

Thank you for purchasing the Smart Wi-Fi LED color bulb from Nexxt Solutions. We are excited to be part of making your life easier, safer and bringing peace of mind into your homes.

### Product overview


1. LED: Displays various lighting colors according to your preferred settings through the application
2. Screw base



## Package content


- Smart LED color bulb (4)
- Quick start guide

## Installing the Nexxt Home App




Download Nexxt Home app on Google Play Store or Apple App Store.

### Step 1




**Register by email.** Fill in the required fields.

## Step 2




Enter the verification code you received.

## Step 3




Create a new password and then select Completed.

#### Step 4



The Nexxt Solutions Home App account has been successfully set up.


#### Bulb installation



Screw in the Smart Wi-Fi LED color bulb to a E26/E27 socket.


## Add device

### Step 1




Select Add device. If the device is not recognized automatically, select the Smart Bulb icon from the list of devices, and tap Go to add.

### Step 2



Power on the smart bulb. You must connect to a 2.4GHz Wi-Fi network. Enter your network password. Make sure you enter the correct password, otherwise the device will not connect.


### Step 3



Make sure the bulb is blinking. If it fails to blink, reset the bulb. Turn it off from the switch, wait 5 seconds before turning it back on again. Tap on Confirm the light blinks rapidly.


#### Step 4





When Device added successfully is displayed, assign a location and click on Done.

### Step 5



If you want to change the icon and the name of the device, and also assign a different location, you can do it now or later through the Settings interface.

## Functions




- **Power button:** Turns the bulb on and off.
- **White:** Changes the brightness and white color temperature.
- **Color:** Changes the color, brightness, and saturation of the bulb.
- **Scene:** Provides several preselected scenes and four scenes you can configure.



- **Music sync:** Enable this function when you want to put the smart bulb in music mode.
- **Note:** To make this function work, the Nexxt Home app must remain opened as it uses the smartphone's microphone to capture the sound.
- **Schedule:** Allows you to add time and day schedule for the device to turn on or off.



## Timer setup



**Timer:** Allows you to set a countdown for a given amount of time to cause the device to turn on or off.


## Schedule setup

### Step 1




Click on More and select the schedule icon to access to the Add schedule screen.

## Step 2



Set the time you wish to schedule. Select Repeat to set settings. Select Note, Notification to enable or disable this feature. Select Switch to schedule on/off status.  
Click on Save on the upper right-hand corner to save a schedule.

## Power-on memory



**Do Not Disturb:** Enable the do-not-disturb feature and turn off your light before you sleep by using the mobile app. In case of a power outage, your light will go back to its previous off-state after power is restored. To power the light back on, just turn the wall switch on and off twice consecutively within five seconds.

Once power is restored, one of the three power-on states below can be selected by the user:


**Initial mode:** Restores the color and brightness to their default settings.

**Restore memory:** Reverts to the color and brightness settings used last.

**Customized:** The bulb lights up based on the specific color and brightness the user has selected.

## Delete setup






To remove a schedule on iOS, slide item to the left, and for Android, press and hold Schedule, followed by Delete.


## Settings

Click on the pencil icon on the upper right-hand corner.



- **Device name:** changes the icon and the name of the device, and it also allows the user to assign a different location.
- **Note:** click on the pencil icon to access the device name menu.
- **Device information:** displays detailed information related to the bulb.
- **Tap-To-Run and Automation:** links the Wi-Fi bulb with other smart products to automatically control them through a customized command.
- **Third-party control:** enables the voice recognition feature through Alexa and Google Assistant.
- **Offline notification:** provides a selection button to enable/ disable this feature.
- **Share device:** allows sharing the Wi-Fi bulb with family and friends.
- **Create group:** makes management of devices easier by selecting and arranging multiple components under a single group.
- **Feedback:** let us know if you have any issues setting up the product.
- **Add home screen:** adds a shortcut of the device to the main screen on your phone.
- **Check for firmware update:** we will sometimes add new features or provide updates with a new firmware upgrade.
- **Remove device:** allows you to unbind the device from the Nexxt Home Account


## Share device



Click on Share devices then tap Add sharing. Enter the e-mail address of family and friends. Tap on Done. The newly configured users will now have access to your smart bulb.

**Note:** family or friends will need their own Nexxt Solutions Home Account to access the device.

### Delete user



To remove a user, on Android press and hold the name you want to eliminate. On iOS slide to the left the user you want to remove. Click on Delete. A notification confirming you don't want to share the device with this user will be displayed. Click on Confirm.




#### FCC ID: X4YHABUC110 (110V only)

Nexxt Solutions® is a registered trademark. All rights reserved. Amazon, Alexa and all related logos are trademarks of [Amazon.com](https://www.amazon.com), Inc. or its affiliates. Google, Android and Google Play are trademarks of Google LLC. SD™ and microSD™ are trademarks owned by SD-3C, LLC. All other brand names and trademarks are the property of their respective owners. Made in China.

#### WARRANTY



#### Documents / Resources

 <p>Smart Wi-Fi LED color bulb</p>	<p><a href="#">NEXXT NHB-C110 Smart Wi-Fi LED color Bulb</a> [pdf] User Guide NHB-C110 Smart Wi-Fi LED color Bulb, NHB-C110, Smart Wi-Fi LED color Bulb, LED color Bulb, Bulb</p>
---	---

#### References

- [a Amazon.com. Spend less. Smile more.](https://www.amazon.com)
- [a Amazon.com. Spend less. Smile more.](https://www.amazon.com)

