



NGS ELEC-SPK-0748 Roller Nitro 2 Wireless Speaker User Manual

[Home](#) » [NGS](#) » NGS ELEC-SPK-0748 Roller Nitro 2 Wireless Speaker User Manual 

Contents


- 1 NGS ELEC-SPK-0748 Roller Nitro 2 Wireless Speaker
- 2 CONTROL BUTTONS
- 3 BLUETOOTH MODE
- 4 HOW TO CHARGE?
- 5 TWS
- 6 RADIO MODE
- 7 USB/TF MODE
- 8 AUX IN MODE
- 9 TECHNICAL SPECIFICATIONS
- 10 Battery warranty
- 11 Documents / Resources
 - 11.1 References
- 12 Related Posts



NGS ELEC-SPK-0748 Roller Nitro 2 Wireless Speaker



CONTROL BUTTONS



1. **Mode / TWS**

Short press: change mode (FM/BT/USB/AUX IN/TF)

2. **Previous song**

In FM mode: short press to the previous channel

3. **Power button**

Long press turn on/off for about 3 seconds/times

4. **Next song**

In FM mode: short press to the next channel

5. **Play/Pause button**

- Short press: play/pause
- Long press to exit wireless connect
- Long press to search the programm in the FM mode

6. **Volume +**

7. **Volume -**


8. **TF audio input**

9. **AUX audio input**


10. USB audio input

11. Type-C interface charging port





























BLUETOOTH MODE







HOW TO CHARGE?




TWS

1			2	
1	  3s			  3s
2	     0.5s			     0.5s
3	 3s			
4	 "Beep"			 "Beep"
5	   			 
6	 			


1			2	
	 3s			

RADIO MODE




Note: Connect the USB cable for a better radio signal

USB/TF MODE



AUX IN MODE



TECHNICAL SPECIFICATIONS

- Compatible with bluetooth 5.0 Yes
- TWS (get double power connecting 2 speakers at the same time without cables) Yes
- Output peak power 20W (2 x 10W)
- RMS power 10W (2 x 5W)
- AUX audio input Yes
- USB audio input Yes
- TF audio input Yes

- Volume control Yes
- Battery Ion-Li 1200mAh x2
- Battery life 12 hours*
- Water resistant IPX5

- * 3 hours at 100% volume
- 12 hours at 70% volume
- 15 hours at 50% volume

Battery warranty

The battery is a consumer product, and as such it is under warranty for 12 months. If at any time in the future you should need to dispose of this product please note that: Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice. (Waste Electrical and Electronic Equipment Directive)

Documents / Resources



[NGS ELEC-SPK-0748 Roller Nitro 2 Wireless Speaker](#) [pdf] User Manual
ELEC-SPK-0748, Roller Nitro 2, Wireless Speaker, ELEC-SPK-0748 Roller Nitro 2 Wireless Speaker, Speaker, Roller Nitro 2 Wireless Speaker, ELEC-SPK-0748 Wireless Speaker

References

-  [NGS | Altavoces y auriculares compatible Bluetooth, teclados, ratones y más ...](#)
-  [NGS](#)