



niceboy Computer Keyboard ORYX K100 User Manual

[Home](#) » [niceboy](#) » niceboy Computer Keyboard ORYX K100 User Manual 

Contents

- 1 niceboy Computer Keyboard
- 2 User Manual
- 3 PACKAGE CONTENT
- 4 CONNECTION
- 5 MULTIMEDIA SHORTCUTS
- 6 BACKLIGHT SETTINGS
- 7 SPECIFICATIONS
- 8 ADDITIONAL INFORMATION
- 9 Documents / Resources
- 10 Related Posts

niceboy Computer Keyboard

User Manual

Model: ORYX K100

PACKAGE CONTENT

Keyboard Niceboy ORYX K100
Manual

CONNECTION

After unpacking the keyboard connect via the USB connector into your computer. If the keyboard is not recognized, check that your USB drivers are up-to-date.

MULTIMEDIA SHORTCUTS

- FN + F1 = Music player

- FN + F2 = Volume-
- FN + F3 = Volume+
- FN + F4 = Mute
- FN + F5 = Stop
- FN + F6 = Previous song
- FN + F7 = Play/Pause
- FN + F8 = Next song
- FN + F9 = Email
- FN + F10 = WEB
- FN + F11 = Keyboard lock
- FN + F12 = Calculator
- FN+WIN-L = Lock Win & APP

BACKLIGHT SETTINGS

FN + Page Up = Increase brightness

FN + Page Down = Decrease brightness

FN + Bulb icon = Mode change

FN + „=“ = To slow down the breathing rate (breathing mode)

FN + „~“ = To speed up the breathing rate (breathing mode)

SPECIFICATIONS

Dimension: 439 * 203 * 26 mm

Weight: 500±50 g

Key number: 108

Switches: Membrane

Switch life time: over 3 million

Cord length: 1,5m

Supported OS: Windows XP 7/8/10

Connectivity: USB 2.0


Multimedia shortcuts: Yes

ADDITIONAL INFORMATION

This package contains tiny parts that may pose hazard to children. This is why the product should be kept beyond their reach. Avoid using the headphones on places exposed to too low or high temperature (0 °C and more/ 45 °C and more) or humidity (20 % and less/ 90 % and more). Avoid storing the headphones on places exposed to too low or high temperature (-20 °C and more/ 60 °C and more) or humidity (90 % and more). Keep the product away from rain, moisture, or liquids. This product meets all the main requirements imposed on it by the EU Directive.

**Importer to EU: RTB media s.r.o., Pretlucka 16,
Prague 10, 100 00, Czech Republic, ID: 294 16 876.**

Documents / Resources



[niceboy Computer Keyboard ORYX K100](#) [pdf] User Manual
Computer Keyboard ORYX K100