

Niceboy K10 OFFICE Gaming Keyboard User Manual

Home » niceboy » Niceboy K10 OFFICE Gaming Keyboard User Manual





OFFICE K10 User Manual / Gaming Keyboard

Contents

- 1 PACKAGE CONTENTS
- **2 CONNECTION**
- **3 MULTIMEDIA SHORTCUTS**
- **4 SPECIFICATIONS**
- **5 ADDITIONAL INFORMATION**
- 6 USER INFORMATION FOR DISPOSING ELECTRICAL AND ELECTRONIC DEVICES (HOME
- 7 Documents / Resources
 - 7.1 References
- **8 Related Posts**

PACKAGE CONTENTS

Keyboard Niceboy K10 Manual

CONNECTION

After unpacking, insert 2x AAA batteries from the bottom of the keyboard. Then just connect the keyboard to your computer using a 2.4 Ghz USB dongle. If the keyboard is not recognized, check that the USB driver on your computer is up-to-date (check with your PC / notebook manufacturer).

MULTIMEDIA SHORTCUTS

Clippings
Сору
Paste
Explorer
Minimize open windows
Back
Forward
Stop searching
Refresh page
Access settings
Lock
Sleep mode

SPECIFICATIONS

Dimensions:	432 x 143 x 23.89 mm
Power supply:	2x AAA batteries, 1.5V
Number of keys:	121
Switch:	Chocolate
Connection:	2.4 GHz USB Dongle
OS Requirements:	Windows 10
Multimedia keys:	Yes with FN key support

ADDITIONAL INFORMATION

This package contaINSERT tiny parts that may pose hazard to children. This is why the product should be kept beyond their reach. Avoid using the headphones on places exposed to too low or high temperature (0 °C and more/ 45 °C and more) or humidity (20 % and less/ 90 % and more). Avoid storing the headphones on places exposed to too low or high temperature (-20 °C and more/ 60 °C and more) or humidity (90 % and more). Keep the product away from rain, moisture, or liquids. This product meets all the main requirements imposed on it by the EU Directive.

RTB Media s.r.o. hereby declares that the type of radio equipment NICEBOY K10 complies with Directives 2014/53 / EU, 2014/30 / EU, 2014/35 / EU, and 2011/65 / EU. The full content of EU Declaration of Conformity is available on the following websites: https://niceboy.eu/cs/podpora/prohlaseni-o-shode-mm38CtmYvX693IHvvu4CWpk3vJGrvnC

USER INFORMATION FOR DISPOSING ELECTRICAL AND ELECTRONIC DEVICES (HOME USE)



This symbol located on a product or in the product's original documentation means that the used electrical or electronic products may not be disposed together with the communal waste. In order to dispose of these products correctly, take them to a designated collection site, where they will be accepted for free. By disposing of a product in this way, you are helping to protect precious natural resources and helping to prevent any potential negative impacts on the environment and human

health, which could be the result of incorrect waste disposal. You may receive more detailed information from your local authority or nearest collection site. According to national regulations, fines may also be given out to anyone who disposes of this type of waste incorrectly. User information for disposing electrical and electronic devices.

(Business and corporate use)

In order to correctly dispose of electrical and electronic devices for business and corporate use, refer to the product's manufacturer or importer. They will provide you with information regarding all disposal methods and, according to the date stated on the electrical or electronic device on the market, they will tell you who is responsible for financing the disposal of this electrical or electronic device. Information regarding disposal processes in other countries outside the EU. The symbol displayed above is only valid for countries within the European Union.

For the correct disposal of electrical and electronic devices, request the relevant information from your local authorities or the device seller.

Documents / Resources



Niceboy K10 OFFICE Gaming Keyboard [pdf] User Manual K10 OFFICE Gaming Keyboard, OFFICE Gaming Keyboard, Gaming Keyboard

References

- Niceboy IT'S YOUR DAY!
- Niceboy IT'S YOUR DAY!

Manuals+,