

niceboy OFFICE K10 Gaming Keyboard User Manual

Home » niceboy » niceboy OFFICE K10 Gaming Keyboard User Manual

Contents

- 1 niceboy OFFICE K10 Gaming
- **Keyboard**
- **2 CONNECTION**
- **3 MULTIMEDIA SHORTCUTS**
- **4 SPECIFICATIONS**
- **5 ADDITIONAL INFORMATION**
- 6 Documents / Resources
 - 6.1 References
- **7 Related Posts**



niceboy OFFICE K10 Gaming Keyboard



CONNECTION

After unpacking, turn on the keyboard using the slider at the top of the keyboard. The button must be in the ON position to turn on. Then just connect the keyboard to your computer using a 2.4 Ghz USB dongle. If the keyboard is not recognized, check that the USB driver on your computer is up-to-date (check with your PC / notebook manufacturer).

MULTIMEDIA SHORTCUTS

• FN + F1 = Clippings

- FN + F2 = Copy
- FN + F3 = Paste
- FN + F4 = Explorer
- FN + F5 = Minimize open windows
- FN + F6 = Back
- FN + F7 = Forward
- FN + F8 = Stop searching
- FN + F9 = Refresh page
- FN + F10 = Access settings
- FN + F11 = Lock
- FN + F12 = Sleep mode

SPECIFICATIONS

Dimensions: 432 x 143 x 23.89 mm
Power supply: 2x AAA batteries, 1.5V

Number of keys: 121Switch: Chocolate

Connection: 2.4 GHz USB DongleOS Requirements: Windows 10

• Multimedia keys: Yes with FN key support

ADDITIONAL INFORMATION

This package contalNSERT tiny parts that may pose hazard to children. This is why the product should be kept beyond their reach. Avoid using the headphones on places exposed to too low or high temperature (0 °C and more/ 45 °C and more) or humidity (20 % and less/ 90 % and more). Avoid storing the headphones on places exposed to too low or high temperature

(-20 °C and more/ 60 °C and more) or humidity (90 % and more). Keep the product away from rain, moisture, or liquids. This product meets all the main requirements imposed on it by the EU Directive.

RTB Media s.r.o. hereby declares that the type of radio equipment NICEBOY K10 complies with Directives 2014/53 / EU, 2014/30 / EU, 2014/35 / EU, and 2011/65 / EU. The full content of EU Declaration of Conformity is available on the following websites: https://niceboy.eu/cs/podpora/prohlaseni-o-shode-mm38CtmYvX693IHvvu4CWpk3vJGrvnC

USER INFORMATION FOR DISPOSING ELECTRICAL AND ELECTRONIC DEVICES (HOME USE)

This symbol located on a product or in the product's original documentation me-ans that the used electrical or electronic products may not be disposed together with the communal waste. In order to dispose of these products correctly, take them to a designated collection site, where they will be accepted for free. By dispo-sing of a product in this way, you are helping to protect precious natural resources and helping to prevent any potential negative impacts on the environment and human health, which could be the result of incorrect waste disposal. You may receive more detailed information from your local authority or nearest collection site. According to national regulations, fines may also be given out to anyone who disposes of this type of waste incorrectly. User information for disposing electrical and electronic devices.

(Business and corporate use)

In order to correctly dispose of electrical and electronic devices for business and corporate use, refer to the product's manufacturer or importer. They will provide you with information regarding all disposal methods and, according to the date stated on the electrical or electronic device on the market, they will tell you who is responsible for financing the disposal of this electrical or electronic device. Information regarding disposal

processes in other countries out-side the EU. The symbol displayed above is only valid for countries within the European Union. For the correct disposal of electrical and electronic devices, request the relevant information from your local authorities or the device seller.

Documents / Resources



References

- Niceboy IT'S YOUR DAY!

Manuals+,