



## niceboy RAZE MINI Bluetooth Speaker User Manual

[Home](#) » [niceboy](#) » niceboy RAZE MINI Bluetooth Speaker User Manual 

# niceboy®

**RAZE MINI**  
User Manual / Bluetooth Speaker


### PACKAGE CONTENTS

Bluetooth speaker Niceboy RAZE mini Operating Instructions MicroUSB cable

#### Contents

- [1 PRODUCT DESCRIPTION](#)
- [2 BASIC OPERATION](#)
- [3 BLUETOOTH CONNECTION MODE](#)
- [4 FM RADIO MODE](#)
- [5 BASIC OPERATION](#)
- [6 BLUETOOTH CONNECTION MODE](#)
- [7 FM RADIO MODE](#)
- [8 PLAYBACK MODE VIA USB AND MICROSD CARD](#)
- [9 TELEPHONE CALLS](#)
- [10 PARAMETERS](#)
- [11 Documents / Resources](#)
- [12 Related Posts](#)

### PRODUCT DESCRIPTION



1. Selection of modes
2. Previous track/volume down
3. Next track/volume up
4. Playback/pause/tuning/answering & termination of a call
5. LED/microphone
6. MicroSD card slot
7. USB port
8. On/Off button
9. Charging microUSB port

## BASIC OPERATION

You will turn on/off the speaker with button 8. Use button 1 to change over between individual modes (indication by beeping). Long press the buttons 2 and 3 to adjust volume (in all modes); by pressing them shortly you will scroll through the individual tracks (in Bluetooth, USB, and MicroSD modes) or broadcasting stations (in FM radio mode). By shortly pressing button 4 you will pause or resume playback (in Bluetooth, USB, and MicroSD modes).

## BLUETOOTH CONNECTION MODE

1. Blue LED (5) flashes and the speaker indicates pairing by beeping in the pairing mode.
2. Activate Bluetooth on your device and select "RAZE mini" from the list of available devices.
3. A beep is heard and the LED lights blue after successful pairing.
4. You can also control volume and change over the tracks from your mobile phone or with buttons on the speaker.

## FM RADIO MODE

1. Insert the supplied USB cable into the charging USB port (9) (the cable acts as an antenna) and change over to the FM Radio mode.
2. Press the tune button (4) to start automatic searching for broadcasting stations (blue LED is flashing quickly).
3. Once the stations are tuned up (blue LED flashing slowly) you can change over between them (pressing shortly buttons 2 and 3).

## BASIC OPERATION

You will turn on/off the speaker with button 8. Use button 1 to change over between individual modes (indication

by beeping). Long press the buttons 2 and 3 to adjust volume (in all modes); by pressing them shortly you will scroll through the individual tracks (in Bluetooth, USB, and MicroSD modes) or broadcasting stations (in FM radio mode). By shortly pressing button 4 you will pause or resume playback (in Bluetooth, USB, and MicroSD modes).

## BLUETOOTH CONNECTION MODE

1. Blue LED (5) flashes and the speaker indicates pairing by beeping in the pairing mode.
2. Activate Bluetooth on your device and select "RAZE mini" from the list of available devices.
3. A beep is heard and the LED lights blue after successful pairing.
4. You can also control volume and change over the tracks from your mobile phone or with buttons on the speaker.

## FM RADIO MODE

1. Insert the supplied USB cable into the charging USB port (9) (the cable acts as antenna) and change over to the FM Radio mode.
2. Press the tune button (4) to start automatic searching for broadcasting stations (blue LED is flashing quickly).
3. Once the stations are tuned up (blue LED flashing slowly) you can change over between them (pressing shortly buttons 2 and 3).

## PLAYBACK MODE VIA USB AND MICROSD CARD

Insertion of the memory card (6) or of USB flash disk (7) will result in the automatic activation of the respective mode on the speaker, which will start playing music. You may also activate the desirable model with the mode selection button (1).

## TELEPHONE CALLS

Answer an incoming call with button 4 and terminate it with the same button. Double press quickly the button 4 to dial the last called number. **CHARGING** The speaker will remind you of low state of its battery by beeping. To charge the speaker battery, connect the supplied USB cable to the charging port (9) on one end and to any charging adapter (5V) or to USB on your PC on the other. Charging in progress is indicated by the red LED, which turns off after the battery is fully charged (2-3 hours).

Our recommendation is to fully charge the speaker before you use it for the first time. This will maximize the battery life.

## PARAMETERS


Bluetooth:	4.2
Transmission distance:	up to 10 m
Power rating:	5W
Sensitivity:	≥ 95 dB
Frequency:	280 Hz – 16 kHz
Dimensions and weight:	92 x 92 x 46 mm, 190 g



Importer to EU: RTB media s.r.o., Pretlucka 16,  
Prague 10, 100 00, Czech Republic, ID: 294 16 876  
Made in China.



## Documents / Resources

	<a href="#">niceboy RAZE MINI Bluetooth Speaker</a> [pdf] User Manual RAZE MINI, Bluetooth Speaker
---	---