



nickelodeon TT-ACLED-494 LED Light Alarm Clock User Manual

[Home](#) » [nickelodeon](#) » nickelodeon TT-ACLED-494 LED Light Alarm Clock User Manual 

Contents

- [1 nickelodeon TT-ACLED-494 LED Light Alarm Clock](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 WHAT'S IN THE BOX](#)
- [5 SPECIFICATIONS](#)
- [6 PRODUCT DIAGRAM](#)
- [7 BOTTOM VIEW](#)
- [8 CONTROLS](#)
- [9 OPERATING INSTRUCTIONS](#)
- [10 TROUBLESHOOTING](#)
- [11 Documents / Resources](#)



nickelodeon TT-ACLED-494 LED Light Alarm Clock



Product Information

The LED Alarm Clock (model TT-ACLED-494) is a compact and versatile alarm clock with various features. It displays the time, month/date, day, and temperature. The clock operates on 3 x AAA batteries and has a standby time. It also features an LED light, an alarm function with snooze capability, and a speaker for audio output.

Product Usage Instructions

Setting Time & Date:

1. Insert 3 x AAA batteries into the battery compartment.
2. Ensure the clock is powered on and in normal display mode.
3. Press the "Set" button to activate the time and date setting mode.
4. Adjust the values by pressing the "Up" or "Down" button.
5. Press "Set" to move to the next field.
6. The field sequence for setting time and date is as follows: Hour > Minutes > Year > Month > Date > Exit.

Setting the Alarm:

1. Ensure the clock is powered on and in normal display mode.
2. Make sure you have set the correct time before setting the alarm.
3. Press the "Alarm" button to switch to alarm mode.
4. Press "Set" to activate the alarm setting mode.
5. Adjust the values by pressing the "Up" or "Down" button.

6. Press “Set” to move to the next field.
7. The field sequence for setting the alarm is as follows: Hour > Minutes > Snooze Duration > Music Type > Exit.

Activating the Alarm and Snooze:

To activate the alarm, press the “Up” or “Down” button until you see a small Bell icon on the screen. To activate snooze, press the “Up” or “Down” button until you see a small Zz icon on the screen.

The alarm will ring for 1 minute once the set time has been reached. The snooze alarm will ring after the first alarm once the snooze duration is reached. Press any button (except LED) during the alarm to turn off the alarm sound.

Note: If you have set a snooze alarm (indicated by the Zz icon onscreen), the alarm will sound at intervals of the snooze duration until the Zz icon is removed. To remove the Zz icon, press the “Up” or “Down” button when in Alarm view.

Troubleshooting:

No Power: Check the batteries and replace them if necessary.

The Alarm keeps sounding: If you have set a snooze alarm, the alarm will activate at intervals based on the snooze duration. To remove the Zz icon and stop the repeated alarms, press the “Up” or “Down” button when in Alarm view.

Thank you for choosing our LED Alarm Clock. For more information, spare parts, FAQs, warranty claims, and more, please scan the QR code or visit our website at www.youtube.com/lasercoau.


WHAT’S IN THE BOX

- Alarm Clock
 - User Manual


SPECIFICATIONS

- **Temperature Range:** 0°C – 50°C or 32°F – 122°F
- **Time Format:** 12 & 24HR
- **Screen Size:** 52 x 52mm
- **Battery:** 3 x AAA (not included)
- **Standby Time:** 90 – 150 days
- **Dimensions:** 78 x 78 x 78mm
- **Weight:** 88g


PRODUCT DIAGRAM



BOTTOM VIEW



CONTROLS



1. Light

- Press to turn LED light on.
- Tapping the top of the clock can also turn on the LED light.
- The light will illuminate for a few seconds before turning off.

2. Up

- Press to increase value.
- In Time view tap to switch between 12 & 24HR time. In Alarm view press to turn alarm and snooze on.

When the alarm is sounding, press to snooze (if snooze is activated).

3. **Down**

- Press to decrease value.
- In Time view tap to switch between Celsius and Fahrenheit temperature.
- In Alarm view tap to turn alarm and snooze on.

4. **Set**

- In Time view tap to set time.
- In Alarm view tap to set alarm.
- Press to move between fields when setting time or alarm.

5. **Alarm**

- Press to view the alarm time

OPERATING INSTRUCTIONS

Setting Time & Date

- Insert 3 x AAA batteries.
- Ensure the unit is powered on and in normal display mode.
- Press “Set” to activate setting of time and date. Adjust the values by pressing the “Up” or “Down” button.
- Press “Set” to move to the next field.
- The field sequence is as follows:
- Hour > Minutes > Year > Month > Date > Exit.

Setting the Alarm

- Ensure the unit is powered on and in normal display mode.
- Make sure you have set the correct time.
- Press the “Alarm” button to switch to alarm mode. Press “Set” to activate setting of the alarm.
- Adjust the values by pressing the “Up” or “Down” button.
- Press “Set” to move to the next field.
- The field sequence is as follows:
- Hour > Minutes > Snooze Duration > Music Type > Exit
- To activate the alarm, press the “UP” or “DOWN” button till you see a small “Bell” icon onscreen.
- To activate snooze, press the “UP” or “DOWN” button till you see a small “Zz” icon onscreen.
- Alarm will ring for 1 minute once the set time has been reached.
- The snooze alarm will ring after the first alarm once the snooze duration is reached.
- Press any button (except LED) during the alarm ring to turn the alarm sound off.

Note:

- The snooze duration is between 1 – 60 minutes. Careful when setting the Snooze value to 60 minutes as this will not sound the snooze alarm again for 1 hour.
- The snooze alarm will keep sounding after the elapsed time unless the “Zz” icon has been removed from the screen.

TROUBLESHOOTING

No Power:

- Check batteries and replace as required.

The Alarm keeps sounding:

- If you have a snooze alarm set as indicated by the “Zz” icon onscreen, then the alarm will activate every interval the snooze duration has been set e.g., if your snooze duration is set as 15, then the alarm will sound every
- 15 minutes after the initial alarm until the “Zz” icon has been removed from the screen.
- To remove the “Zz” icon press the a “Up” or “Down” button when in Alarm view.

Thank you for your purchase!

- Laser Corporation is 100% Australian owned & operated. To get the most out of your product please read the user manual carefully and keep for future use.
- For specific information relating to your product such as Spare Parts, FAQs, Warranty claims, and more, please scan the following QR code:



Visit our website




Check us out at www.youtube.com/lasercoau



© 2023 Paramount Pictures. All Rights Reserved. Teenage Mutant Ninja Turtles and all related titles, logos and characters are trademarks of Viacom Overseas Holdings C.V.

Documents / Resources

	<p>nickelodeon TT-ACLED-494 LED Light Alarm Clock [pdf] User Manual</p> <p>TT-ACLED-494 LED Light Alarm Clock, TT-ACLED-494, LED Light Alarm Clock, Light Alarm Clock, Alarm Clock, Clock</p>
---	---