

NICOR DLE4-ROUGHIN-FRAME Rough In Frame for Remote Driver Canless LED Downlights



# NICOR DLE4-ROUGHIN-FRAME Rough In Frame for Remote Driver Canless LED Downlights Instruction Manual

[Home](#) » [NICOR](#) » NICOR DLE4-ROUGHIN-FRAME Rough In Frame for Remote Driver Canless LED Downlights Instruction Manual 

## Contents

- [1 NICOR DLE4-ROUGHIN-FRAME Rough In Frame for Remote Driver Canless LED Downlights](#)
- [2 Product Usage Instructions](#)
- [3 Product Description](#)
- [4 Dimensions](#)
- [5 Documents / Resources](#)
  - [5.1 References](#)



**NICOR DLE4-ROUGHIN-FRAME Rough In Frame for Remote Driver Canless LED Downlights**



## Specifications

- **Product Name:** ROUGHIN-FRAME
- **Usage:** Rough-In Frame for Remote-Driver (Canless) LED Downlights
- **Construction:** Hanger Bars
- **Dimensions:**
  - **DLE4-ROUGHIN-FRAME**
    - Length (L): 7.78" (197mm)
    - Width (W): 5.29" (134mm)
    - Diameter (D): 4.25" (107mm)
  - **DLE6-ROUGHIN-FRAME**
    - Length (L): 9.25" (235mm)
    - Width (W): 7" (178mm)
    - Diameter (D): 6.25" (159mm)
- **Compatibility:**
  - DLE4-ROUGHIN-FRAME compatible with: DGD4, DGC4, DGF4, DLE4, REL4, RELS4, RELR4
  - DLE6-ROUGHIN-FRAME compatible with: CLR6, DLE6, REL6, RELS6, RELR6, REL6-UNV

## Product Usage Instructions

### Installation Guidelines:

1. Identify the suitable location in the ceiling for the downlight.
2. Place the ROUGHIN-FRAME in the chosen location, aligning it properly.
3. Use the ROUGHIN-FRAME as a cutting guide/template for precise installation.
4. Ensure proper wiring connections according to the downlight specifications.
5. Secure the ROUGHIN-FRAME in place before installing the downlight.

**Maintenance:**

Regularly inspect the ROUGHIN-FRAME for any signs of damage or wear. Clean gently with a dry cloth if needed.

**Removal:**

To remove the ROUGHIN-FRAME, carefully detach it from the ceiling and handle it with care to avoid any damage.

**FAQ**

- **Q: Can the ROUGHIN-FRAME be used with any type of downlights?**

A: The ROUGHIN-FRAME is specifically designed for use with Remote-Driver (Canless) LED Downlights. Make sure to check compatibility before use.

- **Q: How do I know if the ROUGHIN-FRAME is aligned correctly in the ceiling?**

A: Ensure that the dimensions and placement of the ROUGHIN-FRAME match the requirements provided in the installation manual of your downlight.

**ROUGHIN-FRAME**

Rough-In Frame for Remote-Driver (Canless) LED Downlights

Project
Catalog
Type
Date

**Product Description**

The ROUGHIN-FRAME is designed to aid in installation of the remote-driver (canless) downlights by providing a clear location indicator for wiring and installation placement acting as a cutting guide/template within a finished ceiling. It is suitable for use in residential and commercial applications.


**Construction**

Galvanized steel frame

**Hanger Bars**


- Heavy-gauge NICOR captive hanger bars provide greater stability, allowing housing to be positioned at any point within a 24" joist span, then locked in place with set screws
- Unique hanger bar lip design helps align frame to joist
- Four double-headed captive nails provide for ease of installation

- Bars can be repositioned 90° on plaster frame by repositioning hanger bar brackets
- Bars fit onto T-bar spine for quick alignment and can be permanently secured
- Score lines allow bars to be shortened without tools to accommodate a 12" joist span
- Shallow design allows use in 2" x 6" joist construction



## Dimensions

Dimensions			
	Length (L)	Width (W)	Diameter (D)
<b>DLE4-ROUGHIN-FRAME</b>	7.78" (197mm)	5.29" (134mm)	4.25" (107mm)
<b>DLE6-ROUGHIN-FRAME</b>	9.25" (235mm)	7" (178mm)	6.25" (159mm)



Compatibility	
DLE4-ROUGHIN-FRAME	DGD4, DGC4, DGF4, DLE4, REL4, RELS4, RELR4
DLE6-ROUGHIN-FRAME	CLR6, DLE6, REL6, RELS6, RELR6, REL6-UNV

Ordering Information	Example: DLE6-ROUGHIN-FRAME
Series	Description
DLE4-ROUGHIN-FRAME	Rough-in Frame for use with 4" Remote-Driver (Canless) LED Downlights
DLE6-ROUGHIN-FRAME	Rough-in Frame for use with 6" Remote-Driver (Canless) LED Downlights

Specifications and dimensions subject to change without notice.  
NICOR, Inc. 2200 Midtown Place NE, Albuquerque, NM 87107 P: 800.821.6283 F: 800.892.8393  
[www.nicorlighting.com](http://www.nicorlighting.com) July 28, 2023 12:52 PM DLE6-ROUGHIN-FRAME



[NICOR DLE4-ROUGHIN-FRAME Rough In Frame for Remote Driver Canless LED Downlights \[pdf\] Instruction Manual](#)  
DLE4-ROUGHIN-FRAME, DLE6-ROUGHIN-FRAME, DLE4-ROUGHIN-FRAME Rough In Frame for Remote Driver Canless LED Downlights, Rough In Frame for Remote Driver Canless LED Downlights, In Frame for Remote Driver Canless LED Downlights, Remote Driver Canless LED Downlights, Driver Canless LED Downlights, Canless LED Downlights, LED Downlights, Downlights

References

- [User Manual](#)

[Manuals+](#). [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.