



Nikon MC-CF660G High-speed CFexpress Type-B memory card User Manual

[Home](#) » [Nikon](#) » Nikon MC-CF660G High-speed CFexpress Type-B memory card User Manual 

Contents

- [1 Nikon MC-CF660G High-speed CFexpress Type-B memory card](#)
- [2 ONE YEAR LIMITED WARRANTY](#)
- [3 Documents / Resources](#)
- [4 Related Posts](#)

Nikon

Nikon MC-CF660G High-speed CFexpress Type-B memory card



Before operating this media, please read this manual thoroughly, and retain it for future reference.

WARNING: To reduce fire or shock hazard, do not expose the unit to rain or moisture.

For the Customers in the U.S.A.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference,
2. This device must accept any interference received, including interference that may cause undesired operation.

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio/TV technician for help.

CAUTION

The FCC requires the user to be notified that any changes or modifications made to this device that are not expressly approved by Nikon Corporation may void the user's authority to operate the equipment.

Notice: for Customers in Canada CAN ICES-3 B / NMB-3 B

Notices for Customers in Europe: This symbol indicates that electrical and electronic equipment is to be collected separately. The following apply only to users in European countries:

- This product is designated for separate collection at an appropriate collection point. Do not dispose of as household waste.
- Separate collection and recycling helps conserve natural resources and prevent negative consequences for human health and the environment that might result from incorrect disposal.
- For more information, contact the retailer or the local authorities in charge of waste management

This product has been manufactured by or on behalf of Nikon Corporation. Shinagawa Intercity Tower C, 2-1 5-3, Konan, Minato-ku, Tokyo 108-6290 Japan EU Importer: Nikon Europe B.V.

Inquiries to the EU Importer or related to product compliance in Europe should be sent to Nikon Europe B.V., Tripolis 100, Burgerweeshuispad 101, 1076 ER Amsterdam, The Netherlands.

WARNING:

- TO AVOID CHOKING HAZARD, KEEP OUT OF REACH OF CHILDREN.
- DO NOT INSERT THIS MEDIA INTO ANY MEMORY CARD SLOT FOR WHICH IT WAS NOT INTENDED.
- This media can be used with CFexpress Memory Card compatible products.
- To use this media with a personal computer, a card reader is required (sold separately).
- Proper operation with all other products is not guaranteed.

For the details on operations with compatible products, please refer to the product instruction manual.

- Copyright law prohibits unauthorized use of recordings.
- Recorded data is not erased completely by formatting or deleting of the product. When assignment transferring or disposing, break off the data in this media by your responsibility with using specially data erasing software or breaking this media physically.
- Do not touch the terminal with your hand or any metal object.
- Do not strike, bend, drop or wet this media.
- Do not attempt to disassemble or convert this media.
- Do not put a label to this media.
- Do not use or store this media in the following locations:
 - Where the range of operating/storage conditions is exceeded.
(Inside a closed car in summer or in strong sunshine/in direct sunlight/ near a heater, etc.)
 - Humid or corrosive locations.
 - Locations that have a lot of oily smoke, steam, humidity, or dirt.
- We recommend that you make a backup copy of important data.
Please do not use or store this media in any environment exceeding the range of specified operating environment described below.
Abuse or misuse will invalidate product warranty.
- This media is formatted prior to shipping. To reformat this media, use an CFexpress Memory Card compatible products. For details, refer to the product instruction manual or support center.
- Recorded data may be damaged or lost in the following situations.
 - If you remove this media or turn off the power while formatting, reading or writing data.
 - If you use this media in locations subject to static electricity or electrical noise.
- When this media is not recognized with your product, turn the power off and on again or restart the product after removing this media.

Nikon shall not be responsible for any damage to or loss of recorded data.

Design and specifications are subject to change without notice.

The CFexpress logo is a trademark licensed by the Compact Flash Association. and • are not mentioned in each case in this manual.

ONE YEAR LIMITED WARRANTY

For Canada, U.S.A, Mexico and Caribbean

THIS IS YOUR NIKON INC. (VALID IN THE CONTINENTAL UNITED STATES AND HAWAII, PUERTO RICO, U.S. VIRGIN ISLANDS, ARUBA, CURACAO, ST.

MAARTEN, ST. THOMAS, JAMAICA, THE CAYMAN ISLANDS (INCLUDING GRAND CAYMAN, CAYMAN BRAC, AND LITTLE CAYMAN), BONAIRE, BARBADOS, BERMUDA, TRINIDAD & TOBAGO), NIKON CANADA INC.

(VALID IN ALL CANADIAN PROVINCES AND TERRITORIES) OR NIKON MEXICO, I.A. DE C.V. (VALID IN ALL MEXICAN STATES) (EACH INDIVIDUALLY, AS THE CASE MAY BE "NIKON") ONE YEAR LIMITED WARRANTY FOR NEW NIKON CAMERAS, LENSES, SPEEDLIGHTS, MEMORY CARDS AND ANY NIKON HARDWARE ITEMS INCLUDED IN THE ACTUAL PRODUCT BOX WITH ANY OF THE FOREGOING (EACH, A "PRODUCT"). YOU MUST PRESENT THIS WARRANTY FORM TOGETHER WITH YOUR PURCHASE RECEIPT THAT DISPLAYS THE PURCHASE DATE TO OBTAIN WARRANTY SERVICE.

This Product is warranted by Nikon to be free from defects in material and workmanship for one (1) year from the date of purchase by the original consumer purchaser. During this one year period, if this Product is found to be defective in material or workmanship, Nikon will at its option, either repair or replace this Product with a product of comparable specifications and value, each without charge, or refund the purchase price shown on your purchase receipt. Except to the extent restricted or prohibited by law, this warranty is subject to the following conditions, limitations and exclusions:

1. This warranty extends to the original consumer purchaser only and is not assignable or transferable, unless otherwise required by law.
2. This warranty shall not apply to any Product which has been subjected to misuse, abuse, abnormal use, negligence, alteration, accident, power surge if the Product contains electronic components, or has had its serial number altered or removed.
3. This warranty does not apply to any defects or damage directly or indirectly caused by or resulting from the use of unauthorized replacement parts and/or service performed by unauthorized personnel.
4. This warranty does not apply to any batteries.
5. This warranty is valid only with authentic Products, sold new by Nikon and purchased from Nikon or its authorized dealers/resellers in the country of purchase.
6. This warranty does not apply to non-Nikon products provided by Nikon, which are instead covered under the warranty, if any, issued by their respective manufacturers

SUBJECT TO APPLICABLE LAW TO THE CONTRARY, THIS WARRANTY IS MADE EXPRESSLY IN LIEU OF ALL OTHER REPRESENTATIONS, WARRANTIES AND CONDITIONS, EXPRESS, IMPLIED, STATUTORY OR COLLATERAL INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OR CONDITION OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT, QUALITY OR DURABILITY, AND ALL OTHER OBLIGATIONS ON THE PART OF NIKON PROVIDED, HOWEVER, THAT IF THE DISCLAIMER OF IMPLIED WARRANTIES AND CONDITIONS IS INEFFECTIVE UNDER APPLICABLE LAW, THE DURATION OF ANY IMPLIED WARRANTIES ARISING BY OPERATION OF LAW SHALL BE LIMITED TO ONE YEAR FROM THE DATE OF PURCHASE OR SUCH LONGER PERIOD AS MAY BE REQUIRED BY APPLICABLE LAW. SUBJECT TO APPLICABLE LAW TO THE CONTRARY, NIKON HEREBY DISCLAIMS ANY AND ALL LIABILITY FOR CONSEQUENTIAL INCIDENTAL, SPECIAL, INDIRECT, EXEMPLARY OR PUNITIVE DAMAGES ARISING OUT OF OR IN CONNECTION WITH ANY BREACH OF THIS WARRANTY OR ANY OTHER CLAIM WITH RESPECT TO THIS PRODUCT, INCLUDING BUT NOT LIMITED TO, CLAIMS OF NEGLIGENCE, STRICT LIABILITY IN TORT OR BREACH OF CONTRACT. SOME STATES/PROVINCES/TERRITORIES DO NOT ALLOW (A) LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS OR (B) THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU. THIS WARRANTY APPLIES TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, AND UNLESS RESTRICTED OR PROHIBITED BY LAW. WHERE ANY TERM OF THIS WARRANTY IS RESTRICTED OR PROHIBITED BY APPLICABLE LAW, SUCH TERM SHALL BE NULL AND VOID, BUT THE REMAINDER OF THIS WARRANTY SHALL REMAIN IN EFFECT. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS AND YOU MAY HAVE OTHER RIGHTS WHICH VARY FROM STATE/ PROVINCE/TERRITORY TO STATE/PROVINCE/TERRITORY. UNLESS RESTRICTED OR PROHIBITED BY APPLICABLE LAW, THIS WARRANTY IS VALID ONLY IN THE COUNTRY WHERE THE ORIGINAL CONSUMER PURCHASER PURCHASED THE PRODUCT FROM NIKON OR ITS AUTHORIZED DEALERS/RESELLERS IN THAT COUNTRY.

To obtain performance of the warranty obligations in the country of purchase, the original consumer purchaser

must return this Nikon Product together with this warranty form and invoice or purchase receipt displaying the purchase date to the appropriate Nikon service facility. A Nikon authorized dealer stamp may also be accepted as proof of purchase for Mexico. The current address of Nikon's service facility within the United States can be obtained by visiting www.nikonusa.com/woort or by calling 1-600-645-6687; within Canada:

www.nikon.com/support or by calling 1-877-534-9910; within

Mexico: www.nikon.com.mx/woorte or by calling 001-800-645-7777. Unless restricted or prohibited by applicable law, in returning this Nikon Product for repair or replacement or refund under this warranty, the original consumer purchaser must prepay all postage, shipping transportation, insurance and delivery costs, and the Nikon Product must be delivered in either its original carton or a similar package affording an equal degree of protection. Nikon will not be responsible for any loss or damage incurred in connection with the return of this Nikon Product.

IF APPLICABLE, BE SURE TO REMOVE FROM AND STORE TO A SEPARATE DATA STORAGE DEVICE ALL DATA AND IMAGES STORED IN YOUR PRODUCT PRIOR TO SENDING THIS PRODUCT TO NIKON. THERE IS A STRONG RISK THAT SUCH IMAGES AND DATA WILL BE DELETED OR REFORMATTED DURING SERVICE. NIKON IS NOT LIABLE FOR ANY LOSS, DAMAGE, CORRUPTION OR DESTRUCTION OF ANY IMAGES OR DATA ON YOUR PRODUCT.

- Nikon Canada Inc. has its principal business address at 1366 Aerowood Drive, Mississauga, ON L4W 1G1, Canada.
- Nikon Inc. has its principal business address at 300 Walt Whitman Road, Melville, NY 11747, United States of America. Nikon Mexico, S.A de C. V. has its principal business address at Av. Paseo de la Reforma No. 250, Torre Niza, Piso 12, Colonia Juarez, Alkalá Cuauhtémoc, C. P. 06600, Ciudad de Mexico. Notice for residents of the country of Mexico Nikon product accessories and other equipment can be found on Nikon Mexico, S.A de C.V. website at www.nikon.com.mx and its authorized dealers.

THIS WARRANTY FORM MAY NOT BE REPRODUCED OR COPIED AND WILL BE VALID ONLY WITH AUTHENTIC NIKON PRODUCTS

For Europe

Dear Nikon Customer,

We thank you for your purchasing this Nikon product. Should your Nikon product require warranty service, please contact the dealer from whom it was purchased or a member of our authorized service network within the sales territory of Nikon Europe B.V. (e.g. Europe / Russia / others). Set details under: <https://www.euro-nikon.com/support>

In order to avoid any unnecessary inconvenience, we advise you to read the user manuals carefully before contacting the dealer or our authorized service network.

Your Nikon equipment is guaranteed against any manufacturing defects for one full year from the date of original purchase. If during this period of guarantee the product proves defective due to improper material or workmanship, our authorized service network within the sales territory of Nikon Europe B.V. will, without charge for labor and parts, repair the product in the terms and conditions set as below. Nikon reserves the right (at its sole discretion) to replace or repair the product

1. This warranty is only provided upon presentation of the completed warranty card and original invoice or purchase receipt indicating the date of purchase, product type and dealer's name, together with the product. Nikon reserves the right to refuse free-of-charge warranty service if the above documents cannot be presented or if the information contained in it is incomplete or illegible.
2. This warranty will not cover:
 - necessary maintenance and repair or replacement of parts due to normal wear and tear.
 - modifications to upgrade the product from its normal purpose as described in user manuals, without the prior written consent of Nikon.

- transport costs and all risks of transport relating directly or indirectly to the warranty of the products.
3. The warranty will not be applicable in the case of:
- • damage caused by misuse including DUI oot limited to failure to use the product fuf its normal purpose or according to the user instructions on the proper use and maintenance. and to Installation or use of the product inconsistent with the safety standards in force In the country where it is used
 - • damage caused by accddents Including but not limited to lightning, water, fire, misuse or neglect.
 - • alteration, defacing, illegibility or removal of the model or serial number on the product.
 - • damage resulting from repairs or adjustments which have been conducted by unauthorized service orgamzations or persons. , defects In any system into which the product is incorporated or with which it is used.
4. This service warranty does not affect the consumer's stat1.1tory rights under applicable national laws in force, nor the consumer's right against the dealer arising from their sales/purchase contract.

NOTICE: An overview of all authorized Nikon Service Stallons can be found on line by following this Link <https://www.europe-nikon.com/service>

for Asia/ for Australia and New Zealand/ for India

1. Your Nikon product is guaranteed against any manufacturing defects for one full year from the date of purchase. ThtS warranty card is valid only in the country where you purchased this product.
2. To validate this warranty card, you are requested to fill in the date of purchase on the front This warranty card together with the original purchase receipt must be presented to the Nikon authorized service facihty before any repair can be made under warranty.
3. All costs, induding mail, transportation, insurance and other incidental charges in relation to repair work, are at your expense. All other claims of any nature are not covered.
4. THIS WARRANTY DOES NOT APPLY TO ANY OF THE FOLLOWINGS: , DEFECTS ON MALFUNCTIONS CAUSED BY OAMAGE RESULTING FROM IMPROPER CARE, MISUSE OR ABUSE OF THIS PRODUCT, OR OPERATION OF THIS PRODUCT COITRARY TO THE INSTRUCTIONS CONTAINED IN THE OWNER'S MANUAL.
 - DAMAGE OR DEFECT CAUSED BY ACCIDENT, BATTERY LEAKAGE, SANO, DIRT, OUST OR LIQUIO DAMAGE. , OAMAGE CAUSED DURING TRANSPORTATION OR MAIL
 - DAMAGE CAUSED BY ANY MODIFICATION OR SERVICING PERFORMED BY PERSON(S) OTHER THAN NIKON AUTHORIZED SERVICE FACILITY.
 - SUPPLIED ACCESSORIES SUCH A5 BATTERIES, CAI STRAP, LENS CAP, OR OTHER CONSUMABLES. , ANY ELECTRONIC DATA LOSS DUE TO MALFUNCTIONING OR REPAIR OFTHIS PRODUCT.
 - ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES R&SULTING FROM IJ/I BREACH OFWARRAITY, EXPIIISS Oil IMPLIED, APPLICABLE TO THIS PRODUCT. , THE SEruAL NUMBER HAS BEEN ALTERED OR REMOVED.
5. ThtS warranty card is issued only at the time of original purchase. It is nontransferable and will not be re-

issued.

Nikon User Support

Contact a Nikon representative for technical assistance with the operation of your Nikon product or products. For information on the Nikon representatives in your area, visit <http://www.nikon-asia.com/support>.

Supplier's Declaration of Conformity

Trade Name : Nikon


Model : MC-CF660G

Responsible Party : Nikon Inc.

Address : 1300 Walt Whitman Road, Melville, New York 11747-3064, U.S.A.

Telephone Number: 631-547-4200

Documents / Resources

	<p>Nikon MC-CF660G High-speed CFexpress Type-B memory card [pdf] User Manual MC-CF660G High-speed CFexpress Type-B memory card, MC-CF660G, High-speed CFexpress Type-B memory card, CFexpress Type-B memory card, memory card</p>
---	---