



# NINJA BN800UK 3 in 1 Food Processor and Blender User Guide

[Home](#) » [Ninja](#) » NINJA BN800UK 3 in 1 Food Processor and Blender User Guide 

## Contents

- [1 NINJA BN800UK 3 in 1 Food Processor and Blender](#)
- [2 Specifications](#)
- [3 Product Usage Instructions](#)
- [4 FAQ](#)
- [5 Documents / Resources](#)
  - [5.1 References](#)
- [6 Related Posts](#)

# NINJA®

## NINJA BN800UK 3 in 1 Food Processor and Blender



## Specifications

- **Model:** [Product Model]
- **Capacity:** 2.1L Total Crushing Jug, 700ml Single-Serve Cup
- **Dishwasher Safe Parts:**
  - 2.1L Total Crushing Jug and Lid
  - 700ml Single-Serve Cup and Spout Lid
  - Food Processor Bowl
  - Stacked Blade Assembly
  - Pro Extractor Blades Assembly
  - Feed Chute Lid and Pusher
  - Reversible Slicing/Grating Disc
  - Disc Adapter
  - Dough Blade Assembly
  - Chopping Blade Assembly

## Product Usage Instructions

### Cleaning the Unit

To clean your blender unit, follow these steps:

1. Unplug the unit and disassemble all removable parts.
2. Wash the removable parts with warm soapy water and rinse thoroughly.
3. For dishwasher-safe parts, place them on the top rack of the dishwasher.
4. Wipe the base of the unit with a damp cloth.
5. Allow all parts to dry completely before reassembling.

### Spiraling Vegetables

No, this blender does not have a spiralising function.

### Crushing Ice

You can use both the cup and the jug to crush ice. However, please do not use the food processor bowl for this purpose.

### Grinding Grain

We advise against processing dry ingredients with the Single-Serve Blending Cup and Pro Extractor Blades Assembly, the Jug and Stacked Blade Assembly, or the Processor Bowl and Chopping Blade Assembly.

### Flashing Control Panel

If the control panel is flashing, it indicates that the lid is not locked in place correctly. Please ensure that you are installing the spindle, ingredients, disk, and lid correctly to resolve this issue.

## FAQ

Which parts of my blender are dishwasher safe?

The following parts are dishwasher safe (we recommend placing all parts on the top rack of the dishwasher):  
2.1L Total Crushing Jug and Lid 700ml Single-Serve Cup and Spout Lid Food Processor Bowl Stacked Blade Assembly Pro Extractor Blades Assembly Feed Chute Lid and Pusher Reversible Slicing/Grating Disc Disc Adapter Dough Blade Assembly Chopping Blade Assembly

How do I clean my unit?

Before cleaning, separate all parts. For Hand Washing: Wash all containers in warm, soapy water with a soft cloth. Wash blade assemblies in warm, soapy water using a dishwashing utensil with a handle to avoid direct contact with the blades. Exercise care when handling blade assemblies, as the blades are sharp. Thoroughly rinse and air-dry all parts. When Using a Dishwasher: All attachments are dishwasher safe. It is recommended that the containers, lids, and blade assemblies be placed on the top rack of the dishwasher ONLY. Ensure the blade assembly is removed from its container before placing in the dishwasher. Exercise care when handling blade assemblies. Cleaning the Motor Base: Turn off the unit and unplug the motor base before cleaning. Wipe the motor base with a clean, damp cloth. DO NOT use abrasive cloths, pads, or brushes to clean the base.

Can this spiralise vegetables?

No

Which parts of my blender can I crush ice in?

The cup and the jug can be used to crush ice. DO NOT use the food processor bowl to crush ice.

Can I grind grain?

We advise not to process dry ingredients with the Single-Serve Blending Cup and Pro Extractor Blades Assembly, the Jug and Stacked Blade Assembly or the Processor Bowl and Chopping Blade Assembly

Why is the control panel flashing?

If the control panel is flashing, this means the lid is not locked in place correctly. Ensure you are installing the spindle, ingredients, disk and lid correctly.

