

NINJA CB100UK Power Nutri Blender 2-in-1 User Guide

Home » Ninja » NINJA CB100UK Power Nutri Blender 2-in-1 User Guide 🖫



Contents

- 1 What's in the Box
- 2 Using the Unit
- 3 Blend & Enjoy
- 4 Cleaning
- 5 Documents /

Resources

- 5.1 References
- **6 Related Posts**

What's in the Box










Using the Unit



Tips

START/STOP and PULSE cannot be used in conjunction with any Auto-iQ programs. To stop running an Auto-iQ program before it's done, press the currently active button again.



Fill container with desired contents. Screw on the blade assembly until you have a tight seal.



Flip container upside down and install on base. Rotate clockwise until it clicks into place.

Blend & Enjoy



- 1. Select any programto begin blending.
- 2. If using the Power Nutri™ Bowl, twist the Power Paddle anti- clockwise continuously while processing.
- 3. When blending is complete, remove the container from base. Then, remove the blade assembly from container.

Taking It To Go?

Place the Storage Lid or Spout Lid on top of the bowl or cup and turn clockwise to seal.

NOTE: DO NOT microwave or freeze the Power Nutri™ Bowl or Power Nutri™ Cup.





WARNING: Handle the blade assembly with care, as the blades are sharp.

DID YOU KNOW?

Smoothie bowls are thicker & spoonable, compared to smoothies which are thinner & drinkable.



SMOOTHIE BOWL BASICS USING THE POWER NUTRI™ BOWL



Add milk or a milk alternative such as soy, coconut, almond, or oat milk, up to the LIQUID FILL line. ALWAYS DO THIS FIRST.



Add frozen fruits, directly from freezer and/or açaí, up to the MAX FILL line.


Cut larger fruit like bananas, in quarters.

If using açai, thaw slightly and cut in quarters.



3. (Optional)

Amplify your base by adding 1 scoop of yogurt, flavour powder, protein powder, and/or nut butter.



Screw on the blade assembly and install the bowl on the motor base. Select MIX and twist the Power Paddle anti-clockwise continuously while processing.



After blending is complete, add your favorite toppings such as coconut flakes, granola, fresh bananas, berries, and agave nectar.

Cleaning

STUCK-ON INGREDIENTS IN THE POWER NUTRI™ BOWL?



- 1. Rinse the bowl and blade assembly under WARM WATER after processing.
- 2. Fill the bowl with warm water up to the top of the paddle and add 1-2 SMALL DROPS of washing-up liquid.
- 3. Screw on the blade assembly and press MIX. Twist the Power Paddle anti-clockwise continuously while cleaning.
- 4. Once complete, empty contents and rinse under warm water.

NOTE: The Power Paddle in the Power Nutri™ Bowl is not removable.



Dishwasher

Containers, lids, and blade assembly are ONLY dishwasher safe on the top rack.



Hand-Washing

Wash containers, lids, and blade assembly in warm, soapy water. When washing the blade assembly, use a dishwashing utensil with a handle.

WARNING: Handle the blade assembly with care when washing, as the blades are sharp. Contact with the blades' edges can result in a laceration.

For questions or to register your product, visit us online at ninjakitchen.co.uk







Documents / Resources



NINJA CB100UK Power Nutri Blender 2-in-1 [pdf] User Guide CB100UK, Power Nutri Blender 2-in-1

References

• N Ninja UK - Kitchen Appliances | Blenders, Air Fryers, Grills & More

Manuals+,