

NOISE
noise MAX5
Bluetooth ANC
Headset



noise MAX5 Bluetooth ANC Headset User Guide

[Home](#) » [Noise](#) » noise MAX5 Bluetooth ANC Headset User Guide 

Contents

- [1 noise MAX5 Bluetooth ANC Headset](#)
- [2 PACKAGE CONTENTS](#)
- [3 PRODUCT OVERVIEW](#)
- [4 WEAR & ADJUST](#)
- [5 SPECIFICATIONS](#)
- [6 ANC BUTTON CONTROLS](#)
- [7 CONNECT TO A NEW DEVICE \(DUAL CONNECTION\)](#)
- [8 FCC](#)
- [9 WARRANTY](#)
- [10 Frequently Asked Questions](#)
- [11 Documents / Resources](#)
 - [11.1 References](#)
- [12 Related Posts](#)

NOISE

noise MAX5 Bluetooth ANC Headset




PACKAGE CONTENTS



Noise Airwave Max 5 x 1
User manual x 1
Warranty card x 1



Charging cable x 1




Audio cable x 1

PRODUCT OVERVIEW

1. Volume Up/Next Track
2. Multi-function Button
3. ANC Button
4. USB-C Port
5. Ventilation Tuning Hole
6. Volume Down/ Previous Track
7. Bluetooth Indicator
8. Microphone for Noise Cancellation/Call
9. Charging Indicator

10. Microphone for Noise Cancellation



WEAR & ADJUST





Adjust the headphone to properly fit your head, and match L/R earcups with your L/R respectively.

PAIRING

After powering on, it will automatically enter pairing mode, and the white indicator on the right headphone will flash quickly. Search for “Noise Airwave Max 5” for a match, and when the connection is successful, the light will turn on for 1 second and off for 1 second.

Note: the headphones will automatically power off if the connection is not complete within 10 minutes.




SPECIFICATIONS

Product Name	Noise Airwave Max 5
Bluetooth Version	5.4
Frequency Band	2400MHz-2483.5MHz
Max. RF Output Power	4dBm
Transmission Distance	10m/33ft Max (no blocking)
Bluetooth Profile	HFP/AVRCP/A2DP/BLE/SPP
Codecs	AAC/SBC
Frequency Response	20Hz-40kHz
Charging Port	Type-C
Battery Type	Polymer lithium-ion battery
Battery Capacity	600mAh 3.7V (2.22Wh)
Limited Charging Voltage	6.2 V
Charging Input	5V 600mA
Charging Time	About 1.5 hours
Operating Time	About 80 hours (ANC OFF) About 50 hours (ANC ON)


CHARGING

1.5 hours to fully charge.


Note: low power mode is red light 1 seconds off, please charge in time.



POWER ON

Press and hold  for 2 seconds till the white indicator turns on for 1 second.

POWER OFF


Press and hold  for 3 seconds till the red indicator turns on for 1 second.




ANC BUTTON CONTROLS


- Short Press: Cycle through “ANC off/ANC on/Ambient”
- Press and Hold for 1 second: Switch between music & gaming mode (powering off or charging will restore the headphones to the default music mode).

- Adaptive noise reduction mode: In the noise reduction mode, press the ANC button and volume up (+) for 1 second at the same time to enable/disable the adaptive noise reduction mode, and finally return to the default noise reduction mode.




FORCE PAIRING

When power  on, short press the for the 3 times to force the headphone into pairing mode. The white bluetooth indicator will flash quickly.



VOLUME BUTTON/POWER BUTTON CONTROLS




	× 1 Short press × 2 Short press twice × 1s Press & hold for 1s × 3 Short press thrice	Play/Pause/Answer/End call Activate voice assistant Reject call Enter pairing mode
	× 1 Short press × 2s Press & hold for 2s	Volume up Next Track
	× 1 Short press × 2s Press & hold for 2s	Volume down Previous Track
	× 1s Press & hold for 1s × 2 Short press twice	Game mode/music mode Spatial Audio on/off

RESET


Turn it off: Press and hold the power button for 3 seconds.

Resetting: Press and hold the power button for 10 seconds. The red/white indicator would be on for 3 seconds, indicating the resetting is completed.




CONNECT TO A NEW DEVICE (DUAL CONNECTION)

- Turn on your first phone's bluetooth, search for "Noise Airwave Max 5" and make a pair connection.
- Complete pairing with the 1st phone (or tablet/computer).
- Short press the power button for 3 times to put headphones into pairing mode.
- Connect to "Noise Airwave Max 5: in the Bluetooth list of your second device.
- Note: The headphone can only play music from one device at a time. There may be a momentary delay when switching devices due to different brands/versions and their compatibility.
- If one of the devices disconnects after dual connections, the headphones will remain connected to the other device and will attempt to reconnect to the disconnected device within 10 minutes.



WIRED PLAYBACK

- Use the included audio cable to connect the headphones to your device and control audio playback on it.
- Note: The USB-C audio cable included with this product only supports audio transmission and should not be used for charging.
- Some phones are limited by the system version, and you may not be able to use the headphones button and the microphone functions in wired mode.



FCC

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. this device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARRANTY

- The warranty covers your Noise product, including accessories, against manufacturing defects (if any) for 1 year from the date of purchase.
- Things that are not covered in the warranty are listed below:
- Unauthorised tampering, modifications or repairs of the product.
- Physical damage of the product on the account of abuse, handling, storage, installation or testing, including any use that is not by the product manual or documentation or any other instruction provided along with the Noise product.
- For further information on product replacement/refund-related queries, please refer to the terms and conditions mentioned in our online return policy section on www.gonoise.com

REGISTER YOUR WARRANTY www.gonoise.com/pages/

warranty-registration

SUPPORT AND SERVICE 1-YEAR LIMITED WARRANTY



SCAN ME

CUSTOMER QUERY

For any assistance, please reach out to us at support.gonoise.in

SAFETY FOR YOU AND YOUR NOISE AIRWAVE MAX 5

Follow these tips to get the best out of your new Noise Airwave Max 5:

- Do not expose the headphones to liquids, moisture, or humidity as they have electronics and batteries inside.
- Do not use abrasive cleaning solvents to clean your new headphones. Wipe them down with a slightly damp cloth if and when necessary.
- Do not expose the headphones to extremely high or low temperatures as this may damage the battery or even deform the plastic parts.
- Do not throw the headphones in a fire to dispose of them. The internal battery may explode.
- Pay attention to your surroundings, and never wear any headphones while riding, driving, or walking in traffic.
- Do not try to disassemble your headphones. There are no user-serviceable parts inside it.
- Avoid dropping the headphones and keep them away from sharp objects such as keys in your pockets.
- Only charge your headphones from 5V/1A ports such as phones and laptops or PC chargers.
- Avoid listening to music at a high volume, or you may permanently damage your hearing.

Frequently Asked Questions

- **Q: What should I do if I encounter interference while using the device?**

A: If you experience interference, try repositioning the device or adjusting its settings to minimize the impact of the interference. Ensure that the device is not causing harmful interference to other devices.

- **Q: Can I make modifications to enhance the device's performance?**

A: Any modifications should be approved by the relevant authority to maintain compliance with regulations and ensure the continued authority to operate the equipment.

Documents / Resources

	<p>noise MAX5 Bluetooth ANC Headset [pdf] User Guide MAX5, MAX5 Bluetooth ANC Headset, Bluetooth ANC Headset, ANC Headset, Headset</p>
---	--

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.