

NoiseFit Endure User Guide

Home » NoiseFit » NoiseFit Endure User Guide 🖺

Contents

- 1 FAQs
 - 1.1 About the product
 - 1.2 Getting Started
 - 1.2.1 Battery & Charging
 - 1.2.2 App
 - 1.2.3 Syncing
 - 1.2.4 Alerts &
 - **Notifications**
 - 1.2.5 Health Features
 - 1.2.6 Compatibility
 - **1.2.7 Straps**
- 2 Documents / Resources
 - 2.1 References
- **3 Related Posts**



FAQs

About the product



Does NoiseFit Endure have a full touchscreen display?

Yes, NoiseFit Endure features a full touchscreen display.

Is NoiseFit Endure waterproof?

Yes. NoiseFit Endure has an IP68 rating. It can go underwater up to a depth of 1.5m for up to 30 minutes. However, avoid saunas, hot water and ocean water.

Can NoiseFit Endure be used while swimming?

No, you cannot use your NoiseFit Endure while swimming. The NoiseFit Endure is IP68 rated and splash resistant only.

What is the MegaPixel of the NoiseFit Endure camera?

NoiseFit Endure does not feature with a camera. However, it can be used as a remote control for your phone's camera via Bluetooth.

Can I take a photo with it?

NoiseFit Endure does not feature with a camera. However, it can be used as a remote control for your phone's camera via Bluetooth.

Can I view photos in the smartwatch?

No, NoiseFit Endure does not have a gallery to view photos.

Can we reject calls from the smartwatch?

Yes, you can reject calls from the smartwatch.

Does it have a phone tracking option?

Yes. Turn on the watch screen. Swipe down, select Find Phone. However, this will only work if your phone and smartwatch are connected via Bluetooth and in range.

Does NoiseFit Endure have Gesture Control?

Yes, NoiseFit Endure comes with a Wrist Sense that turns on the display when you raise your wrist to look at the screen.

Can NoiseFit Endure store and play music?

NoiseFit Endure has a remote music control feature that controls music playing on your phone as long as your smartphone and smartwatch are in BT range. However, it cannot be used to store music.

Can it play music to Bluetooth headset?

NoiseFit Endure cannot play music through a Bluetooth headset.

Does it have an always on-screen feature?

No, NoiseFit Endure does not have an always-on screen. However, it detects when you raise your wrist to look at the screen and turns on automatically.

Can we change the watch face?

Yes, you can change the watch faces.

Open the Da Fit app, go to the Device, choose Watch Face and select one. From the watch, long-press the home screen. Swipe and choose the watch face. See how it's done in this video.

How do I use the stopwatch on my NoiseFit Endure?

Turn on the screen, swipe down, go to Settings and choose Stopwatch. Press Play to start the stopwatch. Press pause to pause it. Long press the button to exit the stopwatch. See how it's done in this video.

What sensors does the NoiseFit Endure have?

NoiseFit Endure features a Heart Rate and Acceleration sensor.

Does NoiseFit Endure have GPS and WiFi?

No, NoiseFit Endure does not feature GPS or WiFi. However, it can track your location during Outdoor Running mode through your phone's GPS when paired with the Da Fit app.

What are the accessories included with NoiseFit Endure?

NoiseFit Endure comes with one user manual, one magnetic charging dock and one charging cable.

Getting Started

How do I set up my NoiseFit Endure device?

Scan the QR code to download & install the Da Fit App in your phone.

- In the app, go to the device options and add a device. Select Endure.
- Your smartwatch and your smartphone are now paired. See how it's done in this video.

Why won't my NoiseFit Endure device sync?

This may be because it lost Bluetooth connectivity with your smartphone. For a stable connection, please ensure that the Da Fit app is running and locked in the background (Android only).

Why can't I set up my NoiseFit Endure device?

Restart your NoiseFit Endure and try again

Why didn't my NoiseFit Endure device alert me?

Possibly due to Bluetooth connectivity loss. Ensure that your watch & phone are within Bluetooth range with the alerts turned on in the App, which is kept running & locked in the background (Android).

How do I restart my NoiseFit Endure?

You can restart your NoiseFit Endure smartwatch by following these steps.

- · Turn on the watch screen
- Swipe down to go to Settings.
- Go to restart and choose to restart.

Battery & Charging

What is the battery capacity and standby time?

It features a 460mAh battery with up to 20-day battery life & 30-day standby. Stand-by time is the maximum tested time that a single charge will last when the smartwatch is used as a regular watch.

How do I know when my device is charged?

NoiseFit Endure takes approximately 2.5 hours to charge completely. It will display a 100% Charged message once the battery is at full capacity.

How do I check the battery level on my NoiseFit Endure device?

Turn on the screen and swipe down to check the battery level on your NoiseFit Endure.

How can I extend my NoiseFit Endure device's battery life?

You can extend the battery life in your device by turning down the brightness level, by turning off the Wrist Sense feature and turning off the All-Day Heart Rate measurement.

App

What's the name of the app?

The name of the app is Da Fit App.

How do I manage my Da Fit profile?

You can manage the Da Fit profile from the app. Open the App. Go to User. Choose Personal Info and edit your data.

How do I connect with friends on NoiseFit Endure app?

You cannot connect with friends on your Da Fit app.

How do I track my workouts with my Da Fit app?

You can track your workout on the daily report section of the Da Fit app. Open the Da Fit app. Go to the daily report section of the page and get your daily report.

How do I change the units of measurement on my NoiseFit Endure device?

You can change the units of measurement in your Da Fit app. Open the App then go to others and select Unit measurement and choose the unit setting.

Syncing

How does NoiseFit Endure sync data?

NoiseFit Endure syncs data over a Bluetooth connection with Da Fit app.

Alerts & Notifications

Does NoiseFit Endure show notifications from social networking apps?

NoiseFit Endure shows push notifications from social networking apps that have been synced with the Da Fit app. Please ensure that the Da Fit app is running and locked in the background (Android).

Why isn't NoiseFit Endure receiving notifications from my phone?

Possibly due to Bluetooth connectivity loss. Ensure that your watch & phone are within Bluetooth range with the alerts turned on in the App, which is kept running & locked in the background (Android).

Can we see messages and caller info from my phone on the smartwatch?

Yes, you can see messages and caller information on your smartwatch as long as the watch is synced with the Da Fit app and is within Bluetooth range.

How can we see the caller information?

Turn on the call notification feature on the Da Fit app to see incoming call information.

Can I read incoming messages on my NoiseFit Endure or will I only receive message notifications?

You will be notified of new messages on your NoiseFit Endure once it is connected with the Da Fit app. You can read the message at the time you receive a notification.

How do I use the NoiseFit Endure app to track my menstrual cycle?

You can track your menstrual cycle by following the steps. Open the Da Fit app, go to the Device and select Psychological Reminder and enter your cycle data. See how it's done in this video.

Can we silence incoming calls?

Since the band does not feature speakers, there will be no need to silence the incoming calls.

Health Features

How does NoiseFit Endure estimate how many calories I've burned?

NoiseFit Endure estimates the number of calories burned based on your activity duration, steps taken, distance covered, height, weight and age.

How do I track my heart rate with my NoiseFit Endure?

NoiseFit Endure can detect heart rate both manually or automatically. You can track your heart rate with Da Fit App.

Does this watch synchronize the sleep if the app is not connected?

Yes, NoiseFit Endure will measure your sleep even if not connected with App. The data will be synced to the app, once connected.

Does it have a Pedometer?

Yes, NoiseFit Endure comes with an in-built pedometer.

Compatibility

Is NoiseFit Endure compatible with iPhone?

NoiseFit Endure is compatible with all iPhones running on iOS 9 and above.

Is NoiseFit Endure compatible with Android?

NoiseFit Endure is compatible with all Android phones running on Android version 4.4 and above.

Straps

From where can I purchase a replacement strap?

You can purchase replacement straps from our official website. www.gonoise.com .

How do I change the wristband on my NoiseFit Endure device?

The mechanism to remove and replace the band can be found on the underside of the watchband.

Documents / Resources



References

- @ Noise | India's No.1 Wearable Watch Brand
- YouTube
- YouTube
- YouTube

Manuals+,