

NoKBabo B0C2467L3B iPad Keyboard Case With Touchpad



NoKBabo B0C2467L3B iPad Keyboard Case With Touchpad User Manual

[Home](#) » [NoKBabo](#) » NoKBabo B0C2467L3B iPad Keyboard Case With Touchpad User Manual 

Contents

- [1 NoKBabo B0C2467L3B iPad Keyboard Case With Touchpad](#)
- [2 Make sure you get the right model keyboard](#)
- [3 Package Inside](#)
- [4 Wireless Connection](#)
- [5 Backlight Instruction](#)
- [6 Touchpad Instruction](#)
- [7 Key Instruction](#)
- [8 Keyboard Shortcuts Instruction](#)
- [9 Troubleshooting](#)
- [10 Documents / Resources](#)
 - [10.1 References](#)

NoKBabo

NoKBabo B0C2467L3B iPad Keyboard Case With Touchpad



Make sure the keyboard is fully charged when you connect it with your iPad. Charge it for 3 hours when you first get it.

NOTE: “The keyboard is not waterproof. Please kindly pay attention to keep the keyboard away from water.

Make sure you get the right model keyboard

Method 1

- 1 >> Settings>General>About
- 2>> Tap on the M model number to display it

Method 2

- Check the back of your iPad

iPad 10.2/10.5 inch Keyboard Case Compatible Model:

- iPad 9th Generation 10.2 inch 2021 (A2602/A2603/A2604/A2605)
- iPad 8th Generation 10.2 inch 2020 (A2270/A2428/A2429)
- iPad 7th Generation 10.2 inch 2019 (A2197/A2200/A2198)
- iPad Air 10.5 inch 3rd Generation 2019 (A2152/A2153/A2123)
- iPad Pro 10.5 inch 2017 (A1701/A1709)

iPad 10.9/11 inch Keyboard Case Compatible Model:

- iPad Air 10.9 inch 5th Generation 2022(A2591/A2588/A2589)
- iPad Air 10.9 inch 4th Generation 2020(A2072/A2316/A2324/A2325)
- iPad Pro 4th Generation 2022 (A2759/A2435/A2761/A2762)
- iPad Pro 11 inch 3rd Generation 2021 (A2301/A2459/A2460/A2377)
- iPad Pro 11 inch 2nd Generation 2020 (A2228/A2068/A2230)

- iPad Pro 11 inch 1st Generation 2018 (A1876/A2014/A1895)




iPad 10th Gen 10.9 inch Keyboard Case Compatible Model:

- iPad 10th 10.9 inch 10th Generation 2022 (A2696/A2757/A2777)

iPad 12.9 inch Keyboard Case Compatible Model:


- iPad Pro 12.9 inch 6th 2022 (A2736/A2764/A2437/A2766)
- iPad Pro 12.9 inch 5th 2021 (A2378/A2379/A2461/A2462)
- iPad Pro 12.9 inch 4th Generation 2020 (A2069/A2229/A2232/A2233)
- iPad Pro 12.9 inch 3rd Generation 2018 (A1876/A1895/A1983/A2014)

Package Inside

-  Keyboard
-  Charging cable
-  User Manual

Wireless Connection

1. Make sure your iPad's system version is 13.2.2 or later and the iPad AssistiveTouch is on.
(Setting/Accessibility/Touch/AssistiveTouch/AssistiveTouch On)
2. Press the power button for 3 seconds to turn on the keyboard.
For iPad 12.9 inch keyboard case, please power on the keyboard by pushing the switch on the top right edge of keyboard to "ON" position first, then press the power button for 3 seconds to turn on the keyboard.
- 3.




***10.2" 10.5" 10.9" 11" keyboard**

Press pair button for 3 seconds to turn on the keyboard's Bluetooth, the pair indicator flashes blue.

For iPad 12.9 inch keyboard case, press fn+C to turn on the keyboard's Bluetooth, the pair indicator flashes



blue.




*10.2" 10.5" 10.9" 11" keyboard

4. Go to the iPad settings, click on Bluetooth and look for the keyboard. Click "Bluetooth keyboard" and it will connect. Once the connection is successful, the blue light of pair indicator goes off.
5. Once the connection is successful, the blue light of pair indicator goes off.

Backlight Instruction

- Press fn +  (Key to the right of space bar) to turn on the backlight. Press them again to increase the brightness. Press the third time to maximize the brightness. And press the fourth time to turn off the backlight. There are three levels brightness in total.
- Press fn +  (Key next to the light button) to change different rainbow colors. There are various colors for you to choose.
- Press fn+Q to turn on the breathing backlight, the backlight will flash at a rate. By pressing fn+W, you can change the rate of backlight breathing.
- By the way, pressing fn+Q also can turn on the backlight, and pressing them again will turn off the backlighl.



NOTICE:

1. Backlight will automatically turn off if there is no movement on keyboard over 5 seconds. Press any key and the backlight will light on.
2. Backlight will turn on when you turn on the iPad keyboard, and it will turn off automatically within 1 min. Don't worry. It's normal situation.


VERY IMPORTANT: If the keyboard is not working for more than 10 minutes, it will automatically sleep and enter into power saving mode. The keyboard will disconnect with your iPad. The keyboard will wake up and go back into working mode when you press any key. It will connect with your iPad again.

Touchpad Instruction

Make sure the touchpad can be used on your iPad as follows:

1. You need to complete the following settings:
Setting/Accessibility/Touch/AssistiveTouch/AssistiveTouch On
2. Make sure your iPad's system version is 13.2.2 or later.
3. Choose the right keyboard on your iPad.
Settings/General/Keyboard/Keyboards/English(US)/QWERTY

Notice: The third way can only be set after the keyboard and iPad have been successfully paired.



You can adjust the cursor tracking speed in two ways:


1. Settings/Accessibility/Touch/AssistiveTouch/AssistiveTouch/TRACKING SENSITIVITY
2. Settings/General/Trackpad/TRACKING SPEED

Cursor will be slower when it's closer to tortoise and more sensitive when it's close to the rabbit.


Notice: The second way can only be set after the pairing is successful.

If you don't need to use the touch pad for a while, you can press In+ T to lock the touchpad. And you can press them again to unlock the touchpad.

Key Instruction



1. Home
2. Darker
3. Brighter
4. Virtual keyboard
5. Search
6. Back
7. Play/Pause
(**Note:** Third party player video is not supported)
8. Forward
9. Mute
10. Volume down
11. Volume up
12. Lock screen
13. Pair button
(Keep pressing for 3 seconds)
14. Power button ((Keep pressing for 3 seconds to turn on/off)



1. Home
2. Darker
3. Brighter
4. Search
5. Switch the language
6. Virtual keyboard
7. Select all
8. Copy
9. Paste
10. Cut
11. Back
12. Play/pause
(**Note:** Third party player video is not supported)
13. Forward
14. Mute
15. Volume down
16. Volume up
17. Lock screen
18. Delete
19. Tab
20. Caps lock

Keyboard Shortcuts Instruction

1. Switch the language by pressing +

2. + Turn on/off the backlight or adjust the backlight brightness

Usage Method: Press once to turn on the backlight, press again to increase the brightness, press the third time

to maximize the brightness, and the fourth time to turn off the backlight.



3. Press these two keys to switch the backlight between rainbow and white.

4. To type the character in the gray area below, hold down the shift key and press the desired character.



5. Some special shortcuts

Select All + Cut + Paste + Copy +

6. Breathing lamp mode:



Turn on the breathing backlight



Change the breathing backlight rate

7. Fn+PgUp=Home

Fn+PgDN=End (Only for 12.9")

Charge

When the red light flashes, it shows that the keyboard is in a low battery state. You can find the Type-C charging cable in the package to charge it. The red light will stay on while charging and will turn green once it's fully charged. The keyboard will be fully charged in about 3 hours.

Note: If you don't use it normally, please recharge the keyboard in time, charging once a month is advised by NOKBABO.

Troubleshooting


1. Keyboard doesn't connect to your iPad when you first get it.

- Charge the keyboard first until it's fully charged.
- Please click "forget this device" to delete all the devices in your iPad Bluetooth list, then restart your iPad and keyboard. Connect them again.
- If the problem persists, please kindly contact us.

2. Touchpad doesn't work.

- Make sure your iPad's system version is 13.2.2 or later. Touchpad function requires iPad system version 13.2.2 or later to work.
- Make sure the iPad AssistiveTouch is on. It's always off by default. Please go to the iPad Accessibility setting to check if the iPad AssistiveTouch is on.

- The touchpad can be locked by pressing fn+ T, you can press them again to check if the touchpad is locked.
 - For more details, please kindly see the “Touchpad Instruction” on page 4.
 - If the problem persists, please kindly contact us.
3. Some keys doesn't work.
- Turn off the keyboard first, then turn it on again.
 - If the problem persists, please kindly contact us.
4. Inputs and outputs are inconsistent.
- Settings/General/Keyboard/Keyboards/English(US)/QWERTY
5. Space Bar doesn't work or insert a period.
- Settings/Accessibility/Keyboards/Full Keyboard Access/Commands/(INTERACTION) Activate “clear”
 - By default, “.” shortcut is on. Double-clicking the space bar will insert a period followed by a space.
 - You can turn it off as follows:
 - General/Keyboard/Hardware Keyboard/”.”Shortcut OFF
 - If the problem persists, please kindly contact us.
6. If there is a delay after you press a key, please kindly check the iPad Settings below:
- Settings/Accessibility/Keyboards/Slow Keys OFF
 - Settings/Accessibility/Keyboards/Slow Keys on 0.10 Seconds
7. If there are repeated characters after you press a key, please kindly check the iPad Settings below:
- Settings/Accessibility/Keyboards/Key Repeat OFF
 - Settings/Accessibility/Keyboards/Key Repeat on 0.1 O Seconds
8. Keyboard doesn't hold a charge.
- Please change another charging cable to charge the keyboard.
 - If the problem persists, please kindly contact us.
9. Can't find the charging cable in the package (as pictured).
- If there is no charging cable in the white box, please kindly contact us.




Contact Us

If you have any issues or questions, please feel free to contact us. We are committed to resolving any concerns promptly and ensuring your satisfaction. Each unit comes with a full 12-month warranty, so you can relax and be confident in your purchase. For the fastest & friendliest support, please contact us via email below. Our email support is open 24/7/365.

Email: nokbabo@hotmail.com

Documents / Resources

	NoKBabo B0C2467L3B iPad Keyboard Case With Touchpad [pdf] User Manual 6th Gen 2022, 5th Gen 2021, 4th Gen 2020, 3rd Gen 2018, B0C2467L3B, iPad Keyboard Case With Touchpad, Keyboard Case With Touchpad, Case Case With Touchpad, Case With Touchpad, Touchpad
---	---

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.