



Home » NONOMO » NONOMO HAMMOCK Swinging Hammock User Guide 🏗

Contents [hide]

- 1 NONOMO HAMMOCK Swinging Hammock
- 2 Safety information
- 3 Assembly instructions
- 4 Scope of delivery
- 5 Parts
- 6 Preparations
- 7 Let's assemble...
- 8 Make the nest
- 9 Usage and care
- 10 Caring for your NONOMO®
- 11 FAQ
- 12 Documents / Resources
 - 12.1 References



NONOMO HAMMOCK Swinging Hammock



We know...

We know you just can't wait to get your life-changing NONOMO® up and rocking. Soothing your baby to slumberland so that you can relax, knowing they're safe and sound asleep enjoying the best naps.

But...

Hang onto your hat before you start hanging. Count the parts. Read the safety notes. Check the instructions.

Then... you're ready to start. No tools needed.

So, get making. Stand back and admire your handiwork. Add baby. And relax!

Swing natural, cocooned.

calm

Let our NONOMO® swinging hammock wrap your baby in softness, soothe them to sleep and enjoy those calm daytime naps. Keeping them close to you, wherever you are, whatever you're doing. Cleverly designed, beautifully crafted for a peaceful baby, peace of mind for you.

Safety information

• IMPORTANT! RETAIN FOR FUTURE REFERENCE, READ CAREFULLY

- WARNING! Do not use this product without reading the instructions for use first.
 The NONOMO® baby hammock is suitable for babies weighing from 3.5 kg to a maximum of 15 kg.
- WARNING! Stay close to the product and keep an eye on your child as soon as they can sit or kneel or pull themselves up.

- WARNING! Do not place additional items (e.g. toys, pillows...) in the NONOMO®
 Swinging Hammock. Risk of suffocation.
- WARNING! Do not place the product close to another product, which could present a
 danger of suffocation or strangulation, e.g. strings, blind/curtain cords, etc.
 Never hang the swinging hammock near an open fire or other heat sources such as
 radiators, gas ovens, etc.

Always ensure that there is sufficient space.

NONOMO® products are only suitable for use indoors and in dry environments. Please do not leave the NONOMO® outdoors overnight.

- WARNING! All components of the swinging hammock must always be properly
 attached and checked that they are in proper, faultless condition before each use.
 Conversion or modification is not permitted, otherwise there is a risk of personal injury
 and damage to property.
 - Small individual parts are parts that could be swallowed and should never be left lying around loose.
- WARNING! Use only the mattress sold with this crib, do not place a second mattress
 on it, danger of suffocation. Do not use the mattress without hammock.
 Use only during daytime and under supervision. A hammock replaces neither cradle
 nor bed. Your child should be placed in a suitable cradle or bed if it has to sleep at
 night.
- The child may get injured if the amplitude of the swing is excessive (e.g. the child may hit the crib frame, or the crib may hit other furniture); Suspended cribs may pose risks to other children.
- Other children may pose additional risks (e.g. by swinging the crib excessively);
- Uneven surfaces can cause instability of the product. Locate suspended cribs in a
 place where there is no risk of swing impact (e.g. no risk of the child hitting the crib
 frame, or the crib hitting other furniture).
- IMPORTANT: The NONOMO® is neither a swing nor gymnastic or play equipment.
- If there is any damage or a defect in the NONOMO® products or parts are missing, they must no longer be used under any circumstances. All individual parts are available as spare parts via our customer service.

Assembly instructions

How to use safely

Never use the NONOMO® special spring without the safety rope supplied.

The safety rope should go through the spring, the ends should be attached to the snaphooks right above and below the spring.

The laces that hold the spreader bar in place should be tied securely with a double knot and kept out of the reach of children.


Scope of delivery

- Unpack all the parts.
- Follow our easy-peasy guide.
- Link all the parts together.
- Add baby, and relax.

NOTE

Building our hammock might be fun, but we strongly recommend that it's done only by grown-ups!

- get it together
- as easy as ABC
- one, two, sleep



Parts

1. Secure fixing

Weight-tested from 3.5 kg to 15 kg.

2. Steel spring

Rated to 15 kg, strong enough to last for years and never stretch or lose its bounce.

- 3. Spring cover
- 4. Oak spreader bar

Antibacterial, crafted from untreated PEFC certified wood from a sustainably grown forest.

Hanging hammockSoft, safe, cocooning, made from 100% polyester.

6. Mattress with

AeroSleep® protection

A supportive base for baby, with our unique 3D protector that guarantees safe

breathing, regulates temperature and wicks away moisture.

Preparations

Spring

It's spring time! It's our special spring that creates the gentle bob and bounce that soothes your baby to slumberland.

The NONOMO® spring arrives ready assembled. All you need to do is slide on the matching sleeve, and ruffle to taste. Not just a pretty face, it's there to protect baby, too. Tie the lace at the top & bottom so all metal parts are covered.



put a spring in it add the bounce for peaceful babies

Hammock sling

Hanging your hammock couldn't be simpler.

Gather up the handle, open clip, insert fabric, snap clip. Almost ready...





Let's assemble...

The hanging system



2x Snaphooks




Spring + safety rope





Spring cover – Tie the lace at the top & bottom so all metal parts are covered.



For mounting with Move Motor, please check the manual Move Motor.

Make the nest

With hammock sling hanging in position, gather the two ends and put our lovely oak spreader bar in place. Secure by tying the bow at either end. Do this every time you use your hammock, making sure you keep the laces out of reach of other children.











A high quality mattress with mattress cover is already delivered with your product.

Usage and care

Just add baby, and it's time to relax! Gently does it.







- 1. Hold your baby in the crook of your arm so that you're supporting their neck and back. Load from the front, with baby's head close to the top of the sling.
- 2. Close the hammock.
- 3. Time to rock-a-bye-baby.

Caring for your NONOMO®

Premium Hammock

You can just pop our swinging hammock, spring sleeve and mattress cover into the washing machine. All it takes is a quick, eco-friendly 40°C wash to get them fresh again. You don't even need to iron anything afterwards. (We won't tell anyone you haven't.) Because of the high quality AeroSleep® mattress protector covering the mattress foam, your mattress is safely protected from all kinds of liquids and there is no need to wash it.



We're here to help you swing happy!

Hammock sling

100% Polyester

Hopefully, this guide has told you all you need to know. But if not, you'll find lots more info on our website, www.nonomobaby.com Or do get in touch with our friendly NONOMO® team at info@nonomobaby.com

Mattress

Cover: 100% PES Filling: 100% PU Foam

 \boxtimes

Designed and manufactured by QLEVR Waterkeringstraat 21 ZUID IV

FAQ

Can I use a different mattress with the swinging hammock?

No, it is recommended to use only the mattress provided with the hammock to prevent suffocation risks.

Is it safe to leave my child unattended in the swinging hammock?

No, always supervise your child while they are in the hammock to ensure their safety.

Documents / Resources



NONOMO HAMMOCK Swinging Hammock [pdf] User Guide
HAMMOCK-2.0-no_ceiling_fixture-2025, HAMMOCK Swinging Hammock,
HAMMOCK, Swinging Hammock, Hammock

References

- User Manual
- NONOMO
- ▶ Hammock, HAMMOCK Swinging Hammock, HAMMOCK-2.0-no_ceiling_fixture-2025, NONOMO, Swinging Hammock

Leave a comment

Your email address will not be published. Required fields are marked*

Comment *

Name		
Email		
<u> </u>		
Website		
☐ Save my name, email, and website in this browser for the next time I com	ment.	
Post Comment		
Search:		
e.g. whirlpool wrf535swhz	Search	

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.