



NOTIFIER AFP-400 External Programming Utility Instruction Manual

[Home](#) » [NOTIFIER](#) » NOTIFIER AFP-400 External Programming Utility Instruction Manual 

Contents

- [1 NOTIFIER AFP-400 External Programming Utility](#)
- [2 Overview](#)
- [3 Minimum System Requirements](#)
- [4 Programming Kit](#)
- [5 Installation](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)
- [7 Related Posts](#)



NOTIFIER AFP-400 External Programming Utility



AFP-400 External Programming Utility

PRODUCT INSTALLATION DRAWING

Document 50376 Rev A Part Number 50376-A2

ECN 99-099 3/1/99

Overview

The VeriFire 400 Off Line Programming Utility lets you load or download programs between the PC and the control panel. This document contains instructions for installing the VeriFire 400 external programming kit:

- connecting a PC to the AFP-300 or AFP-400
- installing the VeriFire 400 program.

Minimum System Requirements

Minimum system requirements are a personal computer (processor 386 and up) with the following:

- 4MB RAM with a fixed disk
- Windows 3.1 or higher
- VGA monitor

Programming Kit

The VeriFire 400 programming kit contains the following.

Item:	Quantity
-------	----------

- | | |
|------------------------------|-------|
| • VeriFire 400 program disks | 1 Set |
|------------------------------|-------|

- Upload/Download cable (75267) 1 (Cable not in upgrade version)


Installation

For instructions on using the VeriFire program, refer to the on-line help utility.

If using a modem, reverse the black and green wires on the Upload/Download cable.


Install the VeriFire 400 external programming kit as follows:

Step	Action								
1	Connect one end of the Upload/Download cable to the PC communications port (COM1, COM2, COM3, or COM4).								
2	Connect the other end of the Upload/Download cable (P/N 75267) to terminal block TB2 on the CPU-300 or CPU-400 as follows: <div style="text-align: center;"> <table> <tr> <th>TB2 Terminal</th><th>Connect to...</th></tr> <tr> <td>TX</td><td>black</td></tr> <tr> <td>RX</td><td>green</td></tr> <tr> <td>REF</td><td>red</td></tr> </table> </div>	TB2 Terminal	Connect to...	TX	black	RX	green	REF	red
TB2 Terminal	Connect to...								
TX	black								
RX	green								
REF	red								
3	Insert Veri•Fire 400 Program Disk 1 into your PC disk drive.								
4	Read all “Readme” files on the program disks (if applicable).								
5	Start Windows™ and install the Veri•Fire 400 program by running the “Setup” file on Veri•Fire 400 Program Disk 1.								



External Programming Connections for the AFP-400/AFP-300

Documents / Resources

	<p>NOTIFIER AFP-400 External Programming Utility [pdf] Instruction Manual AFP-400 External Programming Utility, AFP-400, External Programming Utility, Programming Utility</p>
---	--

References

-  [Fire Alarm Resources | Download fire alarm documents](#)

Manuals+.