



nous E5 Smart Humidity Temperature Sensor Instruction Manual

[Home](#) » [NOUS](#) » nous E5 Smart Humidity Temperature Sensor Instruction Manual 

Contents

- [1 nous E5 Smart Humidity Temperature Sensor](#)
- [2 Know about the Temperature and Humidity Sensor](#)
- [3 Quick Installation Guide](#)
- [4 Documents / Resources](#)
 - [4.1 References](#)
- [5 Related Posts](#)




nous E5 Smart Humidity Temperature Sensor



You will need the Nous Smart Home App. Scan the QR code or download it from direct link



Know about the Temperature and Humidity Sensor



- **Button**

- **Reset or enter configuration mode:** Press and hold the button for 5 seconds until the blue LED blinks, the device will enter configuration mode

- **LED**


- **Blinking:** The device enters Zigbee network configuration mode(preparing to connect the gateway) OFF:
The device is under standby status

Quick Installation Guide


Note:

Please make sure the gateway is added and online before the next step


- (If you have installed the NOUS Smart Home on your mobile phone, please go to step 2) Scan the QR code or search NOUS Smart Home in the APP Store or Google Play to install the APP (new user must register account first).
- Open the NOUS Smart Home app, on the smart gateway homepage, Click: Zigbee Smart Gateway




2 Click "+Add subdevice"




3




- Remove the insulation sheet and press the reset button for 5 seconds, till the blue LED blink, then click "LED already blink" on the app.



- After waiting for a few seconds, you can see that this device is shown and you may rename it.



- Install the sensor at the place you need

	E5 Smart Humidity Temperature Sensor [pdf] Instruction Manual E5, E5 Smart Humidity Temperature Sensor, Smart Humidity Temperature Sensor, Humidity Temperature Sensor, Temperature Sensor, Sensor
---	--

References

- [User Manual](#)