

NOVY 7921400 Recirculation Box with Monoblock Filter Instruction Manual

Home » NOVY » NOVY 7921400 Recirculation Box with Monoblock Filter Instruction Manual



NOVY 7921400 Recirculation Box with Monoblock Filter Instruction Manual



Contents

- 1 INSTRUCTIONS FOR SAFETY AND USE
- 2 THE MONO BLOCK RE CIRCULATION **FILTER**
- **3 USE OF THE RE-CIRCULATION BOX**
- **4 INSTALLATION**
- 5 Documents / Resources
 - **5.1 References**
- **6 Related Posts**

INSTRUCTIONS FOR SAFETY AND USE

Further information on Novy products, accessories and services may be found on the internet: www.novy.co.uk These are the installation instructions for the appliance shown on the front.

These directions for use make use of a number of symbols.

The meanings of the symbols are shown below.

Symbol	Meaning	Action
	Indication	Explanation of an indication on the device.
	Warning	This symbol indicates an important tip or a dangerous situation



Warnings before installation

- · Read the directions for use and the installation instructions before installing and using this appliance. You will find important information here for the assembly and use of the appliance.
- The appliance is intended exclusively for household use (preparation of food) and excludes all other domestic, commercial or industrial use. Do not use the appliance outside.
- Keep good care of this manual and pass it on to any person who may use the appliance after you.
- This appliance complies with the applicable safety instructions. However, inexpert installation may cause personal injury or damage to the appliance.
- Check the condition of the appliance and the installation fittings as soon as you remove them from the packaging. Remove the appliance from the packaging with care. Do not use sharp knives to open the packaging.
- Do not install the appliance if it is damaged, and in that case inform Novy.
- Check on the basis of drawing 1 that all the materials for installation have been supplied. The filters are in the appliance.
- Novy is not liable for damage resulting from incorrect assembly, incorrect connection, incorrect use or incorrect operation.
- · Safety is guaranteed only with expert installation in accordance with the installation manual. The installing technician is responsible for proper operation at the installation location.
- · Metal parts may have sharp edges, and you may injure yourself on them. For that reason, wear protective gloves during installation.
- Do not convert or alter the appliance.
- Remove labels and stickers on the appliance with tips for use or installation. The type sticker is to be found behind the grease filter in the appliance. Do not remove it.

THE MONO BLOCK RE CIRCULATION FILTER

Contemporary, energy-efficient kitchen ventilation: you can't have the first without the latter. Recirculation offers the solution for this. Recirculation extraction hoods do not remove the cooking fumes, but filter the odour and fat out of the air and then blow the filtered air back into the home.

The Novy mono block filter absorbs unpleasant odours and makes the removal of hot air to the outside unnecessary. The basis of the monob lock filter is an advanced form of activated carbon particles in the shape of minuscule spheres that are bonded to a load-bearing labyrinth structure. Due to the labyrinth structure, the mono block filter has a limited loss of pressure and maintains a maximum efficiency. This results in efficient extraction, excellent odour absorption and a limited noise level.

USE OF THE RE-CIRCULATION BOX

The re circulation box must be used with an extractor hood or worktop extractor.



Before programming and using the re circulation mode, read the operating instructions for your device.


For optimal operation of the mono block re circulation filter, it is important to switch on the extractor before cooking and to respect the after-running time. To do this, read the instructions in the operating instructions for your appliance.



Provide adequate ventilation in the kitchen for optimal efficiency of the re circulation system.

An indication on the cooker hood or downdraft extractor indicates that the Monoblock recirculation filter needs to be replaced.

The lifetime of this Monoblock recirculation filter is indicated on the label on the filter itself.



You can obtain a new mono block filter from specialist retailers or via the Novy website. Article number mono block filter: 7910055 (2x)




Important: Please read the safety and installation instructions before you start.


INSTALLATION

1. Check that all the materials for installation have been supplied.

The filters are located inside the unit.




2. Positioning of the connecting opening: You have to decide before the installation where the connecting opening of the recirculation box is to be placed, all this depends on the build-in location:




- · centre rear side
- corner rear side
- side


- Left/right by turning the box 180°
- 3. Connect the position of a connection opening at the centre rear: mount the plate at the corner, with slots facing the centre. Secure with 4 screws.



4. Connect the position of a connection opening at the rear corner: mount the plate at the centre read, with slots facing the corner. Secure with 4 screws.




- 5. Connect the position of a connection opening at the side:
 - unscrew the long cover plate at the rear side.
 Position the long closed cover plate here.
 - unscrew the short cover plate at the side and position the connection opening here.



6. Create an opening for the drainage channel in the bottom of the housing (if necessary).




7. Make a build-in opening in the skirting with the following dimensions:



- 805 mm x100 mm (tolerance -0/+1 mm).
- Minimum height of the plinth: 100 (keep in mind that the recirculation box must be able to lie flat on the ground).
- Make sure there is sufficient building-in space: minimum building-in depth = 295 mm.
- 8. If the housings are supported by the exhaust box, ensure that the weight is distributed over the surface of the exhaust box.




9. Open the recirculation box by pressing the side (label, press here' or the marking on the exhaust box) until you hear a click. The grille is now completely free. Take the monoblock carbon filter from the recirculation box.




Now place the recirculation box in the opening in the skirting you have made.

10. Fasten the re circulation box by hand tightening the 3 screws supplied, not too tight!



11. Make the connection between the cooker hood and the re circulation box with drainage ducts (not included).



- First connect a piece of duct (906.401) to the connection of the re circulation box.
- A connecting piece can then be connected to this piece of flat duct.

Possible connecting pieces are:

- connector 906.402
- horizontal bend 906.403
- vertical bend 906.404
- Corner adapter 906.405
- Transition piece to Ø150 mm 906.406
- Flexible exhaust tube 906.408
- Use the aluminium tape supplied (906.262) to make an airtight connection.

Replace the mono block filters in the opening and close the grille.

Documents / Resources



NOVY 7921400 Recirculation Box with Monoblock Filter [pdf] Instruction Manual 7921400, 7922400, 7923400, 7921400 Recirculation Box with Monoblock Filter, 7921400, Recirculation Box with Monoblock Filter, Monoblock Filter, Filter, Recirculation Box, Box

References

- N Der Spezialist fÃ1/4r Dunstabzugshauben und Kochfelder Novy
- N Specialist in cooker hoods and hobs Novy
- N Specialist in cooker hoods and hobs | Novy Novy
- N Spécialiste des hottes et tables de cuisson Novy

