



NuPhy Air96 V2 Wireless Custom Mechanical Keyboard User Guide

[Home](#) » [NuPhy](#) » NuPhy Air96 V2 Wireless Custom Mechanical Keyboard User Guide 


NuPhy Air96 V2 Wireless Custom Mechanical
Keyboard User Guide



Contents

- 1 1. System Selection
- 2 2. Connection Mode Selection
- 3 3. Wireless Device Connection
- 4 4. Backlight Settings
- 5 5. Sidelight Settings
- 6 6. Sleep Mode Setting
- 7 7. The screenshot shortcut
- 8 8. Other Key Combos
- 9 9. Factory Reset
- 10 10. VIA keymap configurator
- 11 Documents / Resources
 - 11.1 References



1. System Selection




2. Connection Mode Selection




3. Wireless Device Connection




4. Backlight Settings



5. Sidelight Settings




6. Sleep Mode Setting




If there is no operation on the keyboard, it will turn off the light and enter sleep mode after 6 minutes.


7. The screenshot shortcut



8. Other Key Combos



9. Factory Reset




10. VIA keymap configurator

VIA is open source software developed independently from NuPhy and released under open source licenses. To obtain the latest VIA releases please visit nuphy.com/pages/console. If for any reason your keyboard cannot be detected by VIA under the wired mode, feel free to contact our technical support.

Mac Mode: LAYER 0/1

Win Mode: LAYER 2/3

Documents / Resources

	NuPhy Air96 V2 Wireless Custom Mechanical Keyboard [pdf] User Guide Air96 V2 Wireless Custom Mechanical Keyboard, Air96 V2, Wireless Custom Mechanical Keyboard, Custom Mechanical Keyboard, Mechanical Keyboard, Keyboard
---	---

References

- [User Manual](#)