



## **nutribullet Magic Bullet Mini Blender for Travel and Small Spaces User Guide**

[Home](#) » [nutribullet](#) » **nutribullet Magic Bullet Mini Blender for Travel and Small Spaces User Guide** 

**nutribullet Magic Bullet Mini Blender for Travel and Small Spaces User Guide**



## Contents

- 1 important safeguards
- 2 ventilation safety
- 3 heat and pressure safety
- 4 cleaning & user maintenance instructions
- 5 stubborn
- 6 save these instructions!
- 7 Technical specification
- 8 Documents / Resources
  - 8.1 References
- 9 Related Posts

## important safeguards

When using your magic bullet® mini, always observe basic safety precautions.

### warnings

- To avoid risk of electrical shock, never immerse power base, cord or plug in water/liquids.
- NEVER LEAVE THE MAGIC BULLET® MINI UNATTENDED WHILE IT IS IN USE.
- This appliance shall not be used or played with by children. Keep the appliance and its cord out of reach of children.

### medical safety & interactions!

The information contained in this user guide is not meant to replace the advice of your physician. Always consult your physician regarding health and nutrition concerns. If you are taking any medication, especially cholesterol lowering medication, blood thinners, blood pressure drugs, tranquilizers, or antidepressants, please check with your physician before trying recipes. bad seeds & pits – Do not use seeds and pits of apples, cherries, plums, peached and apricots in the magic bullet® mini, as they contain a chemical that releases cyanide into the body when ingested.

- Use of the magic bullet® mini in locations with different electrical specifications may result in damage to the product so please check specifications before operation. Do not use this product with any type of adapter or voltage converter device; this is considered unauthorized modification of the product and as such voids the warranty.
- Do not pull, twist, or damage the power cord, don't hang it over the edge of the table or counter and don't allow to touch hot surfaces, including a stove. Periodically inspect cord and plug. Do not operate the magic bullet® mini with a damaged cord or plug. A damaged cord or plug must be replaced by a qualified person in order to avoid a hazard.
- If the appliance malfunctions, is dropped or damaged in any manner, contact Customer Service for assistance via [www.nutribullet.nl/.be/.nu](http://www.nutribullet.nl/.be/.nu) or contact [service@nutribulletretail.com](mailto:service@nutribulletretail.com).
- Switch off and disconnect the magic bullet® mini from supply before assembling, disassembling, changing accessories, cleaning, while approaching parts that move in use and before leaving the unit unattended.
- Do not use your magic bullet® mini outdoors or in inclement weather.
- **CAUTION:** In order to avoid a hazard due to inadvertent resetting of the thermal cut-out, this appliance must not be supplied through an external switching device, such as a timer, or connected to a circuit that is regularly switched on and off by the utility.

- The power base, the cups or any other magic bullet® mini accessories are not intended to use in microwave ovens and freezers.
- This appliance may be used, cleaned and/or maintained by persons with reduced physical, sensory or mental abilities or lack of experience and/or knowledge, if they have been given supervision or instruction concerning use of the appliance in a safe way and if they understand the hazards involved.
- If the motor stops working, unplug the power base and let it cool for an hour before use it again.
- Periodically inspect magic bullet® mini components for damage or wear that may impair proper function. Discontinue use and replace components if you detect cracking, crazing or cloudiness or other damage to the plastic, the tabs, gasket or the power base.
- Blending containers and blades are specific to each model. Use of incompatible parts may result in damaging your magic bullet® mini or creating safety hazards. When replacing containers, blades or ordering additional accessories at [www.nutribullet.nl/be/nu](http://www.nutribullet.nl/be/nu), please verify it's compatible with your unit.

Only use original magic bullet® mini parts and accessories. Use of items, not recommended or sold by the manufacturer may cause fire, electric shock or injuries and will void the warranty. You may purchase new blending cups, lids and blades at [www.nutribullet.nl/be/nu](http://www.nutribullet.nl/be/nu).

### **ventilation safety**

To prevent a fire hazard, the openings on the bottom of the power base should be free of dust or lint and never obstructed as they are provided for ventilation to ensure reliable motor operation to prevent overheating. Never place your magic bullet® mini on top of flammable materials such as newspapers, tablecloths, napkins, dishtowels, place mats or other similar type of materials. Always operate the magic bullet® mini on a level surface, leaving unobstructed space beneath and around the power base to permit proper air circulation.

### **heat and pressure safety**

- **DO NOT BLEND HOT INGREDIENTS OR LIQUIDS.** Always start with room temperature or cooler ingredients (21°C or less). Never put hot ingredients or hot liquids in any closed-top blending cup before blending. The heat from the ingredients could cause pressure to build up in sealed cups causing possible expulsion which may cause personal injury or property damage.
- **NEVER ALLOW THE MAGIC BULLET® MINI TO RUN MORE THAN ONE MINUTE** at a time as it may result in the contents overheating which can increase the pressure and may cause the container to burst, resulting in possible personal injury or property damage. If you need to blend for longer, blend for 1-minute intervals allowing power base to shut off completely in between for 15 seconds. After 3 consecutive 1-minute intervals allow contents to settle for 2-3 minutes before continuing if necessary.
- The magic bullet® mini has an internal thermal breaker that shuts off the motor when it overheats. Unplug the power base and let it cool down for an hour or more before using it again. The power base will reset when the thermal breaker has cooled down sufficiently.
- Never blend carbonated liquids or ingredients (i.e. baking soda, yeast etc.). Pressure from released gases can cause the blending cup or blade to burst and resulting in possible injury.
- Don't allow blended mixtures to sit in a sealed cup for long periods of time! Sugar in fruits and vegetables could ferment. Built up pressure can cause ingredients to burst and spray out when opened.
- After blending, allow the contents to settle and release any pressure that may have built up during the extraction process by slowly unscrewing the cup. Have the cup pointed away from your body.
- **NOTE:** when making nut butters or oil-based foods: Due to its consistency the food will stick to the sides of the

cup during processing. Proceed in 20-30 second increments only by simply lifting the cup off the powerbase between intervals. Tap the cup in combination with opening it to scrape down the ingredients to the center before continuing to process the next increment. Allow your magic bullet® mini to cool down for 10 minutes after 4-5 cycles to prevent overheating and

**damaging the unit. blade safety to reduce the risk of personal injury or property damage**

- Blades are sharp! Use care while handling the blades, do not touch the edges.
- Avoid contact with moving parts! Keep hands and utensils out of and away from the blade while blending food. A scraper may be used, but only when the appliance is not running.
- Always inspect your blades before each use.

magic bullet® mini blend blades are designed for blending and available for all models. magic bullet® mini milling blades are available for magic bullet® mini and are ideal for turning dry ingredients into powders, e.g. milling oats, coffee beans, cereals, sugar and crunching herbs, nuts and seeds.

**Never store a blade in de power base without a blending cup attached! Never blend without liquid as doing so may damage the blend blade!**

to prevent leakage and to avoid the risk that residue builds up and damages the power base, always make sure:

- the blade is undamaged and its gasket is completely seated in the blade;
- the blade is securely screwed onto the blending container BEFORE placing it on the power base and operating the magic bullet® mini;
- the ingredients do not extend above the MAX line.
- NEVER BLEND WITHOUT LIQUID AS DOING SO MAY DAMAGE THE BLEND BLADE.
- The magic bullet® mini is not intended to be used as an ice crusher or without liquids. To make cold drinks, we suggest to use frozen fruit and chilled liquids. Alternatively, you may add crushed ice up to 25% of the total cup volume, with water or other liquid filled up to the MAX line.
- DO NOT USE the blend blade for grinding dry ingredients such as grains, cereals, coffee beans etc. as this may damage the motor and the blade.

**important! We recommend replacing the blades every six months or as needed to maintain optimal performance.**

**microwave & stove-top heating safety**

After blending room temperature or cooler ingredients, transfer mixture to an unsealed microwave-safe container or to a stove-top pot to heat. Do not place any of the magic bullet® mini parts in a microwave oven, stove-top pot or immerse in boiling water as this may result in damage to the accessory

**cleaning & user maintenance instructions**

Cleaning your magic bullet® mini is so easy... simply place any of the pieces (except for the power base and blades!) on the top shelf of the dishwasher or rinse/hand wash with warm soapy water.

**step 1:** The most important thing — ALWAYS UNPLUG the power base from the power supply outlet.

**step 2:** Make sure the blending cup/ blade assembly is not attached to the power base.

**step 3:** Now clean the individual components:

**power base** – for the most part, the power base doesn't really get dirty, but if you neglect to twist the blend blade on to the cup tightly, liquids can leak out and get into the base. Please:

- Do not remove the white liners inside the power base.
- Use a sponge/cloth moistened with warm (soapy) water to wipe down the inside well and outside until clean.
- Please pay particular attention to the actuator tabs to loosen any sticky debris from drips and spills. If necessary you may use a small brush to ensure it is kept clean.
- NEVER submerge the power base in water or put it in the dishwasher!

#### **blades:**

- Rinse in warm water immediately after each use to prevent debris from drying on the blades and gasket.
- NEVER wash blades in the dishwasher, elevated temperatures warp the plastic and damage the gasket.
- NEVER remove the gasket as this may permanently damage the blade and cause leakage. If after washing as indicated additional disinfecting is desired, you may rinse with a 10% vinegar/water solution or with lemon juice.
- Dry both sides of the blade completely.
- If, over time, the gasket becomes loose or damaged, you may order a new blade at [www.nutribullet.nl/be/nu](http://www.nutribullet.nl/be/nu).
- Replace your blade every 6 months for optimal performance

#### **magic bullet® mini accessories:**

Cups, lids and drink rings are all TOP RACK dishwasher safe. We recommend rinsing them and giving them a quick brush with a dish brush to remove any dried debris before washing them in the dishwasher. NEVER use the sanitize cycle to wash the blending containers as this may warp the plastic.

#### **stubborn**

#### **clean up**

If ingredients dry inside the magic bullet® mini containers, make your cleanup a snap by filling it about 2/3 full with room temperature (21°C or less) water and screw on the extractor blade. blend for about 20-30 seconds. This will loosen the stuck ingredients, and with a light scrub and rinse, you'll be all done.

#### **save these instructions!**

#### **For Household Use Only**

**tip :** For customers from Belgium: For an annual (or half-yearly) maintenance or cleaning service, we recommend our service center [www.nutribulletoutlet.nl](http://www.nutribulletoutlet.nl) (service@nutribulletoutlet.nl). For a small fee, they make your magic bullet ® mini look like new again!

**Warranty power base:** one year against factory and material defects. The warranty does not cover faults caused by incorrect handling, damage, assembly, attempted repairs and normal wear and tear. This guarantee does also not apply to parts and accessories like that have become unserviceable because of normal wear and tear, injudicious usage, carelessness or abuse. For blades due to normal wear and tear it is highly recommended to replace the blades every 6 months in case of regular use. This warranty does not affect applicable legal rights.

If you have any comments, questions or concerns, please go to [nutribullet.nl/.be/.nu](http://nutribullet.nl/.be/.nu) or send an email to: [info@nutribulletretail.com](mailto:info@nutribulletretail.com). Need service? Contact [service@nutribulletretail.com](mailto:service@nutribulletretail.com).  
FAQ's: [www.nutribullet.com](http://www.nutribullet.com) | [www.nutribullet.nl/be/nu](http://www.nutribullet.nl/be/nu)  
@nutribullet (US) or  
@nutribullet.nl/.b

On social media we take you on a discovery in the world of smoothies, and more! Here you will find numerous tips, tricks and accessible recipes that you can make with your magic bullet® mini. It will undoubtedly inspire you to get started yourself.



This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They will take care for environmental safe recycling.

## Technical specification

- **Voltage:** 220-240V
- **Frequency:** 50-60Hz
- **Protection Class:** II

### Manufactured for:

Capital Brands Distribution, LLC  
Los Angeles, CA 90025, U.S.A.  
Made in China

### Imported and distributed by:

nutribullet® Retail • 1251 NA-11 the Netherlands

[www.nutribullet.nl/be/nu](http://www.nutribullet.nl/be/nu)

For Nordic countries: [www.nutribullet.nu](http://www.nutribullet.nu)


Questions? [info@nutribulletretail.com](mailto:info@nutribulletretail.com)

Service? [service@nutribulletretail.com](mailto:service@nutribulletretail.com)










**For Nordic countries:** [info@nutribullet.nu](mailto:info@nutribullet.nu)

**PLEASE RETAIN THIS INFORMATION FOR FUTURE REFERENCE.**

## Documents / Resources

	<p><a href="#">nutribullet Magic Bullet Mini Blender for Travel and Small Spaces</a> [pdf] User Guide Magic Bullet Mini Blender for Travel and Small Spaces, Magic Bullet Mini, Blender for Travel and Small Spaces, Magic Bullet Mini Blender, Blender</p>
---	---

## References

-  [nutribullet Benelux = De officiële nutribullet website](#)
-  [mixers - 100% fokus på nutribullet & magic bullet](#)
-  [Nutribullet Outlet](#)
-  [TransIP - Reserved domain](#)
-  [nutribullet Benelux = De officiële nutribullet website](#)
-  [nutribullet | Smoothie Recipes, Health Advice & Shop - nutribullet](#)
-  [nutribullet Benelux = De officiële nutribullet website](#)
-  [mixers - 100% fokus på nutribullet & magic bullet](#)
-  [Nutribullet Outlet](#)

Manuals+.