



## nVent HOFFMAN CS480 Swivel Base External Bracket Coupling Instruction Manual

[Home](#) » [nVent HOFFMAN](#) » nVent HOFFMAN CS480 Swivel Base External Bracket Coupling Instruction Manual







### nVent HOFFMAN CS480 Swivel Base External Bracket Coupling Instruction Manual




#### Contents

- [1 Package Contents](#)
- [2 Installation Instruction](#)
- [3 Documents / Resources](#)
  - [3.1 References](#)
- [4 Related Posts](#)



#### Package Contents

|                                                                                                        |                                                                                                        |
|--------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------|
| <p>1</p>  <p>(1x)</p> | <p>2</p>  <p>(1x)</p> |
| <p>3</p>  <p>(4x)</p> | <p>4</p>  <p>(1x)</p> |


**Installation Instaruction**



22 Ft-lbs  
30 Nm



## Documents / Resources



[nVent HOFFMAN CS480 Swivel Base External Bracket Coupling](#) [pdf] Instruction Manual  
CCSS48BBCRE, CS480, CS480 Swivel Base External Bracket Coupling, Swivel Base External  
Bracket Coupling, Base External Bracket Coupling, External Bracket Coupling, Bracket Couplin  
g, Coupling

## References

- 🌟 [We connect and protect | nVent](#)

Manuals+.