




NYLAVEE SK100 Computer Speakers User Manual

[Home](#) » [NYLAVEE](#) » NYLAVEE SK100 Computer Speakers User Manual 

Contents


- [1 NYLAVEE SK100 Computer Speakers](#)
- [2 Package Included](#)
- [3 Specification](#)
- [4 Product Diagram](#)
- [5 Button Control](#)
- [6 Wired connection](#)
- [7 Wireless connection via Bluetooth](#)
- [8 Troubleshooting of Sound](#)
- [9 Worry-free Service Guarantee](#)
- [10 FCC Compliance](#)
- [11 Documents / Resources](#)
 - [11.1 References](#)
- [12 Related Posts](#)

NYLAVEE


NYLAVEE SK100 Computer Speakers



Package Included



1 x Computer Soundbar (SK100)



1 x 3.5mm Audio Cable




1 x User Manual

Specification

Device Model	SK100
Two Connection Options	Bluetooth 5.0 & 3.5mm audio plug
Power Supply	USB plug (no built-in battery)
Power Input	DC 5V :=, 2A Max

Product Diagram



- 1. Volume Knob
- 2. Bluetooth Indicator
- 3. AUXIN Jack
- 4. Power Indicator
- 5. AUX OUT Jack


Button Control

Function	Operation	Voice Prompt	LED Indicator
PowerOn	Insert the USB plug into any USB charging adapter or active computer USB port	Beep	Power Indicator stays solid blue
PowerOff	Unplug the USB power cord	/	/
Bluetooth Mode On /Off	Press the Volume Knob twice quickly	Beep	/
Bluetooth Pairing	/	Beep	Bluetooth Indicator flashes blue and white alternately
Bluetooth Connected	/	Beep	Bluetooth Indicator (blue) flashes every 5 seconds
Bluetooth Out of Range	/	/	Bluetooth Indicator flashes blue and white alternately
Volume+	Turn the Volume Knob clockwise	Beep when highest volume is reached	/
Volume-	Turn the Volume Knob counter clockwise	/	/
Play/ Pause	Press the Volume Knob once	/	/
Answer/ Hang Up Phone Call	Press the Volume Knob once	Beep when answering	/
Decline an Incoming Call	Press and hold the Volume Knob for 1 second	/	/

Wired connection

The soundbar does not have a built-in battery, please insert the USB plug into the USB port on the desktop, laptop, tablet, power bank, etc.

Wired Connection via 3.5mm Plug




1. Wired mode: the sound bar defaults to this mode when it is turned on.
2. When the Bluetooth Indicator light is off, it means the wired mode is on.
3. Insert the 3.5mm Audio Cable into the “AUX IN” jack at the back of the soundbar and plug the other end into your device.

Note:

- When want to use wired mode, please make sure the soundbar is not in Bluetooth mode.
- Quickly press the volume knob twice to switch from Bluetooth mode to wired mode.

Wireless connection via Bluetooth

Switch to Bluetooth mode



1. Press the Volume Knob twice quickly to turn on Bluetooth mode.
2. When the Bluetooth Indicator flashes blue/white, it means the Bluetooth pairing mode is on.

Pair with your device



1. Turn on the Bluetooth of your device and search for nearby devices.
2. Find “SK100” in the search results and tap to connect.

Once connected, a beep will be heard and the Bluetooth indicator (blue) will flash every 5 seconds.

Note:

- Make sure the soundbar isn't connected to other devices, otherwise please disconnect this device.
- If you can't find other connected devices, please press and hold the knob for 3 seconds to return to the Bluetooth pairing mode (Bluetooth Indicator flashes blue/white).
- Keep the soundbar and your device within 16ft/5m.

Troubleshooting of Sound

If there is no sound comes out from the soundbar, please try the following operations:

- Rotate the volume knob clockwise to raise the volume of the soundbar.
- Adjust the volume on your device.
- Press the volume knob to resume in case the soundbar paused.
- Re-insert the USB plug

Troubleshooting of Bluetooth Connection

- Make sure that the sound bar Bluetooth pairing mode is on (Bluetooth Indicator flashes blue/white).
- Make sure the Bluetooth of the soundbar is not connected by other devices.
- Unplug the 3.5mm Audio Cable from your device.
- Delete “SK100” memorized on your device, then search for “SK100” and connect again.

Worry-free Service Guarantee

- 30 days free return and exchange.
- 18 months warranty.
- Lifetime friendly customer service.

Please contact us for more details and further instructions via
service@nylavee.net

Extend 2-years warranty:
www.nylavee.net

FCC Compliance

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and (2) this device must withstand any interference received, including interference that may cause undesired operation.

Documents / Resources

	NYLAVEE SK100 Computer Speakers [pdf] User Manual B1MKbHZQzbL, SK100, SK100 Computer Speakers, Computer Speakers, Speakers
---	---

References

- [User Manual](#)