



ODIN Q4 Handheld Game Console User Manual

[Home](#) » [ODIN](#) » ODIN Q4 Handheld Game Console User Manual 

ODIN Q4 Handheld Game Console User Manual



Contents

- [1 system software](#)
- [2 Safety and User Instructions](#)
- [3 specifications](#)
- [4 Documents / Resources](#)
 - [4.1 References](#)

system software

Turning on the device for the first time

1. It is recommended to charge the battery for at least 30 minutes before turning on the device for the first time.
Be
sure to use the provided Type-C cable because use of unauthorized cables may cause damage on your device.

2. After the battery full charged, press and hold the power button for ten seconds until the device turns on, and the brand logo shows up.
3. Wait for the Logo screen to end, enter the wizard interface, follow the wizard interface to complete the basic settings of the device, and enter the system.

After entering the system:

1. In addition to providing the basic Android system, we also provide you with a front-end app with an integrated emulator. Click the launcher app on the homepage to enter;
2. You can view your current version information in the system update APP;
3. You can find all the setting options to turn off Odin in the settings app;
4. The drop-down taskbar provides you with some convenient function switches;
5. Use any APPs you downloaded in the horizontal screen, and the game assistant will appear on the right side of the interface.

System Upgrade

The device will follow the passage of time, collect user feedback into the system software to update iteratively, improve the operating experience, and add new software functions. Please check the upgrade in the system update APP.

Operation method:

Open the system update app; 2. Click "Check for upgrade". Note: When using this function, please check whether the network is unblocked, the device storage space is sufficient, and ensure that the device has enough power to support the upgrade.

For more information, please visit the website: <https://www.ayn.hk/>

Safety and User Instructions

Read all safety information and user instructions below carefully to ensure your safety and prevent equipment failure :

Health

Soreness, irritation, muscle soreness, numbness, stiffness nor other symptoms, please stop using in time. Let yourself rest, and make sure that your body has recovery. If the symptoms have not been relieved, please consult a doctor in time

Privacy

In order to prevent your private information from being stolen, please clear all accounts inside before discarding the device, restore the factory settings and then recycle.

Charge

- please stop using the device immediately if you find the surface and back cover of the device start to heat up if the device is used while charging then put the equipment in a ventilated place and wait for the device to cool down before continuing to use it.
- When the device is fully charged, disconnect the adapter from both the device and the power outlet;

- Do not clean the device when it's charging.

Buttons/Joysticks

In order to extend the service life of joysticks and buttons, Do not shake the joystick violently. Do not press the button vigorously Do not drop the device from a height. Keep away from the fire. Do not disassemble any components. If any parts appear damaged or missing, please reach us: [info @ayn.hk](mailto:info@ayn.hk)

Maintenance of Equipment

- When the device is not used for a long time, it is recommended to charge the device once in 3-5 months;
- If the equipment is not in use for a long time, please store the equipment in the box you purchased to prevent the equipment from entering dust; ,
- When cleaning the device, please use a soft cleaning cloth to wring dry and wipe, do not clean the screen forcefully, and disconnect the power supply; ,
- Do not leave the device in a high temperature environment for a long time, high temperature may cause the device to explode; ,
- Do not disassemble the equipment at will, please ensure the integrity of the equipment when in use; ,
- Do not place the device under blankets, pillows, or under your body, especially when connected to the charger, as this may cause the device to overheat

Battery If used properly, it will extend the life of the battery.

- Please fully charge the battery before using the device for the first time.
- Do not attempt to disassemble or replace the built-in battery
- Do not place equipment with batteries in a high-temperature environment. After charging is complete, disconnect the adapter from both the device and the power outlet.

Notice: The battery is a lithium battery. The leakage of the components contained in the battery or the combustion products of the components may cause personal injury and damage to the system. Please recycle and dispose of it in accordance with the local law.

Warranty

Returning the device to the factory for repair may cause loss of system data Please back up your data before sending it back.

- The device is entitled of one year warranty from the date of receipt, and the device can be returned or replaced within seven days of receipt if there is any quality problem
- The rechargeable battery will eventually be worn out due to repeated charging and discharging. This is normal consumption. From the date of receipt of the device, the battery will no longer be covered by warranty service after six months.
- Artificial damage (including but not limited to water, moisture, falling, squeezing, etc.) is not covered by warranty service
- Damage caused by improper use of accessories (caused by inferior accessories such as non-original accessories) is not covered by warranty service.

Notice: The device doesn't include shipping, so the return on ly refers to the product cost, not including the shipping fee.

TF card

If you want to add a TF card to the device, the TF card may be incompatible with the device. If there is an incompatibility, please use a card reader to connect to the computer, and form lease use a card reader to connect to the computer, and at the TF card into: FAT/TAT32/exFAT.

- Please check if the TF card is inserted correctly. If it is not rted completely, it may not work normally.
- If you use a TF card to store data, we are not responsible ny data loss inside the TF card.
- when the device is running, do not pull out the TF card to id data loss.
- Use TF card to store files. After inserting the TF card, p go to the corresponding APP to manually modify the stopath .

Clean

Please disconnect the power when cleaning, for safety.

- Please use a soft cleaning cloth to clean the screen.
- Do not use any chemicals containing chemicals to wip equipment
- If the headphone port, USB port, HDMI port, vent, and ker port need to be cleaned, please use a soft small bru clean

Contact

Official website : <https://www.ayn.hk/>

E-mail:info@ayn.hk

specifications

CPU	Qualcomm Snapdragon SD845 64bit Processor(Kryo 385)Quad-core Kryo Gold @ 2.8GHz.256KB L2 Quad-core Kryo Silver@ 1.8GHz.128KB U
GPU	Adreno 630
RAM	4GB/8GB
Storage	64GB/128GB /256GB ; TF Card Support
Screen	FHD 1080p;5.98 inch IPS LCD with touch; 1080×1920 pixels; 16:9 ratio; 369ppi Dragontrail glass
Video Output	HD MI + DisplayPort
Audio	Qualcomm Aqstic Audio Codec&Speaker Amplifier (2'1w)
WIFI	Standard
Bluetooth	Standard
Interface	USB 3.1 Type C/Mini HDMI/3.5mm Audio Jack
OS	Android 10.0
Battery	6600mA
Charging	Quick Charge 3.0/4.0/4.0+
Size	224'95'15

FCC Warning

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The user's manual or instruction manual for an intentional or unintentional radiator shall caution the user that changes or modifications not expressly approved by the party responsible for compliance could void the user's

authority to operate the equipment Specific Absorption Rate (SAR) information:


This Handheld game console meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health. FCC RF Exposure Information and Statement the SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types: Handheld game console has also been tested against this SAR limit. This device was tested for typical body-worn operations with the back of the Handheld game console kept 0mm from the body.

The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly.

The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.



Documents / Resources

	ODIN Q4 Handheld Game Console [pdf] User Manual 2BDXN-Q9, 2BDXNQ9, Q4, Q4 Handheld Game Console, Handheld Game Console, Game Console, Console
---	--

References

- [AYN Technologies Co., Ltd.](#)
- [AYN Technologies Co., Ltd.](#)
- [User Manual](#)