



OHMAXX EP2 Mini Smart Socket Alexa WiFi Smart Socket Instructions

[Home](#) » [OHMAXX](#) » OHMAXX EP2 Mini Smart Socket Alexa WiFi Smart Socket Instructions 

OHMAXX

EP2 Mini Smart Socket Alexa WiFi Smart Socket Instructions




Contents

- [1 What's in the Box](#)
- [2 Specification](#)
- [3 Warnings and Precautions Important!](#)
- [4 Documents / Resources](#)
- [5 Related Posts](#)

What's in the Box

1. Smart Plug
2. User Manual
3. Connection guidelines

At a Glance



Specification

Model: EP2

Rated Voltage: 250V~ 50/60Hz

Rated Current: 10A Max.

AC Frequency: 50Hz

WIFI frequency: 2.4GHz

Power Output: 2500W Max.

Main Features



Voice
Control



APP Remote
Control



Schedule
& Timer



Family
Share



No hub
required



Mini Size



Group & Scenes
Customization



V0 fireproof
materials

Reset

Turn on the power, hold the Switch/Pairing for 8 seconds and let go when the socket starts to flash quickly, the reset is successful.

When the socket is in a new network environment, you need to restore the factory settings, and then reconnect to the network.

Warnings and Precautions Important!

- Keep it out of the reach of children and pets.
- Do not use this product in humid environments or outdoors. It's for indoor use only.
- Do not place this product near heating devices, such as microwave ovens, or radiators.
- Protect the product from extreme temperature sunlight, strong jolts high humidity, moisture, flammable gases, vapors and solvents.
- Do not disassemble, modify, or repair your device, and ask help from the authorized professionals for device malfunction.
- Do not use the device when it is no longer working properly or visibly damaged.
- Do not store the device for extended periods in poor ambient conditions.
- Do not insert your device to another one.
- Never use aggressive detergents such as rubbing alcohol or other chemical solutions because these could damage the casing or even impair the functioning of the product.

Note: The image shown in the manual is indicative only. If there is inconsistency between the image and the actual product, the actual product shall govern

How to connect your device:



<https://qr14.cn/AKIJaq>

OHMAXX

4.02.000.0797 V1.0



Made In China

Documents / Resources

	<p>OHMAXX EP2 Mini Smart Socket Alexa WiFi Smart Socket [pdf] Instructions</p> <p>EP2 Mini Smart Socket Alexa WiFi Smart Socket, EP2, Mini Smart Socket Alexa WiFi Smart Socket, Alexa WiFi Smart Socket, WiFi Smart Socket, Smart Socket</p>
---	---