



## omega OBO9010AMCOM 90cm Built In Oven User Guide

[Home](#) » [Omega](#) » omega OBO9010AMCOM 90cm Built In Oven User Guide 

omega OBO9010AMCOM 90cm Built In Oven



## Contents

- [1 Before First Use](#)
- [2 Touch Control Buttons](#)
- [3 Details](#)
- [4 Setting the Clock](#)
- [5 Cooking Functions](#)
- [6 Customer Support](#)
- [7 Documents / Resources](#)
  - [7.1 References](#)
- [8 Related Posts](#)

## Before First Use

Before using your new Omega Built-In Oven for the first time, please read your manual thoroughly, even if you are familiar with this type of appliance.







When your oven is switched on for the first time, it may give off an unpleasant smell. This smell is completely normal, and is due to the oven's manufacturing process.

To remove the smell, we recommend that you set the temperature to the highest setting with the Fan Forced function selected. Ensure that the oven is completely empty, and that the door has been firmly shut.

Run the program for 90 minutes, then turn the oven off.

After the oven has cooled down, allow the door to be opened at a 45° angle to allow for further ventilation.

## Touch Control Buttons

	Minus / Decrease
	Function
	Plus / Increase
	Alarm
	Set Cooking Time
	End Cooking Time
	Clock

## Details



**Product Dimensions (W, D, H):** 894 × 575.2 × 595mm

**Capacity:** 148L (gross) | **Warranty Period:** 3 Years







## Setting the Clock





When the power is first connected, the oven LED screen will display '12:00' while an illuminated bar above the symbol will flash, indicating you can now set the time.

Press either the + or – buttons to choose the correct time, once the correct time is displayed, simply avoid touching any buttons for 5 seconds and the time will be locked in.

Readjust the time by pressing the function button  until a bar flashes above the clock symbol , then press either the + or – buttons to set the time. As before, avoid contact with the buttons for 5 seconds and the new time will be set.

## Cooking Functions

	<b>Light</b> —
	<b>Conventional</b> 60°C – MAX
	<b>Fan Forced</b> 60°C – MAX
	<b>Fan &amp; Grill</b> 60°C – 200°C
	<b>Grill</b> 60°C – MAX
	<b>Maxi Grill</b> MAX

	<b>Pastry Bake</b> 60 – 250°C
	<b>Fan Bake</b> 30°C – MAX
	<b>Air Fry</b> 230°C
	<b>Defrost</b> —

For more information of each cooking program's function along with detailed operation instructions, please refer to your supplied User Manual, pages 09–12.

## Customer Support

### Details

Product Dimensions (W, D, H): 894 × 575.2 × 595mm  
Capacity: 148L (gross) | Warranty Period: 3 Years





### Support

**Telephone:** 1300 11 HELP (4357)  
**Email:** [support@residentiagroup.com.au](mailto:support@residentiagroup.com.au)



Documents / Resources

	<p><a href="#">omega OBO9010AMCOM 90cm Built In Oven</a> [pdf] User Guide</p> <p>OBO9010AMCOM 90cm Built In Oven, OBO9010AMCOM, 90cm Built In Oven, Built In Oven, I n Oven, Oven</p>
	<p><a href="#">omega OBO9010AMCOM 90cm Built In Oven</a> [pdf] User Manual</p> <p>OBO9010AMCOM 90cm Built In Oven, OBO9010AMCOM, 90cm Built In Oven, Built In Oven, I n Oven, Oven</p>

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.