




omega ODO6012M Built In Oven User Guide

[Home](#) » [Omega](#) » omega ODO6012M Built In Oven User Guide 

Contents

- 1 [omega ODO6012M Built In Oven](#)
- 2 [Product Usage Instructions](#)
- 3 [introducing your new 60cm Built-In Oven](#)
- 4 [Setting the Clock](#)
- 5 [Touch Control Buttons](#)
- 6 [Cooking Functions](#)
- 7 [Documents / Resources](#)
 - 7.1 [References](#)
- 8 [Related Posts](#)

omega

omega ODO6012M Built In Oven



Specifications

- **Model:** ODO6012M
- **Size:** 60cm Double Oven
- **Version:** V1.0 1223
- **Designed Year:** 1998

Product Usage Instructions

Before First Use:

Before using your new Omega Built-In Oven for the first time, read the manual thoroughly. Even if you are familiar with this type of appliance, it's important to understand the specific features of this oven. When turning on the oven for the first time, it may emit an unpleasant smell due to the manufacturing process. To remove the smell, follow these steps:

1. Set the temperature to the highest setting with Fan Forced function selected.
2. Ensure the oven is empty and the door is securely closed.

Setting the Clock:

When the power is connected, the oven LED screen will display a flashing symbol, indicating it's time to set the clock. Follow these steps:

1. Set the correct time using the appropriate buttons.
2. Avoid touching any buttons for 5 seconds to lock in the time.
3. To readjust the time, press the function button four times until the clock symbol flashes again.
4. Avoid touching any buttons for 5 seconds to set the new time.

Touch Control Buttons:

The touch control buttons on your Omega Built-In Oven include:

- Minus/Decrease Function
- Plus/Increase

- Alarm Set
- Cooking Time
- End Cooking Time
- Clock

Cooking Functions:

The oven offers various cooking functions. Refer to the manual for detailed instructions on each function and how to use them effectively.

Contact Information:

- Support Telephone: 1300 11 HELP (4357)
- Email: support@residentiagroup.com.au

FAQ:

- **Q: Why does the oven emit an unpleasant smell when first used?**

A: The smell is normal and is a result of the oven's manufacturing process. To remove the smell, follow the instructions provided in the manual.

- **Q: How do I set the clock on my Omega Built-In Oven?**

A: When the power is connected, follow the steps outlined in the manual to set the clock on your oven.

introducing your new 60cm Built-In Oven


Before First Use

Before using your new Omega Built-In Oven for the first time, please read your manual thoroughly, even if you are familiar with this type of appliance.



When your oven is switched on for the first time, it may give off an unpleasant smell. This smell is completely normal, and is due to the oven's manufacturing process.

To remove the smell, we recommend that you set the temperature to the highest setting with the Fan Forced function selected. Ensure that the oven is completely empty, and that the door has been firmly shut. Run the program for 90 minutes, then turn the oven off. After the oven has cooled down, allow the door to be opened at a 45° angle to allow for further ventilation.

Setting the Clock








When the power is first connected, the oven LED screen will display the  symbol flashing, indicating you can now set the time.

Press either the + or – buttons to choose the correct time, once the correct time is displayed, simply avoid touching any buttons for 5 seconds and the time will be locked in.









You can readjust the time by pressing the function  button four times until the clock symbol  displays flashing, then press either the + or – buttons to set the time.

As before, avoid contact with the buttons for 5 seconds and the new time will be set. To discover more about your oven's functions, see page 10–12 of your supplied User Manual for more information.

Touch Control Buttons

	Minus/Decrease
	Function
	Plus/Increase
	Alarm
	Set Cooking Time
	End Cooking Time
	Clock

Cooking Functions

	Light —		Fan & Grill 60–200°C
	Convection 60°C–MAX		Fan Forced 60–MAX
	Pastry Bake 60–230°C		Brown (Broil) 60–MAX
	Grill 60°C–MAX		Classic Bake 60–MAX

For detailed operation instructions, please refer to your supplied User Manual, pages 10–13.


Details

- **Product Dimensions (W, D, H):** 595 × 561 × 888mm
- **Capacity:** 31+57L (gross)
- **Warranty Period:** 2 Years

Support

- **Telephone:** 1300 11 HELP (4357)
- **Email:** support@residentiagroup.com.au

Documents / Resources

	<p>omega ODO6012M Built In Oven [pdf] User Guide</p> <p>ODO6012M, ODO6012M, ODO6012M Built In Oven, ODO6012M, Built In Oven, In Oven, Oven</p>
---	--

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.