

[Skip to content](#)

Manuals+

User Manuals Simplified.

OMEGA OS306-Series Infrared Thermometer User Guide

[Home](#) » [Omega](#) » OMEGA OS306-Series Infrared
Thermometer User Guide

OMEGA OS306-Series Infrared Thermometer



Contents [hide](#)

[1 Battery Installation](#)

[2 How to turn on the unit](#)

[3 Quick Measurement](#)

[4 Switch between Celsius and Fahrenheit](#)

[5 Field of View](#)

[6 Contact Information](#)

[7 Documents / Resources](#)

[8 Related Posts](#)

Battery Installation

1. Locate the notches on the side of the unit's handle and pull the front of the handle forwards as shown above.



2. Attach a 9V battery (provided) to the black connector inside. The battery should snap into place. Swing the front of the handle back upwards to close the unit.



How to turn on the unit

- Press the trigger of device to power on

Quick Measurement

- Point thermometer at a target surface
- Pull and hold the trigger to begin scanning
- Release the trigger to stop scanning
- The data will be held for 30 seconds then the unit will power off

Switch between Celsius and Fahrenheit


The default setting for the temperature unit is in Celsius. Please follow the below steps to change the temperature units to Fahrenheit.

- Press the “°C °F” Button
- You should now see the temperature displayed in °F (Fahrenheit)



Field of View

- This unit has a distance ratio of 12:1
- When measuring a surface 300 mm away, a 25 mm area will be measured.



Contact Information

If you need technical support, please call 1-888-826-6342.

omega.com



Documents / Resources



[OMEGA OS306-Series Infrared Thermometer \[pdf\] User Guide](#)
OS306-Series, OS306-Series Infrared Thermometer, OS306-Series, Infrared Thermometer

[Manuals+](#),

- [home](#)
- [privacy](#)