



[Home](#) » [Support](#) » **One Fire WH-C17 Small Table Lamp User Manual** 

Contents [[hide](#)]

- [1 One Fire WH-C17 Small Table Lamp](#)
- [2 INTRODUCTION](#)
- [3 SPECIFICATIONS](#)
- [4 WHAT'S IN THE BOX](#)
- [5 FEATURES](#)
- [6 SETUP GUIDE](#)
- [7 CARE & MAINTENANCE](#)
- [8 TROUBLESHOOTING](#)
- [9 PROS & CONS](#)
- [10 WARRANTY](#)
- [11 FREQUENTLY ASKED QUESTIONS](#)
- [12 References](#)



One Fire WH-C17 Small Table Lamp



INTRODUCTION

An inventive, environmentally friendly lighting option ideal for any contemporary living area is the One Fire WH-C17 Small Table Lamp. This fashionable lamp, which was introduced by One Fire, is reasonably priced at **\$18.99** and blends great functionality with versatility. Up to 200 hours of cordless use are possible with its integrated 3600mAh rechargeable battery, which makes it perfect for reading, working, and providing ambient lighting in offices, dorm rooms, and bedrooms, among other places. It has ten programmable brightness levels, touch-sensitive controls, 38 LED beads, and a portable, folding design that is both small and strong. It is composed of sturdy ABS plastic, has a light memory feature, and generates 300 lumens of gentle, ocularly friendly light. Convenience, efficiency, and contemporary style are all combined in the WH-C17, which you may use to improve your child's bedroom or create a comfortable study area. It is a true "green" lamp that does away with the need for throwaway batteries and is proudly constructed with user comfort and sustainability in mind.

SPECIFICATIONS

Product Name	One Fire WH-C17 Small Table Lamp
Price	\$18.99
Power Source	3600mAh Rechargeable Battery + USB Powered
Battery Life	Up to 200 hours (max, depending on brightness level)
Light Source Type	LED (30 LED beads, 300 lumens, eye-caring)
Brightness Levels	9–10 Adjustable Levels
Control Method	Touch Control (Short press: ON/OFF, Long press: Dimming)
Material	Acrylonitrile Butadiene Styrene (ABS)
Mounting Type	Desktop
Foldable	Yes (Portable and compact design)
Cordless	Yes (can be used wirelessly after charging)
Color	Black
Special Features	Light Memory Function, Eco-Friendly, Eye Protection, Wireless, Sturdy Base
Room Type	Office, Kids Room, Bedroom, Classroom, Study Room
Dimension	12.79 h,4.92 w
Is Waterproof	Yes
Bulb Shape Size	A19
Wattage	5W
Number of Light Sources	38 LEDs

Included Components	Built-in Battery
Connectivity Technology	USB
Warranty	24-Month Quality Promise



WHAT'S IN THE BOX

- Table Lamp
- User Manual

FEATURES

- **Rechargeable Battery Life:** After a full charge, the 3600mAh rechargeable battery provides up to 200 hours of cordless illumination.



- **Cordless & Portable:** This battery-powered device is perfect for use at home, at the office, or on the go.
- **Touch Control:** To adjust the lamp's brightness and power, tap its surface.
- **9–10 Brightness Levels:** Long-press control allows you to adjust the brightness of the dimmable lighting.

EYE CARING & DIMMABLE DESK LAMP



- **LED Light Source:** Energy-efficient, gentle, and aesthetically pleasing illumination is produced by 38 LED beads.
- **Brightness of 300 Lumens:** This powerful and steady light output is perfect for working and reading.
- **Memory Function:** When you turn it back on, it remembers your previous brightness setting.
- **Foldable Design:** Adaptable, foldable construction for portability and small storage.
- **Sturdy ABS Construction:** Long-lasting Acrylonitrile Butadiene Styrene is used in its construction
- **Water-Resistant:** Made to withstand small splashes or spills thanks to waterproofing.
- **USB Rechargeable:** Easily charges with a USB cord using a wall adapter, laptop, or power bank.
- **Versatile Use:** Fits well in workplaces, classrooms, study spaces, and bedrooms.
- **Low Wattage (5W):** Strong lighting with energy-efficient operation.

- **Touch-sensitive Switch:** Long press to dim, short press to turn on/off.
- **Eco-Friendly Design:** It is economical and sustainable as it does not require AA batteries.



SETUP GUIDE

- **Unpack Carefully:** Gently take the lamp and its accessories out of the box.
- **Charge Before Using:** Make sure the lamp is completely charged by plugging the USB wire into a power source.
- **Complete Charging Time:** Give it three to five hours to fully charge before using it for the first time.
- **Power On:** To activate the lamp, briefly push the touch button.
- **Brightness Control:** To adjust the light's brightness, long-press the touch area.
- **Fold the Lamp:** To save space, fold the lamp when not in use and adjust the angle as necessary.

- **Portable Use:** Once fully charged, use the cordless lamp anywhere; no cables are required.
- **Desktop Positioning:** To prevent toppling over, place on a level, sturdy surface
- **Modify Light Direction:** To achieve the best lighting direction, tilt or rotate the lamp head.
- **Utilize USB Charging Port:** Connect the USB cable to wall adapters, laptops, or power banks.
- **Avoid Overcharging:** To extend battery life, avoid overcharging and disconnect as soon as the battery is fully charged.
- **Test Brightness Levels:** Go through each brightness level to choose which one you like best.
- **Turn on Memory Function:** To turn on memory function, use the same brightness setting.
- **Ensure Ventilation During Charging:** Don't cover the lamp during charging.
- **Check Indicator Light:** To make sure electricity is flowing, look for a charging light.

CARE & MAINTENANCE

- **Keep Dry:** Avoid submersion in full water, even though it is waterproof.
- **Clean Gently:** Use a gentle, moist cloth to wipe. Avoid using strong chemicals.
- **Prevent Overheating:** Avoid leaving the bulb on for long periods of time without supervision.
- **Charge Frequently:** Even when the battery is not being used, recharge it every few weeks.
- **Prevent Dropping:** Although the lamp is robust, it is not impervious to impacts
- **Preserve the USB Port:** Keep it dry and dust-free.
- **Keep Correctly:** When not in use, fold and keep in a dry, safe place.
- **Avoid Extreme Temperatures:** Steer clear of freezing conditions and heat sources.
- **Avoid Blocking LED Beads:** To provide uniform illumination, keep light sources free.
- **Check for Wear:** If the USB charging cord is ragged or broken, replace it.
- **Battery Maintenance:** Steer clear of routinely overcharging or discharging the battery entirely.
- **Avoid Disassembling:** Doing so could void the warranty or cause harm to certain parts.

- **Monitor Brightness Decline:** This could indicate that you need to recharge.
- **Use Original Cable:** Use the supplied or manufacturer-approved USB cable for optimal performance.
- **Use Warranty:** If you need help within the 24-month period, get in touch with One Fire support.

TROUBLESHOOTING

Issue	Possible Cause	Solution
Lamp not turning on	Battery is completely drained	Recharge the lamp fully using a USB cable
Light turns off unexpectedly	Auto shut-off due to low battery	Fully charge the lamp and avoid using during low battery
Brightness won't change	Long-press gesture not recognized	Ensure finger is steady on touch area for a few seconds
Lamp not charging	Faulty cable or power source	Try a different USB cable or charging port
Flickering light	Loose internal connection or low power	Secure connections or recharge battery
Short battery life	Battery not fully charged or aged battery	Allow full charge cycles or consider warranty support
Touch sensor unresponsive	Sensor area dirty or moisture on surface	Clean and dry the touch control panel
Light not retaining brightness level	Memory function reset	Re-adjust brightness and let lamp complete charge cycle
Lamp overheating	Long-term high-brightness use	Use moderate brightness levels and let lamp cool

Issue	Possible Cause	Solution
Light too dim	Low brightness setting selected	Long-press to increase brightness to desired level

PROS & CONS

Pros:

- Long-lasting 3600mAh rechargeable battery with up to 200 hours of use
- Touch control with 10 brightness levels for customizable lighting
- Foldable, lightweight, and portable design perfect for travel or small spaces
- 38 LED beads provide eye-caring illumination
- Waterproof design suitable for various environments

Cons:

- Takes time to fully charge due to high battery capacity
- Brightness may not be sufficient for large rooms
- Touch controls can be overly sensitive for some users
- Only available in black color option
- No USB adapter included for charging

WARRANTY

The One Fire WH-C17 Small Table Lamp comes with a **24-month quality guarantee**. This warranty covers any manufacturing defects or performance issues during normal use. Customers experiencing product concerns can rely on One Fire's customer service for troubleshooting assistance, replacements, or refunds during the warranty period. The brand emphasizes top-tier service and stands behind its promise of quality, offering peace of mind with every purchase.

FREQUENTLY ASKED QUESTIONS

What is the maximum usage time of the One Fire WH-C17 Small Table Lamp on a full charge?

The One Fire WH-C17 Small Table Lamp supports up to 200 hours of use at the lowest brightness setting, thanks to its powerful built-in 3600mAh rechargeable battery.

How do I turn the One Fire WH-C17 Small Table Lamp on or off?

Simply short press the touch-sensitive switch on the One Fire WH-C17 lamp to turn it on or off.

How do I adjust the brightness levels on the One Fire WH-C17 Small Table Lamp?

Long press the touch control area to adjust the brightness. You can choose from 9 dimmable levels for the perfect lighting.

My One Fire WH-C17 Small Table Lamp is not turning on. What should I check first?

Ensure the lamp is charged. If using the USB cable, verify the connection and try another port. If it still doesn't work, reset the lamp by holding the touch button for 10 seconds.

The brightness of my One Fire WH-C17 lamp seems weak. Why?

Check if the battery is low. Reduced brightness can occur in power-saving mode. Recharge the lamp and test again at full power.

My One Fire WH-C17 lamp doesn't respond to touch controls. What can I do?

Wipe the touch area clean from dust or moisture. If unresponsive, hold the button for a reset or fully recharge the lamp before testing again.

The One Fire WH-C17 lamp flickers when adjusting brightness. Is it faulty?

Flickering may happen at low battery or unstable USB power input. Try charging it fully or using a more stable USB source.

References

- [User Manual](#)

■ One
Fire

◆ B0D69WVF24, One Fire, One Fire WH-C17, Small Table Lamp, user manual, WH-
C17

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.