

Contents [[hide](#)]

- [1 OneClearWinner N100 Notebook](#)
- [2 Introduction](#)
- [3 Disclaimer](#)
- [4 Instruction](#)
- [5 Technical specification](#)
- [6 FCC Warning Statement](#)
- [7 Documents / Resources](#)
 - [7.1 References](#)



OneClearWinner N100 Notebook



Introduction

Dear users, Thank you for choosing Zenaero. This is a product elaborately developed by

Zenaero for freely surfing on the internet. Please read this user manual carefully before using the machine, so as to correctly use the functions of the machine.

Disclaimer

1. Please make sure to use the original power brick for charging. For problems or faults caused by any third-party adapter, the company does not undertake responsibility.
2. Users can use the music video, pictures, and software provided by third parties but we don't take any responsibility for the copyright issue or software fault.
3. If the product fails, we will strictly comply with the warranty terms, but in the process of use may cause property losses or economic losses, we will not be responsible.
4. The device comes with factory-built software that can be used after actual testing. However, if you delete or do not delete yourself while looking for compatibility or other issues, there will be no impact on the machine. Please note that it is not a product quality problem.
5. The company reserves the right to improve the product, product specifications and design are subject to change without prior notice!


Please refer to the real product.

The attentions

- Computers are precision electronic instruments, please do not disassemble by yourself.
- Avoid throwing collision.
- Avoid using the device in high temperatures, low temperatures, high humidity, dust, strong magnetic field, and long-term exposure to sunlight.
- Wipe gently the device by a wrung-out wet cotton cloth. Avoid contact with other chemicals.
- This device can't survive drip and splash water, and can't place it beside such as a full glass of liquid.
- Please use appropriate volume to avoid damaging your hearing.
- Please use the original battery, charger and other accessories. The use of any other type of accessories will violate the warranty and may cause the equipment to malfunction.

- Do not disconnect the device during formatting or ongoing uploads and downloads, or you may cause application errors.
- Dispose of waste machinery and accessories in accordance with local environmental regulations.
- If you have any questions during the use of the equipment, please contact your local distributor or contact our customer service center directly.
- The company reserves the right to improve the product, product specifications and design are subject.

Instruction



The way to turn on the laptop is to press the button, Please press the power button to turn on it. Please click “power off” in the OS to turn off the laptop.

Pressing the power button for several seconds by force to turn off the laptop can be used in special circumstances. What customers need to pay attention to is that frequent power-off by force may cause system files missing or crash of the laptop.

The solution of the common problem The

1. laptop can't boot

1. Check if the battery is fully charged.
2. Check the power adapter before starting the machine again.
3. If it is still unable to boot after charging, please contact with distributors.

2. WiFi can't work

1. Please confirm whether there is a WiFi hotspot.
2. Make sure that the is connected to the WIFI (enter the settings to check).
3. Please confirm the WIFI signal strength and link permission.

Technical specification

- System: Windows
- CPU Brand: Core™ i5-8210Y
- Screen size: 16"
- Screen scale: 16:10
- Resolution: 1920*1200 FHD
- Network Connection: 2.4G/5G 802.11a/b/g/n/ac
- Hot function: Bluetooth 5.0
- M.2 interface: (Built in hidden) 256GB/512GB/1TM
- Other interface: 4-stage Φ 3.5mm Earphone Jack*1 Micro SD*1 RJ45*1
TYPE-A HDMI*1 USB-A 3.0*3 Type-c*1 DC Port*1
- Battery capacity: 44Wh(7.6V/5800mAh)
- Charger: Input: AC100-240V==50-60Hz
Output: DC12V 2A 24W
- Size: 357.5*245*20mm
- Play format: Voice format: OGG, ACC, M4A, FLAC, AMR etc
Video format: AVI, MKV, MP4, M4V, WEBM, 3GP, MPEG4 etc

FCC Warning Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the

receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.


Caution: Any changes or modifications to this device not explicitly approved by the manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet the general RF exposure requirements.



Documents / Resources

	OneClearWinner N100 Notebook [pdf] User Manual 2BDJ4-UL160-TY, 2BDJ4UL160TY, R1569, N100 Notebook, N100, Notebook
---	--

References

- [User Manual](#)

2BDJ4-UL160-TY, 2BDJ4UL160TY, N100, N100 Notebook, Notebook, OneClearWinner, OneClearWinner R1569

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.