



oneLIGHT 38150A LED Linear Profile Instruction Manual

[Home](#) » [oneLIGHT](#) » oneLIGHT 38150A LED Linear Profile Instruction Manual 




Contents

- [1 oneLIGHT 38150A LED Linear Profile](#)
- [2 DIMENSIONS](#)
- [3 SURFACE INSTALLATION](#)
- [4 SUSPENDED INSTALLATION](#)
- [5 CONNECTION](#)
- [6 Documents / Resources](#)
- [7 Related Posts](#)


oneLIGHT 38150A LED Linear Profile




DIMENSIONS




SURFACE INSTALLATION



SUSPENDED INSTALLATION




CONNECTION



Warnings:

1. Make sure that the product is installed properly before connecting to electricity.
2. Do not cover the fitting.
3. Maintenance and installation should only be carried out by a professional electrician.

Documents / Resources



[oneLIGHT 38150A LED Linear Profile](#) [pdf] Instruction Manual
38150A, LED Linear Profile, 38150A LED Linear Profile, Linear Profile, Profile