

OneTemp U-Series Data Logger Instructions

[Home](#) » [OneTemp](#) » OneTemp U-Series Data Logger Instructions 

Contents

1 OneTemp U-Series Data Logger

2 Quick Start for the HOBO® U-Series Data Logger

3 Documents / Resources

3.1 References

4 Related Posts

OneTemp

OneTemp U-Series Data Logger



Specifications

- Model: 16125-F
- Interface: USB
- Software: HOBOWare
- Manufacturer: Onset
- Website: www.onsetcomp.com

Launching the Logger:

Connect the logger to your computer using a USB cable.

Using a New Logger:

1. Update the logger to the latest free software available at www.onsetcomp.com by searching for HOBOWare and downloading it.
2. Open the Launch Logger window, choose settings, and click Start.
3. Disconnect the logger and deploy it. Logging will begin based on the settings chosen in Step 3.

Frequently Asked Questions (FAQ):

Q: How do I update the software for the logger?

A: To update the software, visit www.onsetcomp.com, search for HOBOWare, and download the latest version for free.

Quick Start for the HOBO® U-Series Data Logger

Launching

1. Open HOBOWare® software (install first). Using a new logger model? Update to the latest free software at: www.onsetcomp.com. Search for HOBOWare free download.
2. Connect logger to computer with USB cable. Connect any sensors to logger.



3. Open Launch Logger window. Choose settings. Click Start.



Device > Launch

4. Disconnect logger and deploy it. Logging will begin as determined by settings in Step 3.



Reading Out

5. Connect logger to computer and read it out (or use a HOBO U-Shuttle).



Device > Readout

6. Plot data from logger. Print the plot, export data, save it as a project file, and more.



7. Relaunch and redeploy logger as needed.

For detailed specifications and information about this logger, scan the code or go to:



www.onsetcomp.com/resources


© 2012–2023 Onset Computer Corporation. All rights reserved. Onset, HOBO, and HOBOWare are trademarks or registered trademarks of Onset Computer Corporation.

This product has been manufactured by Onset Computer Corporation and in compliance with Onset's ISO 9001:2015 Quality Management System.



U.S. and International Sales: 1-[508-759-9500](tel:508-759-9500) • www.onsetcomp.com/support/contact

Documents / Resources

	<p>OneTemp U-Series Data Logger [pdf] Instructions U-Series, U-Series Data Logger, Data Logger, Logger</p>
---	--

References

- [0 Onset HOBO and InTemp Data Loggers](#)
- [0 HOBO Resources | Onset's HOBO and InTemp Data Loggers](#)
- [0 Technical Support | Onset's HOBO and InTemp Data Loggers](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.