

[Skip to content](#)

Manuals+

User Manuals Simplified.



Onn Soundbar User Manual

[Home](#) » [Onn](#) » Onn Soundbar User Manual

USER MANUAL




36" 5.1 Soundbar

Contents [[hide](#)]

- 1 What's in the Box?
- 2 Get to Know Your 36" 5.1 SOUNDBAR
- 3 Remote Control Overview
- 4 Using the HDMI IN or HDMI ARC connection
- 5 Using the AUX or Optical Connection
- 6 Bluetooth Connection and 5.1 System Connection
- 7 Using The Bluetooth Connection
- 8 Connection to the Power Outlet
- 9 Product Wall Mounting the first step
- 10 Product Wall Mounting the second step
- 11 Product Wall Mounting the Third Step
 - 11.1 Specification
 - 11.2 Related Manuals:


What's in the Box?

Check to make sure you have everything below.




1. Main unit
2. Subwoofer
3. Satellite Speaker x 2
4. RCA to RCA Cable x 2
5. Remote Control
6. Power Cord x 2
7. AUX Cable x 1
8. HDMI Cable x 1
9. Optical Cable x 1
10. QSG x 1
11. User manual x 1

Get to Know Your 36" 5.1 SOUNDBAR




1. LED Indicator
 - Red when the unit is in STANDBY mode.
 - Lights up yellow in AUX mode.
 - Lights up green in OPTICAL mode.
 - Lights up blue in BLUETOOTH mode.
 - Lights white in HDMI(ARC)mode.
 - Lights up orange in HDMI IN mode
2. Remote Control Sensor
3. HDMI IN Port
4. HDMI ARC Port
5. OPTICAL Port
6. AUX IN Port
7. AC IN Port
8. Button Switches the unit between ON and STANDBY modes
9. SOURCE Button
Selects the input source
10. VOL- Button
Decreases the volume
11. VOL+ Button
Increases the volume


Rear View of Subwoofer



Rear View of Satelites




Remote Control Overview



1. ⏻ Button Switches the unit between ON and STANDBY modes.
2. Press AUX button, device will play audio from aux input.
3. Press OPTICAL button, device will play audio from optical input.
4. VOL+ button increases the volume.
5. ⏮ button skip to previous track in Bluetooth mode.
6. ⏸ button to play/pause music in Bluetooth mode.
- RESET button to reset device to the factory default settings.
7. VOL- button decreases the volume.
8. BASS- button decrease bass
9. TREB- button decrease treb
10. Press EQ button to select music, movie and talk EQ mode.
11. 🔊 button mutes the unit or resumes the sound.
12. Press HDMI IN button, device will play audio from HDMI IN input.
13. Press HDMI ARC button, device will play audio from HDMI ARC input.
14. 📶 Bluetooth Connection switches to Bluetooth mode, press and hold to enable bluetooth pairing if there is an existing connection then disconnect the devices, unit will enter pairing mode.
15. ⏭ button skip to next track in Bluetooth mode.
16. BASS+ button increase bass
17. TREB+ button increase treb


Using the HDMI IN or HDMI ARC connection

Use a HDMI cable (included) to connect the TV's HDMI OUT Port to the soundbar's HDMI IN Port.



HDMI cable (included) length is 1.7m
Please note the soundbar has HDMI CEC function

Use a HDMI to HDMI cable (included) to connect the TV's HDMI (ARC) port to the soundbar's HDMI(ARC) port.




HDMI cable (included) length is 1.7m


Using the AUX or Optical Connection

Use a 3.5mm to RCA stereo audio cable (not included) to connect the TV's audio output Port to the soundbar's AUX IN port.

Use a 3.5mm to 3.5mm stereo audio cable (included) to connect the TV's headphone Port to the soundbar's AUX IN port.



Use an optical cable (included) to connect the TV's OPTICAL OUT Port to the soundbar's OPTICAL Port.



Bluetooth Connection and 5.1 System Connection

Establish Bluetooth connection


When unit powers on, press source button on soundbar or press the Bluetooth key on the remote change to Bluetooth(Bluetooth ID: Onn 36" 5.1 Soundbar) mode to enter Bluetooth pairing mode, the blue LED indicator will fast flash, the LED indicator remain solid bright when Bluetooth connected.

Pairing the subwoofer

Pair manually: Long press mute on the remote for 7s, then long press pairing button on subwoofer for 3s, soundbar's current LED indicator and subwoofer's mixed-color(mixed by red and blue) LED will quick blink until be paired each other.


After connected, led indicator will remain solid bright.

PS: Subwoofer is paired with soundbar before ex-factory, when power on, they will be connected each other automatically.




Using The Bluetooth Connection

- Turn on the power, press () on the unit or remote control to switch the unit to ON mode with a prompt tone.
- Keep the distance of the soundbar and your mobile phone, PC, tablet or other Bluetooth enabled device within 1 meter, The closer, the better.
- Ensure Bluetooth is enabled on your device and that your device is discoverable.
- Select the Bluetooth mode on the soundbar. -Using the remote control, press the Bluetooth button. The indicator light on the soundbar will be flashing blue. -Alternatively, press the source button on the soundbar until the indicator light is flashing blue.
- Select the Bluetooth search function on your device. Your device should discover the soundbar which is called "Onn 36" 5.1 soundbar".
- Select pairing mode: -Using the remote control, press and hold the Bluetooth button for 3 seconds until blue indicator light is flashing slowly. -Alternatively, press and hold the source button on the soundbar for 3 seconds until the blue indicator light is flashing slowly.
- Select the Bluetooth search function on your device. Your device should discover the soundbar which is called "Onn 36" 5.1 soundbar ".
- Select "Onn 36" 5.1 soundbar". your device is paired with the soundbar when the blue indicator light stops flashing and becomes solid.



Connection to the Power Outlet


Connect the AC IN port to the power outlet by power cable.



Ensure all audio connections of the unit are connected before connecting to the mains power outlet.

Product Wall Mounting the first step

1. Drill 2 parallel holes (98mm each according to well type) in the wall. The distance between the holes should be 580mm.




- Installation must be carried out by qualified personnel only. Incorrect assembly can result severe personal injury and property damage (If you intend to Install this product yourself, you must check for installations such as electrical wiring and plumbing that may be bundle inside the wall). It is the installer's responsibility to verify that the wall will safely support the total load of the Soundbar.

- Additional tools (not included) are required for the installation.
- Do not overtighten screws.
- Keep this instruction manual for future reference.
- Use an electronic stud finder to check the wall type before drilling and mounting.


Product Wall Mounting the second step

2. Firmly fix 1dowel D10.2*L30mm (not included) into each hole in the wall if necessary.




Product Wall Mounting the Third Step

3. Insert 1 screw TA 9.40mm (not included) into each anchor. Be sure to leaves 6mm gal, between the wall and the screw's head. Lift the unit over the heads of the screws and slot into place




Battery Replacement for the Remote Control the First Step

Lift up the back cover to open the battery compartment of the remote control.




Battery Replacement for the Remote Control the Second Step

Insert two AAA two batteries. Make sure the (+) and (-) ends of the batteries match the (+) and (-) ends indicated in the battery compartment.




Battery Replacement for the Remote Control the Third Step

Close the battery compartment cover.



Remote Control Operation Range

The remote control sensor on the front unit is sensitive to the remote control's commands up to a maximum of 15' away and within a maximum of a 60 arc.




BATTERY SAFETY GUIDELINES

Used correctly, domestic batteries are a safe and dependable source of portable power. Problems can occur if they are misused or abused – resulting in leakage or, in extreme cases, fire or explosion. Here are some simple guidelines to safe battery use designed to eliminate any such problems.



Take care to fit your batteries correctly, observing the plus and minus marks on the battery and appliance. Incorrect fitting can cause leakage or, in extreme cases, fire or even an explosion.



Replace the whole set of batteries at one time, taking care not to mix old and new batteries or batteries of different types, since this can result in leakage or, in extreme cases, fire or even an explosion.






Store unused batteries in their packaging and away from metal objects which may cause a short-circuit resulting in leakage or, in extreme cases, fire or even an explosion.



Remove dead batteries from equipment and all batteries from equipment you know you are not going to use for a long time. Otherwise the batteries may leak and cause damage.



Never dispose of batteries in fire as this can cause them to explode. Please recycle dead batteries; do not put with the normal household waste.



Specification

Model	100008866
AC IN	Input AC 120V 60Hz
Peak Power	400W
Power Consumption	100W
Net Weight	9.8Kg
Dimension	Subwoofer 200mm(W) x 300mm(D) x 300mm(H) Satellite 80mm(W) x 65mm(D) x 240mm(H)

Features and specifications are subject to change without prior notice.

[Onn-Soundbar-Manual-Optimized](#) [Optimized PDF](#)

[Onn-Soundbar-Manual-Original](#) [Download](#)

Questions about your Manual? Post in the comments!

Related Manuals:

1. [onn. 36" 5.1 Soundbar User Manual](#) onn. 36" 5.1 Soundbar User Manual - Download [optimized] onn....
2. [Onn Remote Code Lookup Tool - For All ONN Remotes](#) Onn Remote Codes Lookup...
3. [onn indoor Speaker User Manual](#) What's in the Box? Check to make sure you have...
4. [Onn Earbuds 10005529 User Manual \[ONN5529. ONN5530\]](#) USER MANUAL Onn Earbuds Models: ONN5529, ONN5530 Get to Know...
5. [Onn Universal Remote 39900 User Guide](#) Universal Remote Model: 39900 & ONA12AV058 PRODUCT MANUAL Table of...
6. [Onn 6-Device Universal Remote User Guide](#) USER MANUAL Onn 6-Device Universal Remote Model: 100008755 Need help?...