Status indicator reference

First time setup
Quick red flashes

Pairing mode
Quick green flashes

Pairing success
Long green flash

Unpairing success
Slow red flashes

Motion sensed
Quick red flash

Signal disconnected
Long red flash

Motion Sensor User Manual

ooma motion sensor
Quick Start Guide

Contents

Key Features

A Status indicator light (hidden)

B Motion sensor lens

C Standing attachment

D Pairing button

E Tamper sensor

F Battery door

G Magnetic mounting plate

Step 1 Install the App

To get started, download and install the **Ooma Home Security** app on your iOS or Android device.
The app can be found at: **ooma.com/app**
When the app is installed, log in using your Ooma phone number and My Ooma password. If you forgot your password, reset it at: **my.ooma.com**
Complete the initial setup in the app.

Step 2 Pair Your Sensor

For the best pairing performance, hold your sensor within 10 feet of your Telo.

In the mobile app, press the "Add Sensor" button on the Dashboard. Select the type of sensor you would like to pair.

Follow the instructions on your screen to pair your sensor.

10 feet

Step 3 Mount Your Sensor

If you are using the included adhesive pads to mount your sensor, use a damp cloth to wipe the surface where you are placing your sensor.

Use the included adhesive pads or screws to mount the sensor within range of the desired area.

Field of view = 85°

Maximum range = 35 ft

If desired, the motion sensor may be mounted in a 90˚ corner using these four screw mounts.

ooma

PUSH

The included Standing attachment can be used to install the motion sensor on any flat surface without adhesive pads or screws.

First-time setup
After installing batteries for the first time, the initial setup lasts 30 secs. The status indicator blinks red until complete.

Starting pairing mode
Press and hold for pairing button for five seconds to start the pairing mode. Status indicator quickly blinks green while in this mode.

Status indicator reference

First time setup
Quick red flashes

Pairing mode
Quick green flashes

Pairing success
Long green flash

Unpairing success
Slow red flashes

Motion sensed
Quick red flash

Signal disconnected
Long red flash

Motion Sensor User Manual – **Optimized PDF**
Motion Sensor User Manual – **Original PDF**

Manuals+,