




## optimum CS-14553 Gateway Instruction Manual

[Home](#) » [optimum](#) » optimum CS-14553 Gateway Instruction Manual 



### CS-14553 Gateway Instruction Manual


These instructions will guide you through installing or replacing a Gateway 5

#### Contents



- [1 New customers – Start here](#)
- [2 Documents / Resources](#)
  - [2.1 References](#)
- [3 Related Posts](#)

→ **New customers – Start here**


If you're a new customer with Optimum, use your phone camera to scan the QR code on the packing slip that came with your shipment. The code will take you to a website that will help you install and activate your new equipment.




→ **All other customers** –please follow the instructions below to replace your equipment.

<div><div>1</div><div>UNPLUG EXISTING EQUIPMENT</div><div></div></div> <div>Disconnect everything from your existing equipment.</div>	<div><div>2</div><div></div></div> <div>Connect the open end of your coaxial cable to the back of the new Gateway.</div>
--	--

3




4



Plug the Gateway power cord into the back of the device.

Plug the other end of the power cord into an electrical outlet.

5



The Gateway is ready for the next step when the top 3 lights (POWER, DS/US, ONLINE) on the front panel are solid green. This may take a few minutes.

6

 | [optimum.net/gateway](https://optimum.net/gateway)

OR



Sign in at [optimum.net/gateway](https://optimum.net/gateway) to personalize your in-home WiFi network name, also called an SSID, and your password. Can't remember or don't have an Optimum ID? Visit [optimum.net/idhelp](https://optimum.net/idhelp). If you'd rather use the defaults, look at the label on the bottom of the Gateway. Note, that your password will be listed as the "Wi-Fi Pre-Shared Key".


7




To connect to the Internet, go to WiFi settings on your device. Select your in-home WiFi network name from the list and when prompted, enter your password. Repeat this step for all of your connected devices.

8

OPTIMUM TV BOX




 | [optimum.net/guides](https://optimum.net/guides)

If you have an Altice One Mini, you need to re-pair it to the Gateway. Refer to the "Replacing an Altice One Mini" instructions at [optimum.net/guides](https://optimum.net/guides). If not, you're all set!



Once you've connected  
and powered on your new  
Gateway, call 877.851.5652 to  
begin the activation process.

## Documents / Resources

	<a href="#">optimum CS-14553 Gateway</a> [pdf] Instruction Manual CS-14553 Gateway, CS-14553, Gateway
---	--

## References

- [Optimum | TV, Phone and Internet Support Home](#)
- [Sign In to Manage Your Services | Optimum](#)
- [View Optimum User Guides | Optimum](#)
- [Optimum | Need help with your Optimum ID and password?](#)
- [Optimum | Equipment Shipping Instructions](#)